

AKD System Configuration with Kollmorgen

KBM Frameless Motors

By Kenny Hampton and Todd Evans

3/12/2017

Rev. A Published

This document shows the wiring requirements for connecting the KBM frameless motor and the feedback of your choice to the AKD servo drive. It also describes the setup procedure for configuring the AKD drive in the Workbench software and getting the motor to commute correctly.

Table of Contents

Section	Page
Conventions and Connections Overview	3
Conventions	3
Orientation	4
Feedback Wiring and Rotation Direction Conventions and Overview	5
Summary Of Remedies If The Feedback Counts Negative in the standard rotational convention	6
Minimum Wiring Requirement for the AKD Drive	7
Motor and Halls Overview	8
Outline Drawing	8
Motor Power	8-9
-Standard	8-9
-Non-Standard	8-9
AKD Primary Feedback X10	10
Halls	11
-Standard	11
-Non-Standard	11
Motor Back EMF and Hall Sensor Signal Alignment	12-13
Feedback	14
-Incremental Encoder With Halls	14
-Incremental Encoder Without Halls	15
-Sine Encoder With Halls	16
-Sine Encoder Without Halls	17
-Resolver	18
-Feedback Types With Serial Communications (BISS,BISS C Renishaw EnDat, Hiperface)	19
Thermal Sensor	20-21

Configure the AKD Drive Using the Workbench Software	22
1. Safety First	22
2. Connect to the AKD Drive	23
3. EXPAND "SETTINGS" AND SELECT THE MOTOR SETUP SCREEN	24
4. Select Motor from Pull Down List	25
5. Select Motor Temperature Sensor	26-28
6. Select the Feedback Type	29
7. Configuring Encoder Feedback Resolution	30
8. Test Encoder Direction and Resolution	31-33
9. Test Hall Sequence When Moving Motor In The Positive Direction	34-35
10. How to Verify the Motor's Commutation Alignment Angle: MOTOR.PHASE for feedback that requires W&S on power up.	36
a. Start The Wake and Shake Routine	37
b. Verify The Motor is Setup Correctly By Jogging It In Both Directions	38
11. How To Verify the Motor's Commutation Alignment Angle: MOTOR.PHASE for feedback that does not require W&S on power up.	39-40
a. Start the Commutation Alignment Routine	39-40
b. Verify The Motor is Setup Correctly By Jogging It In Both Directions	40


Conventions and Connections Overview

Conventions

The preferred standard electrical connections between the AKD-drive to KBM(s) - frameless motor, unless specifically stated otherwise, are based upon a C.C.W. rotation of the rotor as viewed from the lead-exit end of the motor, for a positive count direction of the position-loop. In addition, to help clarify one motor phase or Hall feedback signal, to another, an underlined last letter is utilized under the point of electrical reference; hence, phase-UV, reads: phase-U, with respect to phase-V, leads V, by 120-degrees with a C.C.W. rotation of the rotor; or where a positive Hall-1 (H1) signal, also defined as Huv (drive-Hu for the defined convention), reads: hall signal: H1 (Huv) is positive, and in phase with motor's Bemf, phase-U, with respect to motor phase-V, with a C.C.W. rotation of the rotor.

This document shows color codes that are typical for the KBM(S) motors. Always check the outline drawing of your specific KBM(S) motor to verify the color coding of the motor power (for both KBM and KBMS motors and halls (KBMS)).


Here is an example of these details on a KBMS outline drawing.




Orientation

As stated above the KBM motor uses the following convention.

If the motor is mounted upside down and you are viewing the lead exit side of the motor then the rotation for standard phasing will be CCW.



If the motor is mounted in an upright position and you are viewing the non-exit side of the motor then the rotation for standard phasing will be CW.



Feedback Wiring and Rotation Direction Conventions and Overview

Before proceeding to check feedback wiring and direction online in Workbench it is important to understand the concept and importance of motor power phasing in agreement with feedback direction based on orientation and rotation direction conventions stated above.

Concept:

FB1 is expected to count up in the orientations and directions given above.

This can be checked with the drive disabled and the primary feedback wired to X10.

Make sure Drive Direction "DRV.DIR = 0" is set to zero. This should be added where you referencing how feedback is counting

In this example BISS is used.

The screenshot displays the 'Feedback 1 (X10)' configuration window. On the left, a 'Device Topology' tree shows the project structure, including 'no_name (Online)*' and its sub-components like 'Settings', 'Communication', 'Power', 'Regen', 'Motor', 'Feedback 1', 'Wake and Shake', 'Feedback 2', 'Foldback', and 'Brake'. The main configuration area includes:

- Feedback Selection:** -1 - Auto Identify
- Feedback Identified:** BiSS
- Motor Autoset:** 1 - On
- Position Feedback:** 321,596,239.125 counts (highlighted in green)
- Drive Direction:** 0
- Sine Cycles/Revolution:** 2,048
- Biss Sensor Bits:** 32

A central diagram shows a circular dial with a needle pointing to 305.104°. Red arrows indicate the direction of rotation: clockwise for positive and counter-clockwise for negative. Text next to the dial states: 'If you rotate the motor shaft you should see the dial move.' A 'Goto Wake and Shake' button is located at the bottom right of the configuration area.


If the feedback counts DOWN when manually rotating the rotor in the orientations given above then the feedback type will determine how to remedy the conflict which may require either the motor and/or the feedback phasing to change. This will be covered in more detail later in this application guide.

Summary:

If feedback counts are negative in the direction of rotation for standard convention


Feedback Type	Feedback Remedy	Motor Remedy	Wake and Shake Required?
Halls Only	This is beyond the scope of this application note; see the support documentation for AKD Halls Only operation.		
Resolver	Swap Sin + and Sin -	Not required	No
Incremental Encoder no halls	Swap A+ and A-	Not required	Yes
Incremental encoder with halls	Swap A+ and A- and Swap Halls U and V	Swap Motor U and W	No
Sine Encoder without Halls	Swap Sin+ and Sin-	Not required	Yes
Sine encoder with Halls	Swap A+ and A- and Swap Halls U and W	Swap Motor U and W	No
EnDat with analog	Feedback Direction cannot be inverted by wiring; motor phasing must change	Swap Motor U and W	No
EnDat digital only	Feedback Direction cannot be inverted by wiring; motor phasing must change	Swap Motor U and W	No
BISS with analog	Feedback Direction cannot be inverted by wiring; motor phasing must change	Swap Motor U and W	No
Renishaw BISS C (digital only)	Feedback Direction cannot be inverted by wiring; motor phasing must change	Swap Motor U and W	No
Hiperface with analog	Feedback Direction cannot be inverted by wiring; motor phasing must change	Swap Motor U and W	No
Hiperface DSL (digital only)	Feedback Direction cannot be inverted by wiring; motor phasing must change	Swap Motor U and W	No

MINIMUM WIRING REQUIREMENT FOR THE AKD DRIVE



Motor and Halls Overview

Example Wiring (see outline drawing for your specific model to verify color codes):



Motor Power Standard Convention


KBM Motor Connection	Typical KBM Motor Color	AKD Terminal X2
U	Blue	U
V	Brown	V
W	Violet	W
GND/PE (GND/PE)	Green/Yellow Stripe	GND/PE
Shield (to GND/PE)	Shield	GND/PE

Motor Power Non-Standard Convention (where motor phasing must change; note this is shown as a change on the drive end):


KBM Motor Connection	Typical KBM Motor Color	AKD Terminal X2
U	Blue	W
V	Brown	V
W	Violet	U
GND/PE (GND/PE)	Green/Yellow Stripe	GND/PE
Shield (to GND/PE)	Shield	GND/PE

Important! Often at the time of commissioning the KBM motor is already housed and wiring has been terminated to connectors or extended with a cable. In this case often the motor power lead color codes will change from the motor lead exit via the motor power extension cable or through-port connectorization, etc. It is extremely important to trace and label the wires at the drive end so the cable color code and phasing is known relative to the KBM's stator exit lead color code and phasing conventions.

AKD-x003 to 024, power connector X2




AKD-x048, power connector X2



AKD Feedback X10

AKD Feedback X10

Feedback connector (X10)



PIN	SFD	SFD3/DSL	Resolver	BiSS B (analog)	BiSS C (digital)	EnDAT 2.1	EnDAT 2.2	Hiperface	Sine Enc. +Hall	Tamagawa Smart Abs*	Incr. Enc. +Hall
1	-	-	-	-	-	-	-	-	Hall U	-	Hall U
2	-	-	-	CLK+	CLK+	CLK+	CLK+	-	Hall V	-	Hall V
3	-	-	-	CLK-	CLK-	CLK-	CLK-	-	Hall W	-	Hall W
4	SEN+	-	-	SEN+	SEN+	SEN+	SEN+	SEN+	SEN+	SEN+	SEN+
5	SEN-	-	-	SEN-	SEN-	SEN-	SEN-	SEN-	SEN-	SEN-	SEN-
6	COM+	COM+	R1 Ref+	DAT+	DAT+	DAT+	DAT+	DAT+	Zero+	SD+	Zero+
7	COM-	COM-	R2 Ref-	DAT-	DAT-	DAT-	DAT-	DAT-	Zero-	SD-	Zero-
8	-	-	Thermal control (+)								
9	-	-	Thermal control (-)								
10	+5V	+5V	-	+5V	+5V	+5V	+5V	+8 to +9V	+5V	+5V	+5V
11	0V	0V	-	0V	0V	0V	0V	0V	0V	0V	0V
12	-	-	S1 SIN+	A+	-	A+	-	SIN+	A+	-	A+
13	-	-	S3 SIN-	A-	-	A-	-	SIN-	A-	-	A-
14	-	-	S2 COS+	B+	-	B+	-	COS+	B+	-	B+
15	-	-	S4 COS-	B-	-	B-	-	COS-	B-	-	B-

CLK = CLOCK, DAT = DATA, SEN = SENSE, *= for AKD with "NB" (rev 8+) only

Halls

As previously stated, this application note covers halls when used with either incremental with halls or sine encoder with halls feedback device. Halls only commutation is beyond the scope of this guide and the user should refer to the AKD Halls Only application note on the KDN website.

The 2 feedback types covered in this application note where halls would be used (with the KBMS) is for either 1) Comcoder (incremental encoder with halls) or 2) Sine Encoder with Halls

Standard

KBM Hall Channel	KBM Color	AKD Motor Terminal Connection	AKM X10 Terminal
Hall U (H1)	Brown	Hall U (H1)	Pin 1
Hall V (H2)	Orange	Hall V (H2)	Pin 2
Hall W (H3)	Violet	Hall W (H3)	Pin 3
Common	Green/Common	Common (0 V)	Pin 11
Shield (GND/PE)	Shield	Shell	Shell

Non-Standard

In this case Halls U (H1) and V (H2) are swapped at the drive side X10 connection

KBM Hall Channel	KBM Color	AKD Motor Terminal Connection	AKM X10 Terminal Pin
Hall U (H1)	Brown	Hall V (H2)	Pin 2
Hall V (H2)	Orange	Hall U (H1)	Pin 1
Hall W (H3)	Violet	Hall W (H3)	Pin 3
Common	Green/Common	Common (0 V)	Pin 11
Shield (GND/PE)	Shield	Shell	Shell

MOTOR BACK EMF AND HALL SENSOR SIGNAL ALIGNMENT (STANDARD)

The following assumes the user has an oscilloscope where the inputs and/or probes are isolated from earth ground.

I. HALL SIGNALS –versus- MOTOR PHASES (of a presentment as an oscilloscope plot):






Figure 3

When using a Kollmorgen KBM motor and when the feedback direction is positive toward the “Lead Exit End” of motor (that is, the end of the motor where the leads come out) rotated in a CCW direction when viewing from the lead exit end or CW from the opposite end of the motor then the hall alignment and motor phasing will match exactly as shown in Figure 3.

When determining the motor phasing, the U phase (U phase with reference to V phase) will lead the back emf voltage waveform by 120° of the V phase (V phase with reference to W phase) when the motor is manually turned using the directional convention of the KBM motor (CCW with respect to the lead exit of the stator).



The following shows with the same direction as above, the motor V phase (V phase with reference to W phase) will lead the back emf voltage waveform by 120° of W phase (W phase with reference to U phase).



FEEDBACK

Incremental Encoder With Halls

With the normal convention the wiring is shown. If the counts go DOWN with that convention then swap A+ and A- and swap halls U and V. The motor phasing must change where phases U and W must change at the drive end (Non-Standard Convention; see overview section).


9.12.13 Incremental Encoder

Feedback devices, which do not deliver absolute information for commutation, can either work with wake&shake commutation (see *WorkBench Online Help*) or can be used as a complete feedback system when combined with an additional Hall encoder. All signals are connected using a pre-assembled comcoder connection cable. The thermal control in the motor is connected via the encoder cable and evaluated in the drive.

If cable lengths of more than 25 m are planned, please consult customer support.

Type	FBTYPE	Frequency Limit
Incremental Encoder&Hall Switches (Comcoder)	10	2.5 MHz
Incremental Encoder (Wake&Shake)	11	2.5 MHz

The pin assignment shown on the encoder end relates to Kollmorgen AKM motors.



Non-Standard Convention: In this case Halls U (H1) and V (H2) are swapped at the drive side X10 connection

KBM Hall Channel	KBM Color	AKD Motor Terminal Connection	AKM X10 Terminal Pin
Hall U (H1)	Brown	Hall V (H2)	Pin 2
Hall V (H2)	Orange	Hall U (H1)	Pin 1
Hall W (H3)	Violet	Hall W (H3)	Pin 3
Common	Green/Common	Common (0 V)	Pin 11

Incremental Encoder without Halls

With the normal convention the wiring is shown. If the counts go DOWN with that convention then swap A+ and A-. Motor Phasing does not change from the Standard Convention.


9.12.13 Incremental Encoder

Feedback devices, which do not deliver absolute information for commutation, can either work with wake&shake commutation (see *WorkBench Online Help*) or can be used as a complete feedback system when combined with an additional Hall encoder. All signals are connected using a pre-assembled comcoder connection cable. The thermal control in the motor is connected via the encoder cable and evaluated in the drive.

If cable lengths of more than 25 m are planned, please consult customer support.

Type	FBTYPE	Frequency Limit
Incremental Encoder&Hall Switches (Comcoder)	10	2.5 MHz
Incremental Encoder (Wake&Shake)	11	2.5 MHz

The pin assignment shown on the encoder end relates to Kollmorgen AKM motors.




Sine Encoder with Halls

With the normal convention the wiring is shown. If the counts go DOWN with that convention then swap A+ and A- and swap halls U and V. The motor phasing must change where phases U and W must change at the drive end (Non-Standard Convention; see overview section).

9.12.12 Sine Encoder

Feedback devices, which do not deliver absolute information for commutation, can either work with wake&shake commutation (*WorkBench Online Help*) or can be used as a complete feedback system when combined with an additional Hall encoder. All signals are connected to X10 and evaluated there. If cable lengths of more than 25 m are planned, please consult customer support.

Type	FBTYPE	Up	Frequency Limit
SinCos 1 V p-p with Hall	20	5.1 V +/-5%	1 MHz, 250 kHz for encoders that require termination resistors
SinCos 1 V p-p (Wake&Shake)	21	5.1 V +/-5%	



Non-Standard Convention: In this case Halls U (H1) and V (H2) are swapped at the drive side X10 connection

KBM Hall Channel	KBM Color	AKD Motor Terminal Connection	AKM X10 Terminal Pin
Hall U (H1)	Brown	Hall V (H2)	Pin 2
Hall V (H2)	Orange	Hall U (H1)	Pin 1
Hall W (H3)	Violet	Hall W (H3)	Pin 3
Common	Green/Common	Common (0 V)	Pin 11


Sine Encoder Without Halls

With the normal convention the wiring is shown. If the counts go DOWN with that convention then swap A+ and A-. Motor Phasing does not change from the Standard Convention.

9.12.12 Sine Encoder

Feedback devices, which do not deliver absolute information for commutation, can either work with wake&shake commutation (*WorkBench Online Help*) or can be used as a complete feedback system when combined with an additional Hall encoder. All signals are connected to X10 and evaluated there. If cable lengths of more than 25 m are planned, please consult customer support.

Type	FBTYPE	Up	Frequency Limit
SinCos 1 V p-p with Hall	20	5.1 V +/-5%	1 MHz,
SinCos 1 V p-p (Wake&Shake)	21	5.1 V +/-5%	250 kHz for encoders that require termination resistors



Resolver


With the normal convention the wiring is shown. If feedback counts DOWN, swap SIN+ with COS+ and SIN- with COS-. Motor Phasing does not change from the Standard Convention.

9.12.4 Resolver

The diagram below shows the connection of a resolver (2 to 36-poles) as a feedback system. The thermal control in the motor is connected via the Resolver cable and evaluated in the drive. If no thermal control is in the motor, the cable must short pins 8 and 9. If cable lengths of more than 100 m are planned, please contact customer support.

Type	FATYPE	Description
Resolver	40	Accuracy: 14 bit (0.022°), resolution: 16 bit (0.006°)

The pin assignment shown on the Resolver end relates to Kollmorgen motors.



Feedback Devices with Serial Communications (without or without analog/all digital):

With the given convention, the following feedback types, if your counts go DOWN because of the mechanical orientation of the installed feedback device then the feedback direction for commutation cannot be changed by wiring. The motor phasing is the only wiring that can change to correct for this.

Feedback Devices this applies to:

EnDat 2.1 with analog

EnDat 2.2 all digital

BISS with analog

BISS (Renishaw BISS C all digital)

Hiperface with analog

Hiperface DSL (all digital)

See the AKD Installation manual for wiring connections. The KDN has application notes regarding Renishaw BISS C wiring conventions and setup of the feedback device in Workbench.

Thermal Device


Per the following nomenclature, the 2 standard offerings for thermals on the KBM(S) motors are the PTC type thermistor and the KTY84-130.

Mechanical Options

00=PTC Single Thermistor

01=PTC Single Thermistor

03= KTY84/130



① S rating not available on frame sizes 10, 14, 17, 25, 35, and 45.

Before proceeding keep in mind the KBM frameless motor is available in high customized models and part numbers. The following is general information and to ensure the proper setup of the motor thermal settings and protection in the AKD drive it is important to acquire the datasheet for your exact model number which will include data such as thermal switching resistance, etc.

The KBM motor frame size 10,14,17,25,35, and 45 all use a single PTC thermistor for -X00 or X01 models. X03 models use a KTY84/130.


The KBM 43 has a Triplex configuration (three PTC's in series and all located in different sections of the stator)

The same trip point should be at or near the same resistance on this Triplex configuration as was on the single PTC device. The triplex configuration has the same resistance point on the upper end of the curve. The motor winding "critical temperature" is 155 deg C. The single PTC and the Triplex PTC show a resistance of 1330 ohms @ approx 155 degs C. **Workbench defaults to 1300 ohms when a KBM motor is selected on the Motor screen which can be left as such.**


Here is a sample thermistor curve:

Thermistors

To provide for continuous safe operation of KBM(S) series motors in demanding applications, integral thermistors are mounted in the stator. These passive devices provide an output characteristic [Avalanche type] as shown in the side table for use in typical control safety circuits as the temperature goes beyond the rating of the motor windings [155C]. The KBM(S)-10XXX through KBM(S)-35XXX and KBM(S)-45XXX motors all have a single avalanche type thermistor while the balance of the KBM(S) family motors have two or three wired in series or independently depending on the model number. Linear thermistors are optionally available for use in winding temperature data acquisition and exhibit a basically linear resistance characteristic over the operating range of the motor.



Feedback connector (X10)



PIN	SFD	SFD3/DSL	Resolver	BISS B (analog)	BISS C (digital)	EnDAT 2.1	EnDAT 2.2	Hiper-face	Sine Enc. +Hall	Tamagawa Smart Abs*	Incr. Enc. +Hall
1	-	-	-	-	-	-	-	-	Hall U	-	Hall U
2	-	-	-	CLK+	CLK+	CLK+	CLK+	-	Hall V	-	Hall V
3	-	-	-	CLK-	CLK-	CLK-	CLK-	-	Hall W	-	Hall W
4	SEN+	-	-	SEN+	SEN+	SEN+	SEN+	SEN+	SEN+	SEN+	SEN+
5	SEN-	-	-	SEN-	SEN-	SEN-	SEN-	SEN-	SEN-	SEN-	SEN-
6	COM+	COM+	R1 Ref+	DAT+	DAT+	DAT+	DAT+	DAT+	Zero+	SD+	Zero+
7	COM-	COM-	R2 Ref-	DAT-	DAT-	DAT-	DAT-	DAT-	Zero-	SD-	Zero-
8	-	-	Thermal control (+)								
9	-	-	Thermal control (-)								
10	+5V	+5V	-	+5V	+5V	+5V	+5V	+8 to +9V	+5V	+5V	+5V
11	0V	0V	-	0V	0V	0V	0V	0V	0V	0V	0V
12	-	-	S1 SIN+	A+	-	A+	-	SIN+	A+	-	A+
13	-	-	S3 SIN-	A-	-	A-	-	SIN-	A-	-	A-
14	-	-	S2 COS+	B+	-	B+	-	COS+	B+	-	B+
15	-	-	S4 COS-	B-	-	B-	-	COS-	B-	-	B-

CLK = CLOCK, DAT = DATA, SEN = SENSE, * = for AKD with "NB" (rev 8+) only

KBM Thermistor	KBM Color	AKD X10 Connection	AKM X10 Terminal Pin
+	Black	Thermal Control +	Pin 8
-	Blue	Thermal Control -	Pin 9
Shield (GND/PE)	Shield	Shield	Shell

Configure the AKD Drive Using the Workbench Software

Install AKD Workbench. The software program can be found on the website (<http://www.kollmorgen.com/en-us/products/drives/servo/akd/>), (<http://kdn.kollmorgen.com/>) and the Product Support Package (PSP) CD-ROM packaged with the drive. Follow the installation instructions. (If in doubt, install "Kollmorgen WorkBench GUI Full Version.")

1. SAFETY FIRST

When first starting up the system, it is recommended to limit the peak current of the drive to a safe value and add wood blocks at each motor end stop to confirm it is operating correctly. If the motor was to run away at its full output force capability, it could cause serious injury or damage to the equipment.

1: Click on the "LIMITS"

2: Lower the Peak Current values to a safe level

Section	Parameter	Value	Unit
Current Limits	Positive Peak Current:	9.000	Ams
	Negative Peak Current:	-9.000	Ams
	Dynamic Break Peak Current:	1.000	Ams
Velocity Limits	Positive Speed Limit:	3,000.000	rpm
	Negative Speed Limit:	-3,000.000	rpm
	User Over-Speed Limit:	9,599.894	rpm
	Overall Over-Speed Limit:	9,599.894	rpm
Position Limits	Maximum Position Error:	655,360	Counts16Bit
	Position Limit 0:	0	Counts16Bit
	Position Limit 1:	1,048,576	Counts16Bit
Acceleration Limits	Acceleration:	59.903	rpm/s
	Deceleration:	59.903	rpm/s
Motor Limits	Motor limits are set through the Motor Foldback Screen:		Goto Foldback

2. Connect to the AKD Drive

Follow the instruction from the WorkBench help file.

The screenshot displays the Kollmorgen WorkBench software interface. The top menu bar includes 'File', 'Edit', 'View', 'Tools', and 'Help'. Below the menu bar, there are buttons for 'Connect' and 'Panic'. The 'Device Topology' pane on the left shows a 'Start Page' and a 'Kollmorgen Device (169.254.250.201)'. The main window displays the 'Kollmorgen WorkBench Help' content, with a breadcrumb trail 'User Manual > Connecting the Drive'. The 'Contents' pane on the left lists various topics, with 'Connecting the AKD' highlighted. A callout box with the text '1: Click on the Help then on "Documentation -> AKD"' points to the 'Help' menu item. Another callout box with the text '2: Expand "AKD User Manual" and then "connect to the AKD"' points to the 'Connecting the AKD' item in the 'Contents' pane. The main content area shows the 'Connecting the Drive' page with a list of sub-topics: 'Connected and Disconnected States', 'Disconnected Device', 'Confirm Connection with the Device', 'Connect To Another Device', 'TwinCAT and Workbench Connection', and 'Troubleshooting Connection and Communication Problems'. The bottom of the interface shows a 'Watch' area with 'Enab...' and 'Device' tabs, and a 'Parameter' tab.

1: Click on the Help then on "Documentation -> AKD"

2: Expand "AKD User Manual" and then "connect to the AKD"

Copyright © 2014 Kollmorgen

KOLLMORGEN
Because Motion Matters

3. EXPAND "SETTINGS" AND SELECT THE MOTOR SETUP SCREEN

The screenshot displays the Kollmorgen WorkBench software interface. The top menu bar includes File, Edit, View, Tools, and Help. Below the menu is a toolbar with navigation icons and control buttons: Enable, Stop, 3 - Analog, 1 - Velocity Mode, Disable & Clear Faults, and Save T. The main window is divided into two panes. The left pane, titled "Device Topology", shows a tree structure under "no-name (Online)". The "Settings" folder is expanded, revealing a list of sub-items: Communication, Power, Regen, Motor, Feedback, Feedback 2, Foldback, Brake, Units, Modulo, Limits, Current Loop, Velocity Loop, Encoder Emulation (X9 Cfg), Analog Input, Analog Output, Digital I/O, Programmable Limit Switches, Compare Engines, Enable/Disable, Position Capture, and Performance Servo Tuner. The right pane, titled "Motor", displays configuration parameters for a motor. A callout box with the text "1: Click here to expand the tree" points to the "Settings" folder in the tree. Another callout box with the text "2: Click on 'Motor'" points to the "Motor" item in the tree. The Motor configuration screen includes a "Motor Name" field with the value "AKM31E-ANKI", a "Motor Type" dropdown menu set to "0 - Rotary, Per", and a "Motor Autoset" dropdown menu set to "0 - Off". Other parameters listed include Continuous Current, Peak Current, Instant, Inductance (quad, H), Inductance Saturation, Motor Poles, Motor Phase, Inertia, Torque Constant, EMF Constant, and Motor Resistance (H).

4. Select Motor from Pull Down List

Kollmorgen WorkBench

File Edit View Tools Help

Enable Stop 0 - Service 2 - Position Mode Disable & Clear Faults Save To Device Disconnect Panic

Device Topology

- Start Page
- AKD-PN (Online)*
 - Settings
 - Communication
 - Power
 - Regen
 - Motor**
 - Feedback 1
 - Feedback 2
 - Foldback
 - Brake
 - Units
 - Modulo
 - Limits
 - Home
 - Current Loop
 - Velocity Loop
 - Position Loop
 - Service Motion
 - Encoder Emulation (X9 Cfg)
 - Analog Input
 - Analog Output
 - Digital I/O
 - Programmable Limit Switches
 - Compare Engines
 - Enable/Disable
 - Position Capture
 - Motion Profile Table
 - Performance Servo Tuner
 - Slider Tuning
 - Motion Tasks
 - Drive Motion Status
 - Faults and Warnings
 - Scope
 - Parameter Load/Save

Motor

These parameters describe the motor attached to this drive.

Motor Name: AKM21C-ANBNAB00 **Select Motor...** 2. Click on "Select Motor"

Motor Type: 0 - Rotary, Permanent Mt Create Motor...

Field Weakening: 0 - Disabled

Motor Autoselect: 0 - Off 1. Turn off

Continuous Current: 1.578 Arms

Select Motor

Motor Learn more about this topic

Select the motor that is attached to the drive.

To attach a motor, first select Motor family and then Motor series.

Motor Family: KBM Series 3. Change Motor Family to correct motor type

Name: KBM-17H01-A 4. Select motor part number then click ok

To create new or edit existing custom motors:

Custom Motors...

Target Feedback: Feedback 1 Select the feedback connector that your motor is connected to.

OK Close



NOTE

If the motor cannot be found in the database, Custom motors can be setup using the "Edit Custom Motors" tools under "Edit" on the tool bar. Instructions for use can be found in the WorkBench help file.

5. SELECT MOTOR TEMPERATURE SENSOR


Per the following nomenclature, standard KBM(S) motors have PTC avalanche type thermistors embedded in the stator for motor thermal protection. Other sensors are available:

Mechanical Options

00=PTC Single Thermistor

01=PTC Single Thermistor

03= KTY84/130




① S rating not available on frame sizes 10, 14, 17, 25, 35, and 45.

The 2 standard offerings we have are the PTC type thermistor and the KTY84-130. Trip point in the drive, from my understanding, would be set to 1330 Ohms, which equates to about 150 – 155°C winding temp.

The KBM has a 155°C motor winding temperature rating with integral thermistor

Before proceeding keep in mind the KBM frameless motor is available in high customized models and part numbers. The following is general information and to ensure the proper setup of the motor thermal settings and protection in the AKD drive it is important to acquire the data such as thermal switching resistance, etc. for your exact model number from Kollmorgen.


The KBM motor frame size 10,14,17,25,35, and 45 all use a single PTC thermistor for -X00 or X01 models. X03 models use a KTY




Note to double-click on “Motor” to expand the project tree if “Motor Temperature” is not visible.

1. Thermistor Option type “00 or 01” Single PTC thermistor sensor

Kollmorgen DDL linear motors use a PTC thermistor sensor if the Thermostat Option selected is TR “Thermistor” (MOTOR.RTYPE = 0, “Single PTC Thermistor”). When the KBM motor is selected in Workbench on the Motor screen,



2. Thermostat Option type "03": KTY84-130





Motor Temperature


Monitor the motor temperature and configure faults/warnings.

Thermal Resistor Type:

Actual Thermistor Value: Ohm

Fault Level : Ohm  0 means no fault

Warning Level : Ohm  0 means no warning

 Many motors have a thermistor embedded in their windings.
The thermistor is usually connected through the feedback connector.

For all other types refer to the thermistor datasheet for your specific model.

6. SELECT FEEDBACK TYPE

Notes on the resolution setting are explained below.

The screenshot displays the configuration interface for 'Feedback 1 (X10)'. On the left, the 'Device Topology' tree shows the 'Feedback 1' component selected under 'Settings'. A callout box labeled '1. Click on "Feedback 1"' points to this component. The main panel shows the 'Feedback Selection' dropdown menu open, with '40 - Resolver' selected. A callout box labeled '2. Select Feedback Type' points to this dropdown. The dropdown list includes options such as '-1 - Auto Identify', '1 - None', '10 - Incremental Encoder with Halls', '11 - Incremental Encoder without Halls', '12 - Halls Only', '20 - Sine Encoder with Halls', '21 - Sine Encoder without Halls', '30 - Endat 2.1', '31 - Endat 2.2', '32 - BiSS Analog', '33 - Hiperface', '34 - BiSS Mode C Renishaw', '40 - Resolver', '41 - SFD (Smart Feedback Device)', '42 - Tamagawa Serial', '43 - Network Cyclic Feedback', '45 - SFD3 (Smart Feedback Device Gen3)', '46 - Hiperface DSL', and '50 - Reserved (do not use)'. Below the dropdown, the 'Rotary Encoder Resolution' is set to 65,536, 'Phase Lag' is -2.000 deg, 'Nominal Transformation Ratio' is 0.500, and 'Position Feedback Poles' is 2. A 'Goto Wake and Shake' link is visible at the bottom right.

1. Click on "Feedback 1"

2. Select Feedback Type

Feedback 1 (X10)
The primary position feedback fitted to your motor.

Feedback Selection: 40 - Resolver

- 1 - Auto Identify
- 1 - None
- 10 - Incremental Encoder with Halls
- 11 - Incremental Encoder without Halls
- 12 - Halls Only
- 20 - Sine Encoder with Halls
- 21 - Sine Encoder without Halls
- 30 - Endat 2.1
- 31 - Endat 2.2
- 32 - BiSS Analog
- 33 - Hiperface
- 34 - BiSS Mode C Renishaw
- 40 - Resolver
- 41 - SFD (Smart Feedback Device)
- 42 - Tamagawa Serial
- 43 - Network Cyclic Feedback
- 45 - SFD3 (Smart Feedback Device Gen3)
- 46 - Hiperface DSL
- 50 - Reserved (do not use)

If you rotate the motor shaft you should see the dial move.

Motor Autoset: _____

Position Feedback: _____

Drive Direction: _____

Rotary Encoder Resolution: 65,536

Phase Lag: -2.000 deg

Nominal Transformation Ratio: 0.500

Position Feedback Poles: 2

[Goto Wake and Shake](#)

7. CONFIGURING ENCODER FEEDBACK RESOLUTION

Depending on your feedback selection the Feedback 1 screen will change graphically and also change in regards to feedback 1 related parameters.



For example a Sine Encoder with Halls show the Halls graphically and the configuration requires the sine cycles/revolution be entered that match the specifications of your feedback device.

Feedback 1 (X10)

The primary position feedback fitted to your motor.

Feedback Selection:

If you rotate the motor shaft you should see the dial move.



Motor Autose:

Position Feedback: Counts16Bit

Drive Direction:

Sine Cycles/Revolution:

[Goto Wake and Shake](#)


Compare with a Biss Mode C Renishaw where no halls are shown and there are 2 parameters that must be entered: 1) Rotary Encoder Resolution and Biss Sensor Bits. Please use the KDN articles for wiring conventions and also how to configure the BISS C Renishaw encoder for a rotary application.

Feedback 1 (X10)

The primary position feedback fitted to your motor.

Feedback Selection:

If you rotate the motor shaft you should see the dial move.



Motor Autose:

Position Feedback: Counts16Bit

Drive Direction:

Rotary Encoder Resolution:

Biss Sensor Bits:

[Goto Wake and Shake](#)

8. TEST ENCODER DIRECTION AND RESOLUTION

Note: It is very important the Drive Direction parameter on the Feedback 1 screen is set to 0 until correct commutation is established. Once the motor is running with correct commutation, if the direction of rotation is reverse of what is required in the application then the Drive Direction can be changed at that point to a 1.

The Feedback test available is the movement of the indicator on the motor feedback screen.

The screenshot displays the 'Feedback 1 (X10)' configuration screen. On the left, a 'Device Topology' tree shows a project named 'no_name (Online)*' with a sub-tree for 'Settings' containing 'Communication', 'Power', 'Regen', 'Motor', 'Feedback 1', 'Wake and Shake', 'Feedback 2', 'Foldback', and 'Brake'. The main area is titled 'Feedback 1 (X10)' and contains the following parameters:

- Feedback Selection: -1 - Auto Identify
- Feedback Identified: BiSS
- Motor Autoselect: 1 - On
- Position Feedback: 321,596,239.125 counts (highlighted in green)
- Drive Direction: 0
- Sine Cycles/Revolution: 2,048
- Biss Sensor Bits: 32

A dial indicator is shown with a reading of 305.104°. Red arrows indicate the direction of rotation. A blue link 'Goto Wake and Shake' is located at the bottom right.

The Summary is presented again here for convenience. Please refer back to the wiring section of this application guide for details and diagrams.

Summary:


If feedback counts are opposite of convention

Feedback Type	Feedback Remedy	Motor Remedy	Wake and Shake Required?
Halls Only	This is beyond the scope of this application note; see the support documentation for AKD Halls Only operation.		
Resolver	Swap Sin + and Sin -	Not required	No
Incremental Encoder no halls	Swap A+ and A-	Not required	Yes
Incremental encoder with halls	Swap A+ and A- and Swap Halls U and V	Swap Motor U and W	No
Sine Encoder without Halls	Swap Sin+ and Sin-	Not required	Yes
Sine encoder with Halls	Swap A+ and A- and Swap Halls U and W	Swap Motor U and W	No
EnDat with analog	Feedback Direction cannot be inverted by wiring; motor phasing must change	Swap Motor U and W	No
EnDat digital only	Feedback Direction cannot be inverted by wiring; motor phasing must change	Swap Motor U and W	No
BISS with analog	Feedback Direction cannot be inverted by wiring; motor phasing must change	Swap Motor U and W	No
Renishaw BISS C (digital only)	Feedback Direction cannot be inverted by wiring; motor phasing must change	Swap Motor U and W	No
Hiperface with analog	Feedback Direction cannot be inverted by wiring; motor phasing must change	Swap Motor U and W	No
Hiperface DSL (digital only)	Feedback Direction cannot be inverted by wiring; motor phasing must change	Swap Motor U and W	No


Checking Motor Feedback Resolution

Workbench Units setup will depend on your application and if fieldbus communications (i.e. Ethernet IP, Profinet, Canopen, Ethercat, etc.) is used the scaling and setup may be different than what is shown.

In this example it is assumed the KBM(S) motor is direct drive and the desired units are degree, degree/s, and degree/s².

 **Units**
You can select the units used for positions, velocities and accelerations.

Select Type of Mechanics:



Position Unit:

Velocity Unit:

Acceleration Unit:

Custom Position Unit:

Modbus Unit: [Goto Modbus](#)

Position: deg


If possible, move the rotor manually with the drive disabled and monitor the change in Position on the readout of the Units screen above.

If the position display does not match the distance the motor is moved, you may need to revisit the encoder scaling section of this manual or confirm the feedback device scale.

9. IF THE MOTOR HAS HALLS THEN CHECK THE HALLSTATE SEQUENCE WHEN MOVING MOTOR USING THE CONVENTIONS IN THIS APP. NOTE.

Standard Convention (assuming the halls and motor phasing do not need to change from standard)

The hall phasing can be check with the parameter FB1.HALLSTATE. This is a binary value, where “001” is Hall U, “010” is Hall V, and “100” is Hall W.



Hall Sensor Sequence when FeedBack (PL.FB) Is Counting Positive When Using AKD Firmware Version = or > 01-13-10-001. Do not use the parameter FB1.HALLSTATE in the oscilloscope feature to monitor Hall sensor state

Step(CW)	FB1.HALLSTATEW	FB1.HALLSTATEV	FB1.HALLSTATEU
1	0	0	1
2	0	1	1
3	0	1	0
4	1	1	0
5	1	0	0
6	1	0	1
7	0	0	1

Hall Sensor Sequence when FeedBack (PL.FB) Is Counting Positive When Using AKD Firmware Version < 01-13-10-001. Do not use the parameter FB1.HALLSTATE in the oscilloscope feature to monitor Hall sensor state.

Step(CW)	FB1.HALLSTATEW	FB1.HALLSTATEV	FB1.HALLSTATEU
1	0	0	1
2	1	0	1
3	1	0	0
4	1	1	0
5	0	1	0
6	0	1	1
7	0	0	1

10. How To Verify The Motor's Commutation Alignment Angle MOTOR.PHASE for feedback that requires W&S on power up.

Set the Wake & Shake Current WS.IMAX equal to continuous of your KBM(S) motor in the Terminal Screen.

The screenshot displays the Kollmorgen WorkBench software interface. On the left, the 'Device Topology' tree is expanded to show the 'Terminal' option. A callout box labeled '1: Click on "Terminal"' has an arrow pointing to the 'Terminal' icon in the tree. On the right, the 'Terminal' window is active, showing a command line interface. The text '-->WS.IMAX' is entered, followed by '1.000 [Arms]' and a new prompt '-->'. A callout box labeled '2: Enter a value for WS.IMAX' has an arrow pointing to the '1.000' value.

Kollmorgen WorkBench

File Edit View Tools Help

Enable Stop 3 - Analog 1 - Velocity Mode Disable & Clear Faults Save To Device Disconnect Panic

Device Topology

- Start Page
 - no-name (Online)
 - Settings
 - Communication
 - Power
 - Regen
 - Motor
 - Feedback 1
 - Feedback 2
 - Foldback
 - Brake
 - Units
 - Modulo
 - Limits
 - Current Loop
 - Velocity Loop
 - Encoder Emulation (X9 C)
 - Analog Input
 - Analog Output
 - Digital I/O
 - Programmable Limit Swit
 - Enable/Disable
 - Position Capture
 - Performance Servo Tuner
 - Slider Tuning
 - Program
 - Faults and Warnings
 - Scope
 - Parameter Load/Save
 - Parameters
 - Terminal

Start the Wake and Shake Routine

Kollmorgen WorkBench

File Edit View Tools Help

Enable Stop 3 - Analog 1 - Velocity Mode Disable & Clear Faults Save To Device Disconnect Panic

Device Topology

- Start Page
- no-name (Online)
- Settings
 - Communication
 - Power
 - Regen
 - Motor
 - Feedback 1
 - Wake and Shake
 - Feedback 2
 - Foldback
 - Brake
 - Units
 - Modulo
 - Limits
 - Current Loop
 - Velocity Loop
 - Encoder Emulation (X9 C)
 - Analog Input
 - Analog Output
 - Digital I/O
 - Programmable Limit Swit
 - Enable/Disable
 - Position Capture
 - Performance Servo Tuner
 - Slider Tuning
 - Program
 - Faults and Warnings
 - Scope
 - Parameter Load/Save
 - Parameters
 - Terminal

Wake and Shake

Wake and Shake will determine alignment offset between feedback and the electrical phases of the motor.

Mode
Sets the method used for Wake and Shake
2 - Auto Wake and Shake

Commutation Check
Mode: 1 - Active

Arm
Arm Idle
Motor Phase: 4 deg

- 1: Click on the the "Wake and Shake"
- 2: Select 2 - Auto Wake and Shake
- 3: Click the Arm Button
- 4: Click on the Enable

Start the Wake and Shake routine to find the MOTOR.PHASE offset value. When commissioning the linear motor system, the Wake and shake routine should be performed in several different positions of the motor's travel. The MOTOR.PHASE values should be no more than 5 degrees different in the different positions.

Verify the Motor is Setup Correctly by Jogging it in Both Directions

The screenshot shows the Kollmorgen WorkBench software interface. The main window is titled 'Service Motion' and contains the following configuration options:

- Service Motion Mode:** Pulse, Reversing, Continuous
- Group:** Group 1
- Velocity 1:** 32,000 mm/s
- Time 1:** 2,000 ms
- Acceleration:** 3,584,000,000.000 Counts/s²
- Deceleration:** 715,839,984,631.808 Counts/s²
- Position Feedback:** 0 mm
- Velocity Feedback:** -0.757 mm/s

Annotations on the screenshot indicate the following steps:

- 1: Select Service Mode
- 2: Select Velocity Mode
- 3: Select Service Motion
- 4: Select Pulse
- 5: Input a slow Motor Velocity
- 6: Make sure the move time does not allow the motor to hit the hard stops
- 7: Select Start
- 7: Enable the AKD



Make sure the AKD drive's peak current is limited before doing this exercise. A motor runaway can result in damage to the system equipment or possible bodily injury.

The AKD to KBM(S) motor initial commissioning is now complete!

11. How To Verify The Motor's Commutation Alignment Angle MOTOR.PHASE for feedback that do not require W&S on power up.

For motors with feedback devices that do not require Wake and Shake on powerup, a commutation alignment test must be performed so the correct MOTOR.PHASE is set in the AKD drive.



Make sure the AKD drive's peak current is limited before doing this exercise. A motor runaway can result in damage to the system equipment or possible bodily injury.

The AKD to KBM(S) motor initial commissioning is now complete!

Commutation alignment check


From the Feedback 1->Wake and Shake screen:

- Set Mode to 1-Commutation Alignment Check.
- Set Commutation Check Mode to 1-Active
- Set the Maximum allowed current to the continuous rating of the motor. Keep in mind additional loading can affect the accuracy of the test. The motor should be free to turn and not connected to anything while you are attempting to setup and verify proper commutation.
- Before enabling the drive make sure you take precautions in the event the motor runs away. When ready click the "Arm" button and then enable the drive. The motor will move and the Motor Phase as a read-only will appear under the Arm button as shown in the screenshot below. The status will show "Running" and if successful when done will indicate "Successful and the Motor Phase angle will be reported in degrees.

It is generally a good idea to run the commutation alignment check several times to see the value is approximately the same angle.

The screenshot displays the 'Wake and Shake' configuration window. On the left is a 'Device Topology' tree with 'Feedback 1' selected. The main window has a title bar 'Wake and Shake' and a subtitle 'Wake and Shake will determine alignment offset between feedback and the electrical phases of the motor.' Below this, there are three sections: 'Mode' with a dropdown set to '1 - Commutation Alignment' and an 'Arm' button; 'Commutation Check' with a dropdown set to '1 - Active'; and 'Settings' with two input fields: 'Maximum allowed current' (1.390 Arms) and 'Settling Time' (1,000 ms). On the right side, there is a 'Motor Phase' field showing '359 deg' and a 'Successful' status indicator.

At the top of the Workbench screen, click on “Save to Device”.



Verify the Motor is Setup Correctly by Jogging it in Both Directions

1: Select Service Mode

2: Select Velocity Mode

3: Select Service Motion

4: Select Pulse

5: Input a slow Motor Velocity

6: Make sure the move time does not allow the motor to hit the hard stops

7: Select Start

7: Enable the AKD



Make sure the AKD drive's peak current is limited before doing this exercise. A motor runaway can result in damage to the system equipment or possible bodily injury.

The AKD to KBM(S) motor initial commissioning is now complete!