

Kollmorgen Automation Suite

KAS Reference Manual - Motion Library



Document Edition: E, May 2014
Valid for KAS Software Revision 2.8
Part Number: 959716

Keep all manuals as a product component during the life span of the product.
Pass all manuals to future users / owners of the product.

Trademarks and Copyrights

Copyrights

Copyright © 2009-14 Kollmorgen™

Information in this document is subject to change without notice. The software package described in this document is furnished under a license agreement or non-disclosure agreement. The software may be used or copied only in accordance with the terms of those agreements.

This document is the intellectual property of Kollmorgen™ and contains proprietary and confidential information. The reproduction, modification, translation or disclosure to third parties of this document (in whole or in part) is strictly prohibited without the prior written permission of Kollmorgen™.

Trademarks

KAS and AKD are registered trademarks of Kollmorgen™.

SERVOSTAR is a registered trademark of Kollmorgen™.

Kollmorgen™ is part of the Danaher Motion company.

Windows® is a registered trademark of Microsoft Corporation

EnDat is a registered trademark of Dr. Johannes Heidenhain GmbH.

EtherCAT® is registered trademark of Ethercat Technology Group.

PLCopen® is an independent association providing efficiency in industrial automation.

INTime® is a registered trademark of TenAsys® Corporation.

Codemeter is a registered trademark of WIBU-Systems AG.

All product and company names are trademarks™ or registered® trademarks of their respective holders. Use of them does not imply any affiliation with or endorsement by them.

Kollmorgen Automation Suite is based on the work of:

- AjaxFileUpload, software (distributed under the MPL License).
- Apache log4net library for output logging (distributed under the Apache License).
- bsdtar and libarchive2, a utility and library to create and read several different archive formats (distributed under the terms of the BSD License).
- bzip2.dll, a data compression library (distributed under the terms of the BSD License).
- Curl software library
- DockPanel Suite, a docking library for .Net Windows Forms (distributed under the MIT License).
- FileHelpers library to import/export data from fixed length or delimited files.
- [GNU gzip¹](http://www.gnu.org/licenses/gpl-2.0.html) (www.gnu.org) is used by the PDMM (distributed under the terms of the GNU General Public License <http://www.gnu.org/licenses/gpl-2.0.html>).
- [GNU Tar²](http://www.gnu.org/licenses/gpl-2.0.html) (www.gnu.org) is used by the PDMM (distributed under the terms of the GNU General Public License <http://www.gnu.org/licenses/gpl-2.0.html>).

¹Copyright (C) 2007 Free Software Foundation, Inc. Copyright (C) 1993 Jean-loup Gailly. This is free software. You may redistribute copies of it under the terms of the GNU General Public License <<http://www.gnu.org/licenses/gpl.html>>. There is NO WARRANTY, to the extent permitted by law. Written by Jean-loup Gailly.

²Copyright (C) 2007 Free Software Foundation, Inc. License GPLv2+: GNU GPL version 2 or later <<http://gnu.org/licenses/gpl.html>> This is free software: you are free to change and redistribute it. There is NO WARRANTY, to the extent permitted by law. Written by John Gilmore and Jay Fenlon.

- jQuery.Cookies, a Javascript library for accessing and manipulating HTTP cookies in the web browser (distributed under the MIT License).
- jquery-csv, a library for parsing CSV files in javascript (distributed under the MIT license <http://www.opensource.org/licenses/mit-license.php>).
- jQuery File Tree, a file browser plugin (distributed under the MIT License).
- jQueryRotate, a plugin which rotates images (img html objects) by a given angle on web pages (distributed under the MIT License, <http://opensource.org/licenses/mit-license.php>).
- JsonCpp software (distributed under the MIT License –see terms see <http://json-cpp.sourceforge.net/LICENSE> for terms).
- LZMA SDK (<http://www.7-zip.org/sdk.html>), used to compress crash dump information (available as public domain).
- Mongoose v3.7, an embedded web server library (distributed under the MIT License).
- MVVM Light Toolkit components for Model – View –ViewModel patterns with Windows Presentation Foundation (distributed under the MIT License).
- pugixml, an XML and XPath parsing library (distributed under the MIT License).
- Qwt project (distributed under the terms of the GNU Lesser General Public License).
- U-Boot, a universal boot loader is used by the AKD-PDMM (distributed under the terms of the GNU General Public License, <http://www.gnu.org/licenses/gpl-2.0.html>). The U-Boot source files, copyright notice, and readme are available on the distribution disk that is included with the AKD-PDMM.
- ZedGraph class library, user control, and web control for .NET (distributed under the LGPL License).
- Zlib software library
- Zlib1.dll, a data compression library (distributed under the terms of the BSD License).

All other product and brand names listed in this document may be trademarks or registered trademarks of their respective owners.

Disclaimer

The information in this document (Version 2.8 published on 5/16/2014) is believed to be accurate and reliable at the time of its release. Notwithstanding the foregoing, Kollmorgen assumes no responsibility for any damage or loss resulting from the use of this help, and expressly disclaims any liability or damages for loss of data, loss of use, and property damage of any kind, direct, incidental or consequential, in regard to or arising out of the performance or form of the materials presented herein or in any software programs that accompany this document.

All timing diagrams, whether produced by Kollmorgen or included by courtesy of the PLCopen organization, are provided with accuracy on a best-effort basis with no warranty, explicit or implied, by Kollmorgen. The user releases Kollmorgen from any liability arising out of the use of these timing diagrams.

This page intentionally left blank.

Table of Contents

Kollmorgen Automation Suite	1
KAS Reference Manual - Motion Library	1
Trademarks and Copyrights	2
Table of Contents	5
1 Motion Library	37
1.1 Motion Library / Pipe Network	38
1.1.1 Motion Library	38
1.1.2 Motion Library - Pipe Network	39
1.1.2.1 MLPipeAct	39
1.1.2.2.1 Description	39
1.1.2.3.2 Arguments	39
1.1.2.4.3.1 Input	39
1.1.2.5.4.2 Output	40
1.1.2.6.5.3 Return Type	40
1.1.2.7.6 Related Functions	40
1.1.2.8.7 Example	40
1.1.2.9.8.1 Structured Text	40
1.1.2.10.9.2 Ladder Diagram	40
1.1.2.11.10.3 Function Block Diagram	40
1.1.2.12 MLPipeAddBlock	40
1.1.2.13.1 Description	40
1.1.2.14.2 Arguments	41
1.1.2.15.3.1 Input	41
1.1.2.16.4.2 Output	41
1.1.2.17.5.3 Return Type	42
1.1.2.18.6 Related Functions	42
1.1.2.19.7 Example	42
1.1.2.20.8.1 Structured Text	42
1.1.2.21.9.2 Ladder Diagram	42
1.1.2.22.10.3 Function Block Diagram	42
1.1.2.23 MLPipeCreate	42
1.1.2.24.1 Description	42
1.1.2.25.2 Arguments	43

1.1.2.26.3.1	Input	43
1.1.2.27.4.2	Output	43
1.1.2.28.5	Related Functions	43
1.1.2.29.6	Example	43
1.1.2.30.7.1	Structured Text	43
1.1.2.31.8.2	Ladder Diagram	43
1.1.2.32.9.3	Function Block Diagram	44
1.1.2.33	MLPipeDeact	44
1.1.2.34.1	Description	44
1.1.2.35.2	Arguments	44
1.1.2.36.3.1	Input	44
1.1.2.37.4.2	Output	45
1.1.2.38.5.3	Return Type	45
1.1.2.39.6	Related Functions	45
1.1.2.40.7	Example	45
1.1.2.41.8.1	Structured Text	45
1.1.2.42.9.2	Ladder Diagram	45
1.1.2.43.10.3	Function Block Diagram	45
1.1.3	Motion Library - Block	45
1.1.3.1	MLBIkCreate	46
1.1.3.2.1	Description	46
1.1.3.3.2	Arguments	46
1.1.3.4.3.1	Input	46
1.1.3.5.4.2	Output	46
1.1.3.6.5	Related Functions	47
1.1.3.7.6	Example	47
1.1.3.8.7.1	Structured Text	47
1.1.3.9.8.2	Ladder Diagram	47
1.1.3.10.9.3	Function Block Diagram	47
1.1.3.11	MLBIkReadOutVal	47
1.1.3.12.1	Description	47
1.1.3.13.2	Arguments	47
1.1.3.14.3.1	Input	47
1.1.3.15.4.2	Output	48

1.1.3.16.5	Related Functions	48
1.1.3.17.6	Example	48
1.1.3.18.7.1	Structured Text	48
1.1.3.19.8.2	Ladder Diagram	48
1.1.3.20.9.3	Function Block Diagram	48
1.1.3.21	MLBIkReadModPos	48
1.1.3.22.1	Description	48
1.1.3.23.2	Arguments	49
1.1.3.24.3.1	Input	49
1.1.3.25.4.2	Output	49
1.1.3.26.5	Related Functions	49
1.1.3.27.6	Example	49
1.1.3.28.7.1	Structured Text	49
1.1.3.29.8.2	Ladder Diagram	50
1.1.3.30.9.3	Function Block Diagram	50
1.1.3.31	MLBIkIsReady	50
1.1.3.32.1	Description	50
1.1.3.33.2	Arguments	50
1.1.3.34.3.1	Input	50
1.1.3.35.4.2	Output	50
1.1.3.36.5.3	Return Type	50
1.1.3.37.6	Related Functions	50
1.1.3.38.7	Example	51
1.1.3.39.8.1	Structured Text	51
1.1.3.40.9.2	Ladder Diagram	51
1.1.3.41.10.3	Function Block Diagram	51
1.1.3.42	MLBIkWriteModPos	51
1.1.3.43.1	Description	51
1.1.3.44.2	Arguments	51
1.1.3.45.3.1	Input	51
1.1.3.46.4.2	Output	52
1.1.3.47.5.3	Return Type	52
1.1.3.48.6	Related Functions	52
1.1.3.49.7	Example	52

1.1.3.50.8.1	Structured Text	52
1.1.3.51.9.2	Ladder Diagram	52
1.1.3.52.10.3	Function Block Diagram	53
1.1.4	Motion Library - Adder	53
1.1.4.1	MLAddInit	53
1.1.4.2.1	Description	53
1.1.4.3.2	Arguments	54
1.1.4.4.3.1	Input	54
1.1.4.5.4.2	Output	55
1.1.4.6.5.3	Return Type	55
1.1.4.7.6	Related Functions	55
1.1.4.8.7	Example	55
1.1.4.9.8.1	Structured Text	55
1.1.4.10.9.2	Ladder Diagram	56
1.1.4.11.10.3	Function Block Diagram	56
1.1.4.12	MLAddReadOff1	56
1.1.4.13.1	Description	56
1.1.4.14.2	Arguments	57
1.1.4.15.3.1	Input	57
1.1.4.16.4.2	Output	57
1.1.4.17.5	Related Functions	57
1.1.4.18.6	Example	57
1.1.4.19.7.1	Structured Text	57
1.1.4.20.8.2	Ladder Diagram	57
1.1.4.21.9.3	Function Block Diagram	57
1.1.4.22	MLAddReadOff2	58
1.1.4.23.1	Description	58
1.1.4.24.2	Arguments	58
1.1.4.25.3.1	Input	58
1.1.4.26.4.2	Output	58
1.1.4.27.5	Related Functions	58
1.1.4.28.6	Example	59
1.1.4.29.7.1	Structured Text	59
1.1.4.30.8.2	Ladder Diagram	59

1.1.4.31.9.3	Function Block Diagram	59
1.1.4.32	MLAddReadRatio1	59
1.1.4.33.1	Description	59
1.1.4.34.2	Arguments	59
1.1.4.35.3.1	Input	59
1.1.4.36.4.2	Output	60
1.1.4.37.5	Related Functions	60
1.1.4.38.6	Example	60
1.1.4.39.7.1	Structured Text	60
1.1.4.40.8.2	Ladder Diagram	60
1.1.4.41.9.3	Function Block Diagram	60
1.1.4.42	MLAddReadRatio2	60
1.1.4.43.1	Description	60
1.1.4.44.2	Arguments	61
1.1.4.45.3.1	Input	61
1.1.4.46.4.2	Output	61
1.1.4.47.5	Related Functions	61
1.1.4.48.6	Example	61
1.1.4.49.7.1	Structured Text	61
1.1.4.50.8.2	Ladder Diagram	62
1.1.4.51.9.3	Function Block Diagram	62
1.1.4.52	MLAddWriteInput	62
1.1.4.53.1	Description	62
1.1.4.54.2	Arguments	62
1.1.4.55.3.1	Input	62
1.1.4.56.4.2	Output	63
1.1.4.57.5.3	Return Type	63
1.1.4.58.6	Related Functions	63
1.1.4.59.7	Example	63
1.1.4.60.8.1	Structured Text	63
1.1.4.61.9.2	Ladder Diagram	64
1.1.4.62.10.3	Function Block Diagram	64
1.1.4.63	MLAddWriteOff1	64
1.1.4.64.1	Description	64

1.1.4.65.2 Arguments	64
1.1.4.66.3.1 Input	64
1.1.4.67.4.2 Output	65
1.1.4.68.5.3 Return Type	65
1.1.4.69.6 Related Functions	65
1.1.4.70.7 Example	65
1.1.4.71.8.1 Structured Text	65
1.1.4.72.9.2 Ladder Diagram	65
1.1.4.73.10.3 Function Block Diagram	66
1.1.4.74 MLAddWriteOff2	66
1.1.4.75.1 Description	66
1.1.4.76.2 Arguments	66
1.1.4.77.3.1 Input	66
1.1.4.78.4.2 Output	66
1.1.4.79.5.3 Return Type	67
1.1.4.80.6 Related Functions	67
1.1.4.81.7 Example	67
1.1.4.82.8.1 Structured Text	67
1.1.4.83.9.2 Ladder Diagram	67
1.1.4.84.10.3 Function Block Diagram	67
1.1.4.85 MLAddWriteRat1	67
1.1.4.86.1 Description	67
1.1.4.87.2 Arguments	68
1.1.4.88.3.1 Input	68
1.1.4.89.4.2 Output	68
1.1.4.90.5.3 Return Type	68
1.1.4.91.6 Related Functions	68
1.1.4.92.7 Example	69
1.1.4.93.8.1 Structured Text	69
1.1.4.94.9.2 Ladder Diagram	69
1.1.4.95.10.3 Function Block Diagram	69
1.1.4.96 MLAddWriteRat2	69
1.1.4.97.1 Description	69
1.1.4.98.2 Arguments	70

1.1.4.99.3.1	Input	70
1.1.4.100.4.2	Output	70
1.1.4.101.5.3	Return Type	70
1.1.4.102.6	Related Functions	70
1.1.4.103.7	Example	70
1.1.4.104.8.1	Structured Text	70
1.1.4.105.9.2	Ladder Diagram	71
1.1.4.106.10.3	Function Block Diagram	71
1.1.5	Motion Library - Axis	71
1.1.6	Motion Library - Cam Profile	73
1.1.7	Motion Library - Comparator	74
1.1.7.1	MLCompCheck	74
1.1.7.2.1	Description	74
1.1.7.3.2	Arguments	75
1.1.7.4.3.1	Input	75
1.1.7.5.4.2	Output	75
1.1.7.6.5.3	Return Type	75
1.1.7.7.6	Related Functions	75
1.1.7.8.7	Example	76
1.1.7.9.8.1	Structured Text	76
1.1.7.10.9.2	Ladder Diagram	76
1.1.7.11.10.3	Function Block Diagram	76
1.1.7.12	MLComplInit	76
1.1.7.13.1	Description	76
1.1.7.14.2	Arguments	77
1.1.7.15.3.1	Input	77
1.1.7.16.4.2	Output	77
1.1.7.17.5.3	Return Type	77
1.1.7.18.6	Related Functions	77
1.1.7.19.7	Example	78
1.1.7.20.8.1	Structured Text	78
1.1.7.21.9.2	Ladder Diagram	78
1.1.7.22.10.3	Function Block Diagram	78
1.1.7.23	MLCompReadRef	78

1.1.7.24.1	Description	78
1.1.7.25.2	Arguments	78
1.1.7.26.3.1	Input	78
1.1.7.27.4.2	Output	79
1.1.7.28.5	Related Functions	79
1.1.7.29.6	Example	79
1.1.7.30.7.1	Structured Text	79
1.1.7.31.8.2	Ladder Diagram	79
1.1.7.32.9.3	Function Block Diagram	79
1.1.7.33	MLCompReset	79
1.1.7.34.1	Description	79
1.1.7.35.2	Arguments	80
1.1.7.36.3.1	Input	80
1.1.7.37.4.2	Output	80
1.1.7.38.5.3	Return Type	80
1.1.7.39.6	Related Functions	80
1.1.7.40.7	Example	80
1.1.7.41.8.1	Structured Text	80
1.1.7.42.9.2	Ladder Diagram	80
1.1.7.43.10.3	Function Block Diagram	80
1.1.7.44	MLCompWriteRef	81
1.1.7.45.1	Description	81
1.1.7.46.2	Arguments	81
1.1.7.47.3.1	Input	81
1.1.7.48.4.2	Output	82
1.1.7.49.5.3	Return Type	82
1.1.7.50.6	Related Functions	82
1.1.7.51.7	Example	82
1.1.7.52.8.1	Structured Text	82
1.1.7.53.9.2	Ladder Diagram	82
1.1.7.54.10.3	Function Block Diagram	83
1.1.7.55	Usage example of Comparator Functions	83
1.1.8	Motion Library - Convertor	85
1.1.8.1	MLCNVConnect	86

1.1.8.2.1	Description	86
1.1.8.3.2	Arguments	86
1.1.8.4.3.1	Input	86
1.1.8.5.4.2	Output	87
1.1.8.6.5.3	Return Type	87
1.1.8.7.6	Related Functions	87
1.1.8.8.7	Example	87
1.1.8.9.8.1	Structured Text	87
1.1.8.10.9.2	Ladder Diagram	87
1.1.8.11.10.3	Function Block Diagram	87
1.1.8.12	MLCNVConnectEx	88
1.1.8.13.1	Description	88
1.1.8.14.2	Arguments	88
1.1.8.15.3.1	Input	88
1.1.8.16.4.2	Output	90
1.1.8.17.5.3	Return Type	90
1.1.8.18.6	Related Functions	90
1.1.8.19.7	Example	90
1.1.8.20.8.1	Structured Text	90
1.1.8.21.9.2	Ladder Diagram	90
1.1.8.22.10.3	Function Block Diagram	90
1.1.8.23	MLCNVDisconnect	91
1.1.8.24.1	Description	91
1.1.8.25.2	Arguments	91
1.1.8.26.3.1	Input	91
1.1.8.27.4.2	Output	91
1.1.8.28.5.3	Return Type	91
1.1.8.29.6	Related Functions	91
1.1.8.30.7	Example	91
1.1.8.31.8.1	Structured Text	91
1.1.8.32.9.2	Ladder Diagram	92
1.1.8.33.10.3	Function Block Diagram	92
1.1.8.34	MLCNVInit	92
1.1.8.35.1	Description	92

1.1.8.36.2 Arguments	92
1.1.8.37.3.1 Input	92
1.1.8.38.4.2 Output	92
1.1.8.39.5.3 Return Type	93
1.1.8.40.6 Related Functions	93
1.1.8.41.7 Example	93
1.1.8.42.8.1 Structured Text	93
1.1.8.43.9.2 Ladder Diagram	93
1.1.8.44.10.3 Function Block Diagram	93
1.1.9 Motion Library - Delay	93
1.1.9.1 MLDelayInit	93
1.1.9.2.1 Description	93
1.1.9.3.2 Arguments	94
1.1.9.4.3.1 Input	94
1.1.9.5.4.2 Example	94
1.1.9.6.5.3 Structured Text	94
1.1.9.7.6.4 Ladder Diagram	94
1.1.9.8.7.5 Function Block Diagram	94
1.1.10 Motion Library - Derivator	95
1.1.10.1 MLDerInit	95
1.1.10.2.1 Description	95
1.1.10.3.2 Arguments	95
1.1.10.4.3.1 Input	95
1.1.10.5.4.2 Output	96
1.1.10.6.5.3 Return Type	96
1.1.10.7.6 Related Functions	96
1.1.10.8.7 Example	96
1.1.10.9.8.1 Structured Text	96
1.1.10.10.9.2 Ladder Diagram	96
1.1.10.11.10.3 Function Block Diagram	96
1.1.10.12 MLDerReadInModPos	97
1.1.10.13.1 Description	97
1.1.10.14.2 Arguments	97
1.1.10.15.3.1 Input	97

1.1.10.16.4.2	Output	97
1.1.10.17.5	Related Functions	98
1.1.10.18.6	Example	98
1.1.10.19.7.1	Structured Text	98
1.1.10.20.8.2	Ladder Diagram	98
1.1.10.21.9.3	Function Block Diagram	98
1.1.10.22	MLDerWriteInModPos	98
1.1.10.23.1	Description	98
1.1.10.24.2	Arguments	99
1.1.10.25.3.1	Input	99
1.1.10.26.4.2	Output	99
1.1.10.27.5.3	Return Type	99
1.1.10.28.6	Related Functions	99
1.1.10.29.7	Example	100
1.1.10.30.8.1	Structured Text	100
1.1.10.31.9.2	Ladder Diagram	100
1.1.10.32.10.3	Function Block Diagram	100
1.1.11	Motion Library - Gear	100
1.1.11.1	Usage example of Gear Functions	101
1.1.12	Motion Library - Integrator	102
1.1.12.1	MLIntInit	103
1.1.12.2.1	Description	103
1.1.12.3.2	Arguments	103
1.1.12.4.3.1	Input	103
1.1.12.5.4.2	Output	104
1.1.12.6.5.3	Return Type	104
1.1.12.7.6	Related Functions	104
1.1.12.8.7	Example	104
1.1.12.9.8.1	Structured Text	104
1.1.12.10.9.2	Ladder Diagram	104
1.1.12.11.10.3	Function Block Diagram	104
1.1.12.12	MLIntWriteOutVal	105
1.1.12.13.1	Description	105
1.1.12.14.2	Arguments	105

1.1.12.15.3.1	Input	105
1.1.12.16.4.2	Output	105
1.1.12.17.5.3	Return Type	105
1.1.12.18.6	Related Functions	105
1.1.12.19.7	Example	105
1.1.12.20.8.1	Structured Text	105
1.1.12.21.9.2	Ladder Diagram	106
1.1.12.22.10.3	Function Block Diagram	106
1.1.13	Motion Library - Master	106
1.1.13.1	MLMstAbs	107
1.1.13.2.1	Description	107
1.1.13.3.2	Arguments	107
1.1.13.4.3.1	Input	107
1.1.13.5.4.2	Output	108
1.1.13.6.5	Related Functions	108
1.1.13.7.6	Example	109
1.1.13.8.7.1	Structured Text	109
1.1.13.9.8.2	Ladder Diagram	109
1.1.13.10.9.3	Function Block Diagram	109
1.1.13.11	MLMstAdd	109
1.1.13.12.1	Description	109
1.1.13.13.2	Arguments	109
1.1.13.14.3.1	Input	109
1.1.13.15.4.2	Output	110
1.1.13.16.5	Related Functions	110
1.1.13.17.6	Example	110
1.1.13.18.7.1	Structured Text	110
1.1.13.19.8.2	Ladder Diagram	110
1.1.13.20.9.3	Function Block Diagram	110
1.1.13.21	MLMstForcePos	111
1.1.13.22.1	Description	111
1.1.13.23.2	Arguments	111
1.1.13.24.3.1	Input	111
1.1.13.25.4.2	Output	111

1.1.13.26.5	Related Functions	111
1.1.13.27.6	Example	111
1.1.13.28.7.1	Structured Text	111
1.1.13.29.8.2	Ladder Diagram	112
1.1.13.30.9.3	Function Block Diagram	112
1.1.13.31	MLMstInit	112
1.1.13.32.1	Description	112
1.1.13.33.2	Arguments	113
1.1.13.34.3.1	Input	113
1.1.13.35.4.2	Output	115
1.1.13.36.5	Example	115
1.1.13.37.6.1	Structured Text	115
1.1.13.38.7.2	Ladder Diagram	115
1.1.13.39.8.3	Function Block Diagram	116
1.1.13.40	MLMstReadAccel	116
1.1.13.41.1	Description	116
1.1.13.42.2	Arguments	116
1.1.13.43.3.1	Input	116
1.1.13.44.4.2	Output	116
1.1.13.45.5	Related Functions	116
1.1.13.46.6	Example	117
1.1.13.47.7.1	Structured Text	117
1.1.13.48.8.2	Ladder Diagram	117
1.1.13.49.9.3	Function Block Diagram	117
1.1.13.50	MLMstReadDecel	117
1.1.13.51.1	Description	117
1.1.13.52.2	Arguments	117
1.1.13.53.3.1	Input	117
1.1.13.54.4.2	Output	117
1.1.13.55.5	Example	118
1.1.13.56.6.1	Structured Text	118
1.1.13.57.7.2	Ladder Diagram	118
1.1.13.58.8.3	Function Block Diagram	118
1.1.13.59	MLMstReadInitPos	118

1.1.13.60.1	Description	118
1.1.13.61.2	Arguments	118
1.1.13.62.3.1	Input	118
1.1.13.63.4.2	Output	119
1.1.13.64.5	Example	119
1.1.13.65.6.1	Structured Text	119
1.1.13.66.7.2	Ladder Diagram	119
1.1.13.67.8.3	Function Block Diagram	119
1.1.13.68	MLMstReadSpeed	119
1.1.13.69.1	Description	119
1.1.13.70.2	Arguments	119
1.1.13.71.3.1	Input	119
1.1.13.72.4.2	Output	120
1.1.13.73.5	Related Functions	120
1.1.13.74.6	Example	120
1.1.13.75.7.1	Structured Text	120
1.1.13.76.8.2	Ladder Diagram	120
1.1.13.77.9.3	Function Block Diagram	120
1.1.13.78	MLMstRel	120
1.1.13.79.1	Description	120
1.1.13.80.2	Arguments	121
1.1.13.81.3.1	Input	121
1.1.13.82.4.2	Output	121
1.1.13.83.5	Related Functions	121
1.1.13.84.6	Example	121
1.1.13.85.7.1	Structured Text	121
1.1.13.86.8.2	Ladder Diagram	122
1.1.13.87.9.3	Function Block Diagram	122
1.1.13.88	MLMstRun	122
1.1.13.89.1	Description	122
1.1.13.90.2	Arguments	122
1.1.13.91.3.1	Input	122
1.1.13.92.4.2	Output	123
1.1.13.93.5	Related Functions	123

1.1.13.94.6 Example	123
1.1.13.95.7.1 Structured Text	123
1.1.13.96.8.2 Ladder Diagram	123
1.1.13.97.9.3 Function Block Diagram	123
1.1.13.98 MLMstStatus	123
1.1.13.99.1 Description	123
1.1.13.100.2 Arguments	124
1.1.13.101.3.1 Input	124
1.1.13.102.4.2 Output	124
1.1.13.103.5 Example	125
1.1.13.104.6.1 Structured Text	125
1.1.13.105.7.2 Ladder Diagram	125
1.1.13.106.8.3 Function Block Diagram	125
1.1.13.107 MLMstWriteAccel	125
1.1.13.108.1 Description	125
1.1.13.109.2 Arguments	125
1.1.13.110.3.1 Input	125
1.1.13.111.4.2 Output	126
1.1.13.112.5 Related Functions	126
1.1.13.113.6 Example	126
1.1.13.114.7.1 Structured Text	126
1.1.13.115.8.2 Ladder Diagram	126
1.1.13.116.9.3 Function Block Diagram	126
1.1.13.117 MLMstWriteDecel	126
1.1.13.118.1 Description	126
1.1.13.119.2 Arguments	127
1.1.13.120.3.1 Input	127
1.1.13.121.4.2 Output	127
1.1.13.122.5 Related Functions	127
1.1.13.123.6 Example	127
1.1.13.124.7.1 Structured Text	127
1.1.13.125.8.2 Ladder Diagram	128
1.1.13.126.9.3 Function Block Diagram	128
1.1.13.127 MLMstWritelInitPos	128

1.1.13.128.1	Description	128
1.1.13.129.2	Arguments	128
1.1.13.130.3.1	Input	128
1.1.13.131.4.2	Output	129
1.1.13.132.5	Example	129
1.1.13.133.6.1	Structured Text	129
1.1.13.134.7.2	Ladder Diagram	129
1.1.13.135.8.3	Function Block Diagram	129
1.1.13.136	MLMstWriteSpeed	129
1.1.13.137.1	Description	129
1.1.13.138.2	Arguments	129
1.1.13.139.3.1	Input	129
1.1.13.140.4.2	Output	130
1.1.13.141.5	Related Functions	130
1.1.13.142.6	Example	130
1.1.13.143.7.1	Structured Text	130
1.1.13.144.8.2	Ladder Diagram	130
1.1.13.145.9.3	Function Block Diagram	131
1.1.13.146	Usage example of Master Functions	131
1.1.14	Motion Library - Phaser	131
1.1.14.1	Usage example of Phaser Functions	132
1.1.15	Motion Library - PMP	133
1.1.16	Motion Library - Sampler	134
1.1.16.1	MLSmpConnect	134
1.1.16.2.1	Description	134
1.1.16.3.2	Arguments	135
1.1.16.4.3.1	Input	135
1.1.16.5.4.2	Output	135
1.1.16.6.5.3	Return Type	135
1.1.16.7.6	Example	135
1.1.16.8.7.1	Structured Text	135
1.1.16.9.8.2	Ladder Diagram	135
1.1.16.10.9.3	Function Block Diagram	136
1.1.16.11	MLSmpConnectEx	136

1.1.16.12.1	Description	136
1.1.16.13.2	Arguments	136
1.1.16.14.3.1	Input	136
1.1.16.15.4.2	Output	137
1.1.16.16.5.3	Return Type	138
1.1.16.17.6	Example	138
1.1.16.18.7.1	Structured Text	138
1.1.16.19.8.2	Ladder Diagram	138
1.1.16.20.9.3	Function Block Diagram	138
1.1.16.21	MLSmpInit	138
1.1.16.22.1	Description	138
1.1.16.23.2	Arguments	139
1.1.16.24.3.1	Input	139
1.1.16.25.4.2	Output	139
1.1.16.26.5	Example	140
1.1.16.27.6.1	Structured Text	140
1.1.16.28.7.2	Ladder Diagram	140
1.1.16.29.8.3	Function Block Diagram	140
1.1.17	Motion Library - Synchronizer	140
1.1.17.1	MLSyncInit	141
1.1.17.2.1	Description	141
1.1.17.3.2	Arguments	141
1.1.17.4.3.1	Input	141
1.1.17.5.4.2	Output	141
1.1.17.6.5	Related Functions	141
1.1.17.7.6	Example	142
1.1.17.8.7.1	Structured Text	142
1.1.17.9.8.2	Ladder Diagram	142
1.1.17.10.9.3	Function Block Diagram	142
1.1.17.11	MLSyncReadDeltaS	142
1.1.17.12.1	Description	142
1.1.17.13.2	Arguments	143
1.1.17.14.3.1	Input	143
1.1.17.15.4.2	Output	143

1.1.17.16.5	Related Functions	143
1.1.17.17.6	Example	144
1.1.17.18.7.1	Structured Text	144
1.1.17.19.8.2	Ladder Diagram	144
1.1.17.20.9.3	Function Block Diagram	144
1.1.17.21	MLSyncStart	144
1.1.17.22.1	Description	144
1.1.17.23.2	Arguments	144
1.1.17.24.3.1	Input	144
1.1.17.25.4.2	Output	145
1.1.17.26.5	Example	145
1.1.17.27.6.1	Structured Text	145
1.1.17.28.7.2	Ladder Diagram	145
1.1.17.29.8.3	Function Block Diagram	145
1.1.17.30	MLSyncStop	145
1.1.17.31.1	Description	145
1.1.17.32.2	Arguments	146
1.1.17.33.3.1	Input	146
1.1.17.34.4.2	Output	146
1.1.17.35.5	Example	146
1.1.17.36.6.1	Structured Text	146
1.1.17.37.7.2	Ladder Diagram	146
1.1.17.38.8.3	Function Block Diagram	147
1.1.17.39	MLSyncWriteDeltaS	147
1.1.17.40.1	Description	147
1.1.17.41.2	Arguments	148
1.1.17.42.3.1	Input	148
1.1.17.43.4.2	Output	148
1.1.17.44.5	Example	148
1.1.17.45.6.1	Structured Text	148
1.1.17.46.7.2	Ladder Diagram	148
1.1.17.47.8.3	Function Block Diagram	148
1.1.17.48	Usage example of Synchronizer Functions	149
1.1.18	Motion Library - Trigger	149

1.1.18.1	MLTrigClearFlag	150
1.1.18.2.1	Description	150
1.1.18.3.2	Arguments	150
1.1.18.4.3.1	Input	150
1.1.18.5.4.2	Output	150
1.1.18.6.5.3	Return Type	150
1.1.18.7.6	Related Functions	151
1.1.18.8.7	Example	151
1.1.18.9.8.1	Structured Text	151
1.1.18.10.9.2	Ladder Diagram	151
1.1.18.11.10.3	Function Block Diagram	151
1.1.18.12	MLTrigInit	151
1.1.18.13.1	Description	151
1.1.18.14.2	Arguments	152
1.1.18.15.3.1	Input	152
1.1.18.16.4.2	Output	152
1.1.18.17.5.3	Return Type	152
1.1.18.18.6	Related Functions	153
1.1.18.19.7	Example	153
1.1.18.20.8.1	Structured Text	153
1.1.18.21.9.2	Ladder Diagram	153
1.1.18.22.10.3	Function Block Diagram	153
1.1.18.23	MLTrigIsTriggered	154
1.1.18.24.1	Description	154
1.1.18.25.2	Arguments	154
1.1.18.26.3.1	Input	154
1.1.18.27.4.2	Output	154
1.1.18.28.5.3	Return Type	155
1.1.18.29.6	Related Functions	155
1.1.18.30.7	Example	155
1.1.18.31.8.1	Ladder Diagram	155
1.1.18.32.9.2	Function Block Diagram	155
1.1.18.33	MLTrigReadDelay	155
1.1.18.34.1	Description	155

1.1.18.35.2.1	Input	155
1.1.18.36.3.2	Output	156
1.1.18.37.4	Related Functions	156
1.1.18.38	MLTrigReadPos	156
1.1.18.39.1	Description	156
1.1.18.40.2	Arguments	157
1.1.18.41.3.1	Input	157
1.1.18.42.4.2	Output	157
1.1.18.43.5	Related Functions	157
1.1.18.44.6	Previous Function Name	157
1.1.18.45.7	Example	157
1.1.18.46.8.1	Structured Text	157
1.1.18.47.9.2	Ladder Diagram	157
1.1.18.48.10.3	Function Block Diagram	158
1.1.18.49	MLTrigReadTime	158
1.1.18.50.1	Description	158
1.1.18.51.2	Arguments	158
1.1.18.52.3.1	Input	158
1.1.18.53.4.2	Output	159
1.1.18.54.5	Related Functions	159
1.1.18.55.6	Previous Function Name	159
1.1.18.56.7	Example	159
1.1.18.57.8.1	Ladder Diagram	159
1.1.18.58.9.2	Function Block Diagram	159
1.1.18.59	MLTrigSetEdge	159
1.1.18.60.1	Description	159
1.1.18.61.2	Arguments	160
1.1.18.62.3.1	Input	160
1.1.18.63.4.2	Output	160
1.1.18.64.5.3	Return Type	160
1.1.18.65.6	Examples	160
1.1.18.66.7.1	Function Block Diagram	160
1.1.18.67.8.2	Ladder Diagram	160
1.1.18.68.9.3	Structured Text	160

1.1.18.69 MLTrigWriteDelay	161
1.1.18.70.1 Description	161
1.1.18.71.2.1 Input	161
1.1.18.72.3.2 Output	161
1.1.18.73.4.3 Return Type	161
1.1.18.74.5 Related Functions	161
1.1.18.75 Usage example of Trigger Functions	161
1.2 Motion Library / PLCopen	163
1.2.1 Control	165
1.2.1.1 MC_ClearFaults (Function)	165
1.2.1.2.1 Description	165
1.2.1.3.2 Arguments	165
1.2.1.4.3.1 Input	165
1.2.1.5.4.2 Output	165
1.2.1.6.5 Usage	165
1.2.1.7.6 Related Functions	166
1.2.1.8.7 Example	166
1.2.1.9.8.1 Structured Text	166
1.2.1.10.9.2 Ladder Diagram	166
1.2.1.11 MC_CreateAxis	166
1.2.1.12.1 Description	166
1.2.1.13.2 Arguments	166
1.2.1.14.3.1 Input	166
1.2.1.15.4.2 Output	168
1.2.1.16.5 Example	169
1.2.1.17.6.1 Structured Text	169
1.2.1.18.7.2 Ladder Diagram	169
1.2.1.19 MC_EStop	169
1.2.1.20.1 Description	169
1.2.1.21.2 Arguments	169
1.2.1.22.3.1 Input	169
1.2.1.23.4.2 Output	170
1.2.1.24.5 Usage	170
1.2.1.25.6 Related Functions	170

1.2.1.26.7 Example	170
1.2.1.27.8.1 Structured Text	170
1.2.1.28.9.2 Ladder Diagram	170
1.2.1.29 MC_InitAxis (Function)	171
1.2.1.30.1 Description	171
1.2.1.31.2 Arguments	171
1.2.1.32.3.1 Input	171
1.2.1.33.4.2 Output	172
1.2.1.34.5 Example	172
1.2.1.35.6.1 Structured Text	172
1.2.1.36.7.2 Ladder Diagram	173
1.2.1.37 MC_Power	173
1.2.1.38.1 Description	173
1.2.1.39.2 Arguments	174
1.2.1.40.3.1 Input	174
1.2.1.41.4.2 Output	174
1.2.1.42.5 Example	175
1.2.1.43.6.1 Structured Text	175
1.2.1.44.7.2 Ladder Diagram	175
1.2.1.45 MC_ResetError	175
1.2.1.46.1 Description	175
1.2.1.47.2 Arguments	176
1.2.1.48.3.1 Input	176
1.2.1.49.4.2 Output	176
1.2.1.50.5 Example	176
1.2.1.51.6.1 Structured Text	176
1.2.1.52.7.2 Ladder Diagram	177
1.2.1.53 MC_Stop	177
1.2.1.54.1 Description	177
1.2.1.55.2 Time Diagram	177
1.2.1.56.3 Arguments	178
1.2.1.57.4.1 Input	178
1.2.1.58.5.2 Output	179
1.2.1.59.6 Example	179

1.2.1.60.7.1	Structured Text	179
1.2.1.61.8.2	Ladder Diagram	180
1.2.2	I/O	180
1.2.2.1	MC_AbortTrigger (Function Block)	180
1.2.2.2.1	Description	180
1.2.2.3.2	Arguments	180
1.2.2.4.3.1	Input	180
1.2.2.5.4.2	Output	181
1.2.2.6.5	Usage	182
1.2.2.7.6	Related Functions	182
1.2.2.8.7	Example	182
1.2.2.9.8.1	Structured Text	182
1.2.2.10.9.2	Ladder Diagram	182
1.2.2.11	MC_TouchProbe (Function Block)	182
1.2.2.12.1	Description	182
1.2.2.13.2	Arguments	183
1.2.2.14.3.1	Input	183
1.2.2.15.4.2	Output	185
1.2.2.16.5	Usage	186
1.2.2.17.6	Related Functions	186
1.2.2.18.7	Example	186
1.2.2.19.8.1	Structured Text	186
1.2.2.20.9.2	Ladder Diagram	187
1.2.3	Info	187
1.2.3.1	MC_ReadActPos	187
1.2.3.2.1	Description	187
1.2.3.3.2	Arguments	187
1.2.3.4.3.1	Input	187
1.2.3.5.4.2	Output	188
1.2.3.6.5	Example	188
1.2.3.7.6.1	Structured Text	188
1.2.3.8.7.2	Ladder Diagram	188
1.2.3.9	MC_ReadActVel	188
1.2.3.10.1	Description	188

1.2.3.11.2	Arguments	189
1.2.3.12.3.1	Input	189
1.2.3.13.4.2	Output	189
1.2.3.14.5	Example	190
1.2.3.15.6.1	Structured Text	190
1.2.3.16.7.2	Ladder Diagram	190
1.2.3.17	MC_ReadAxisErr	190
1.2.3.18.1	Description	190
1.2.3.19.2	Arguments	190
1.2.3.20.3.1	Input	190
1.2.3.21.4.2	Output	191
1.2.3.22.5	Example	192
1.2.3.23.6.1	Structured Text	192
1.2.3.24.7.2	Ladder Diagram	192
1.2.3.25	MC_ReadBoolPar (Function Block)	192
1.2.3.26.1	Description	192
1.2.3.27.2	Arguments	192
1.2.3.28.3.1	Input	192
1.2.3.29.4.2	Output	193
1.2.3.30.5	Example	193
1.2.3.31.6.1	Structured Text	193
1.2.3.32.7.2	Ladder Diagram	194
1.2.3.33	MC_ReadParam (Function Block)	194
1.2.3.34.1	Description	194
1.2.3.35.2	Arguments	194
1.2.3.36.3.1	Input	194
1.2.3.37.4.2	Output	195
1.2.3.38.5	Example	195
1.2.3.39.6.1	Structured Text	195
1.2.3.40.7.2	Ladder Diagram	196
1.2.3.41	MC_ReadStatus	196
1.2.3.42.1	Description	196
1.2.3.43.2	Arguments	196
1.2.3.44.3.1	Input	196

1.2.3.45.4.2	Output	197
1.2.3.46.5	Example	198
1.2.3.47.6.1	Structured Text	198
1.2.3.48.7.2	Ladder Diagram	198
1.2.3.49	MC_WriteBoolPar (Function Block)	198
1.2.3.50.1	Description	198
1.2.3.51.2	Arguments	199
1.2.3.52.3.1	Input	199
1.2.3.53.4.2	Output	199
1.2.3.54.5	Example	200
1.2.3.55.6.1	Structured Text	200
1.2.3.56.7.2	Ladder Diagram	200
1.2.3.57	MC_WriteParam (Function Block)	200
1.2.3.58.1	Description	200
1.2.3.59.2	Arguments	200
1.2.3.60.3.1	Input	200
1.2.3.61.4.2	Output	201
1.2.3.62.5	Example	201
1.2.3.63.6.1	Structured Text	201
1.2.3.64.7.2	Ladder Diagram	202
1.2.4	PLCopenMotion	202
1.2.4.1	MC_Halt (Function Block)	202
1.2.4.2.1	Description	202
1.2.4.3.2	Time Diagram	202
1.2.4.4.3	Arguments	203
1.2.4.5.4.1	Input	203
1.2.4.6.5.2	Output	204
1.2.4.7.6	Example	205
1.2.4.8.7.1	Structured Text	205
1.2.4.9.8.2	Ladder Diagram	205
1.2.4.10	MC_MoveAbsolute	205
1.2.4.11.1	Description	205
1.2.4.12.2	Time Diagram	206
1.2.4.13.3	Arguments	207

1.2.4.14.4.1	Input	207
1.2.4.15.5.2	Output	210
1.2.4.16.6	Example	211
1.2.4.17.7.1	Structured Text	211
1.2.4.18.8.2	Ladder Diagram	211
1.2.4.19	MC_MoveAdditive (Function Block)	211
1.2.4.20.1	Description	211
1.2.4.21.2	Time Diagram	212
1.2.4.22.3	Arguments	213
1.2.4.23.4.1	Input	213
1.2.4.24.5.2	Output	214
1.2.4.25.6	Example	215
1.2.4.26.7.1	Structured Text	215
1.2.4.27.8.2	Ladder Diagram	215
1.2.4.28	MC_MoveRelative	215
1.2.4.29.1	Description	215
1.2.4.30.2	Time Diagram	216
1.2.4.31.3	Arguments	217
1.2.4.32.4.1	Input	217
1.2.4.33.5.2	Output	219
1.2.4.34.6	Example	219
1.2.4.35.7.1	Structured Text	219
1.2.4.36.8.2	Ladder Diagram	220
1.2.4.37	MC_MoveSuperimp (Function Block)	220
1.2.4.38.1	Description	220
1.2.4.39.2	Time Diagram	220
1.2.4.40.3	Arguments	221
1.2.4.41.4.1	Input	221
1.2.4.42.5.2	Output	222
1.2.4.43.6	Example	223
1.2.4.44.7.1	Structured Text	223
1.2.4.45.8.2	Ladder Diagram	223
1.2.4.46	MC_MoveVelocity (Function Block)	223
1.2.4.47.1	Description	224

1.2.4.48.2 Time Diagram	224
1.2.4.49.3 Arguments	225
1.2.4.50.4.1 Input	225
1.2.4.51.5.2 Output	226
1.2.4.52.6 Example	227
1.2.4.53.7.1 Structured Text	227
1.2.4.54.8.2 Ladder Diagram	227
1.2.4.55 MC_SetOverride (Function Block)	227
1.2.4.56.1 Description	227
1.2.4.57.2 Arguments	228
1.2.4.58.3.1 Input	228
1.2.4.59.4.2 Output	228
1.2.4.60.5 Example	228
1.2.4.61.6.1 Structured Text	228
1.2.4.62.7.2 Ladder Diagram	229
1.2.5 Profile	229
1.2.5.1 MC_CamIn	229
1.2.5.2.1 Description	229
1.2.5.3.2 Arguments	229
1.2.5.4.3.1 Input	229
1.2.5.5.4.2 Output	231
1.2.5.6.5 Usage	232
1.2.5.7.6 Related Functions	232
1.2.5.8.7 Examples	232
1.2.5.9.8.1 Structured Text	232
1.2.5.10.9.2 Ladder Diagram	233
1.2.5.11.10.3 Example 1	233
1.2.5.12.11.4 Example 2	234
1.2.5.13.12.5 Example 3	235
1.2.5.14 MC_CamOut	236
1.2.5.15.1 Description	236
1.2.5.16.2 Arguments	237
1.2.5.17.3.1 Input	237
1.2.5.18.4.2 Output	238

1.2.5.19.5	Usage	239
1.2.5.20.6	Related Functions	239
1.2.5.21.7	Example	239
1.2.5.22.8.1	Structured Text	239
1.2.5.23.9.2	Ladder Diagram	239
1.2.5.24	MC_CamTblSelect	239
1.2.5.25.1	Description	239
1.2.5.26.2	Arguments	239
1.2.5.27.3.1	Input	239
1.2.5.28.4.2	Output	240
1.2.5.29.5	Usage	241
1.2.5.30.6	Related Functions	241
1.2.5.31.7	Example	242
1.2.5.32.8.1	Structured Text	242
1.2.5.33.9.2	Ladder Diagram	242
1.2.5.34	MC_GearIn	242
1.2.5.35.1	Description	242
1.2.5.36.2	Time Diagram	243
1.2.5.37.3	Arguments	244
1.2.5.38.4.1	Input	244
1.2.5.39.5.2	Output	246
1.2.5.40.6	Example	246
1.2.5.41.7.1	Structured Text	246
1.2.5.42.8.2	Ladder Diagram	247
1.2.5.43	MC_GearInPos	247
1.2.5.44.1	Description	247
1.2.5.45.2	Time Diagram	248
1.2.5.46.3	Arguments	249
1.2.5.47.4.1	Input	249
1.2.5.48.5.2	Output	250
1.2.5.49.6	Example	251
1.2.5.50.7.1	Structured Text	251
1.2.5.51.8.2	Ladder Diagram	252
1.2.5.52	MC_GearOut	252

1.2.5.53.1	Description	252
1.2.5.54.2	Arguments	253
1.2.5.55.3.1	Input	253
1.2.5.56.4.2	Output	254
1.2.5.57.5	Example	254
1.2.5.58.6.1	Structured Text	254
1.2.5.59.7.2	Ladder Diagram	255
1.2.5.60	MC_Phasing	255
1.2.5.61.1	Description	255
1.2.5.62.2	Arguments	255
1.2.5.63.3.1	Input	255
1.2.5.64.4.2	Output	257
1.2.5.65.5	Example	257
1.2.5.66.6.1	Structured Text	257
1.2.5.67.7.2	Ladder Diagram	258
1.2.5.68	MC_SyncSlaves	258
1.2.5.69.1	Description	258
1.2.5.70.2	Arguments	258
1.2.5.71.3.1	Input	258
1.2.5.72.4.2	Output	259
1.2.5.73.5	Usage	259
1.2.5.74.6	Related Functions	260
1.2.5.75.7	Example	260
1.2.5.76.8.1	Structured Text	260
1.2.5.77.9.2	Ladder Diagram	260
1.2.6	Reference	260
1.2.6.1	MC_Reference (Function Block)	260
1.2.6.2.1	Description	260
1.2.6.3.2	Arguments	261
1.2.6.4.3.1	Input	261
1.2.6.5.4.2	Output	263
1.2.6.6.5	Usage	264
1.2.6.7.6	Related Functions	265
1.2.6.8.7	Example	265

1.2.6.9.8.1	Structured Text	265
1.2.6.10.9.2	Ladder Diagram	265
1.2.6.11	MC_SetPosition (Function)	265
1.2.6.12.1	Description	265
2	Fieldbus Library	267
2.1	EtherCAT Library	268
2.1.1	EtherCAT Library - Drive	270
2.1.1.1.1	Execution Time	270
2.1.1.2.2.1	Reason	270
2.1.1.3.3.2	Result	270
2.1.1.4.4.3	Solution	270
2.1.1.5	DriveParamRead (Function Block)	270
2.1.1.6.1	Description	270
2.1.1.7.2	Arguments	272
2.1.1.8.3.1	Input	272
2.1.1.9.4.2	Output	273
2.1.1.10.5	Usage	275
2.1.1.11.6	Related Functions	275
2.1.1.12.7	Example	275
2.1.1.13.8.1	Structured Text	275
2.1.1.14	DriveParamWrite (Function Block)	275
2.1.1.15.1	Description	275
2.1.1.16.2	Arguments	276
2.1.1.17.3.1	Input	276
2.1.1.18.4.2	Output	277
2.1.1.19.5	Usage	278
2.1.1.20.6	Related Functions	278
2.1.1.21.7	Example	278
2.1.1.22.8.1	Structured Text	278
2.1.2	EtherCAT Library - SDO	278
2.1.2.1	ECATReadSdo (Function Block)	279
2.1.2.2.1	Description	279
2.1.2.3.2.1	State Diagram	280
2.1.2.4.3	Arguments	281


2.1.2.5.4.1	Input	281
2.1.2.6.5.2	Output	282
2.1.2.7.6	Related Functions	283
2.1.2.8.7	Example	283
2.1.2.9.8.1	Structured Text	283
2.1.2.10	ECATWriteSdo (Function Block)	283
2.1.2.11.1	Description	283
2.1.2.12.2.1	State Diagram	284
2.1.2.13.3	Arguments	285
2.1.2.14.4.1	Input	285
2.1.2.15.5.2	Output	286
2.1.2.16.6	Related Functions	288
2.1.2.17.7	Example	288
2.1.2.18.8.1	Structured Text	288
2.1.2.19.9.2	Ladder Diagram	288
2.1.3	EtherCAT Library - Debug	288
2.1.3.1	ECATReadData (Function)	288
2.1.3.2.1	Description	288
2.1.3.3.2	Arguments	289
2.1.3.4.3.1	Input	289
2.1.3.5.4.2	Output	289
2.1.3.6.5	Related Functions	289
2.1.3.7.6	Example	289
2.1.3.8.7.1	Structured Text	289
2.1.3.9	ECATWriteData (Function)	289
2.1.3.10.1	Description	290
2.1.3.11.2	Arguments	290
2.1.3.12.3.1	Input	290
2.1.3.13.4.2	Output	290
2.1.3.14.5	Related Functions	290
2.1.3.15	ECATGetObjVal (Function)	290
2.1.4	EtherCAT Library - Status	291
2.1.4.1	ECATGetStatus (Function)	291
2.1.4.2.1	Description	291

2.1.4.3.2	Arguments	291
2.1.4.4.3.1	Input	291
2.1.4.5.4.2	Output	291
2.1.4.6.5	Related Functions	291
2.1.4.7.6	Example	292
2.1.4.8.7.1	Structured Text	292
2.1.4.9	ECATSetControl (Function)	292
2.1.4.10.1	Description	292
2.1.4.11.2	Arguments	292
2.1.4.12.3.1	Input	292
2.1.4.13.4.2	Output	293
2.1.4.14.5	Related Functions	293
3	System Library	295
3.1	PrintMessage (Function)	296
3.1.1	Description	296
3.1.1.1	About the Source	296
3.1.1.2	About the Level	296
3.1.2	Arguments	296
3.1.2.1	Input	296
3.1.2.2	Output	297
3.1.3	Usage	297
3.1.4	Example	297
3.1.4.1	Structured Text	297
3.1.4.2	Function Block Diagram	298
Index	299

1 Motion Library

1.1 Motion Library / Pipe Network	38
1.2 Motion Library / PLCopen	163

This chapter covers the Motion Library (for **Pipe Network** and **PLCopen**) in the function blocks tab of the Library toolbox.



KAS function library contains ML function blocks that are used to integrate motion in a PLC program. ML function blocks can be used in 4 of the IEC 61131-3 languages: ST, FBD, FFLD and IL.

Regarding SFCSFC programs, ML function blocks (like any other function blocks from the library) are used as part of a stepstep or transitiontransition which are defined with ST, FBD, FFLD or IL languages.

1.1 Motion Library / Pipe Network

The KAS IDE function library contains ML function blocks that are used to integrate motion from a Pipe Network in a PLC program. ML Function blocks are of the following types:

Function	Description
Motion	Prepare the physical motion part: init, reset, start, stop
Pipe Network	Manage the Pipe Network: create/activate
Block	Manage the blocks: create/activate
Pipe Block	Manage each specific Pipe Block: read/write parameters...

Table 1-1: List of Pipe Network FB

IMPORTANT Pipe Network code is generated automatically by the compiler, you should not try to modify it.

Hover the mouse above a Pipe Block in the figure below to display its description at the bottom....



1.1.1 Motion Library

Name	Description	Return type
MLMotionInit	Initializes the motion library. Must be called before any other Motion Library function. Returns TRUE if the function succeeded. BasePeriod is the duration of one motion cycle in microseconds.	BOOL
MLMotionStart	Starts the motion engine, motion bus driver, and initializes EtherCAT network to operational mode. Applicable to PLCoopen and PipesNetwork motion engines. Returns TRUE if the function succeeded.	BOOL
MLMotionStatus	Returns the status of the motion engine 0: Not initialized 1: Running 2: Stopped 3: Error	None
MLMotionStop	Stops the motion bus driver, motion engine, and EtherCAT network operation, resulting in the EtherCAT network transitioning to the Init state. Returns TRUE if the function succeeded.	BOOL
MLMotionSysTime	Prints the system time to the log	BOOL
MLMotionCycleTime		

1.1.2 Motion Library - Pipe Network

Name	Description	Return type
MLPipeAct	Activates a pipe	BOOL
MLPipeAddBlock	Adds a Pipe Block to a pipe	BOOL
MLPipeCreate	Creates a new pipe object	None
MLPipeDeact	Deactivates a pipe	BOOL

1.1.2.1 MLPipeAct

1.1.2.2.1 Description

Activates a pipe. A Pipe contains an Input Pipe Block (Master, PMP, or Sampler), a Converter Output Pipe Block, and any Transformation Pipe Block that can be in between. The figure below shows two Pipes, both with the same Master Input Pipe Block. The first ends with the first converter, and has a Gear Pipe Block to transform the input values from the Master. The second pipe ends with the second converter, and has a CAM Pipe Block to modify the input values from the Master.

Once a Pipe is activated then history on the values in the Pipe's Blocks are saved and updated each program cycle. A Converter object connected to a destination Axis object cannot send updated position values unless its Pipe is activated.




Figure 1-1: MLPipeAct



All Pipes in the Pipe Network can be activated at once with the command PipeNetwork(MLPN_ACTIVATE). This calls automatically generated code with MLPipeAct commands for each Pipe object. Therefore, in a multi-pipe program only one command can be used to activate Pipes instead of writing code for each Pipe separately.

1.1.2.3.2 Arguments

1.1.2.4.3.1 Input

PipeID	Description	ID number of a created Pipe object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—

1.1.2.5.4.2 Output

Default (.Q)	Description	Returns TRUE if the Pipe is activated
	Data type	BOOL
	Unit	n/a

1.1.2.6.5.3 Return Type

BOOL

1.1.2.7.6 Related Functions

MLPipeDeact


MLCNVConnect

PipeNetwork(MLPN_ACTIVATE)

MLPipeAddBlock

1.1.2.8.7 Example1.1.2.9.8.1 Structured Text

```
//Activate a Pipe
MLPipeAct( PipeAXIS1 );
```

1.1.2.10.9.2 Ladder Diagram1.1.2.11.10.3 Function Block Diagram**1.1.2.12 MLPipeAddBlock**1.1.2.13.1 Description

Add a Pipe Block to a pipe. A Pipe contains an Input Pipe Block (Master, PMP, or Sampler), a Converter Output Pipe Block, and any Transformation Pipe Block that can be in between.

The figure below shows two Pipes, both with the same Master Input Pipe Block. If a user were to create the Pipe 1 below without using the Graphical Engine, they would use the following commands once a Pipe and the Pipe Blocks have been created.

```
MLPipeAddBlock( PipeAXIS1, MASTER);
```

```
MLPipeAddBlock( PipeAXIS1, MyGear);
```

```
MLPipeAddBlock( PipeAXIS1, CNV1);
```




Figure 1-2: MLPipeAddBlock

NOTE

All Blocks in the Pipe Network are added to a Pipe automatically. Code with MLPipeAddBlock commands are automatically generated and called in a program with PipeNetwork(MLPN_CREATE_OBJECTS). Therefore, when using the Pipe Network graphical engine to create Pipe Blocks the user does not have to manually add MLPipeAddBlock commands to the Project.

1.1.2.14.2 Arguments

1.1.2.15.3.1 Input

PipeID	Description	ID number of a created Pipe
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
BlockID	Description	ID number of a created Pipe object to add to the selected Pipe
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—

1.1.2.16.4.2 Output

Default (.Q)	Description	Returns TRUE if the Pipe Block is added to the Pipe
---------------------	--------------------	---

Data type	BOOL
Unit	n/a

1.1.2.17.5.3 Return Type

BOOL

1.1.2.18.6 Related Functions

PipeNetwork(MLPN_CREATE_OBJECTS)


MLPipeAct

MLPipeCreate

MLPipeDeact

1.1.2.19.7 Example1.1.2.20.8.1 Structured Text

```
//Add a block to a pipe
MLPipeAddBlock( PipeAXIS1, MyGear );
```

1.1.2.21.9.2 Ladder Diagram1.1.2.22.10.3 Function Block Diagram**1.1.2.23 MLPipeCreate****1.1.2.24.1 Description**

Create a new pipe object. A Pipe contains an Input Pipe Block (Master, PMP, or Sampler), a Converter Output Pipe Block, and any Transformation Pipe Block that can be in between. The figure below shows two Pipes, both with the same Master Input Pipe Block.



Pipes are normally created in the Pipe Network using the graphical

NOTE

engine. Then you do not have to add MLPipeCreate function blocks to their programs. Pipes are created graphically, and the code with MLPipeCreate commands are automatically generated and called in a program with PipeNetwork(MLPN_CREATE_OBJECTS).

1.1.2.25.2 Arguments**1.1.2.26.3.1 Input**

Name	Description
	Desired name for the newly created Pipe
Data type	String
Range	—
Unit	n/a
Default	—

1.1.2.27.4.2 Output

ID	Description
	Assigned ID number of the created Pipe
Data type	DINT
Unit	n/a

Default —

1.1.2.28.5 Related Functions

PipeNetwork(MLPN_CREATE_OBJECTS)


MLPipeAddBlock

MLPipeAct

MLPipeDeact

1.1.2.29.6 Example**1.1.2.30.7.1 Structured Text**

```
//Create a new pipe
PipeAXIS1 := MLPipeCreate( 'PipeAXIS1' );
```

1.1.2.31.8.2 Ladder Diagram

1.1.2.32.9.3 Function Block Diagram**1.1.2.33 MLPipeDeact****1.1.2.34.1 Description**

Deactivates a pipe. A Pipe contains an Input Pipe Block (Master, PMP, or Sampler), a Converter Output Pipe Block, and any Transformation Pipe Block that can be in between. The figure below shows two Pipes, both with the same Master Input Pipe Block. The first ends with the first converter, and has a Gear Pipe Block to transform the input values from the Master. The second pipe ends with the second converter, and has a CAM Pipe Block to modify the input values from the Master.

Once a Pipe is activated then history on the values in the Pipe's Blocks are lost and no longer updated. A Converter object connected to a destination Axis object cannot send updated position values once its Pipe is deactivated.




Figure 1-3: MLPipeDeact

NOTE

All Pipes in the Pipe Network can be deactivated at once with the command PipeNetwork(MLPN_DEACTIVATE). This calls automatically generated code with MLPipeDeact commands for each Pipe object. Therefore, in a multi-pipe program only one command can be used to deactivate Pipes instead of writing code for each Pipe separately.

1.1.2.35.2 Arguments**1.1.2.36.3.1 Input**

PipeID	Description	ID number of a created Pipe object
Data type	DINT	
Range	[-2147483648, 2147483648]	
Unit	n/a	
Default	—	

1.1.2.37.4.2 Output

Default (.Q)	Description	Returns TRUE if the Pipe is deactivated
	Data type	BOOL
	Unit	n/a

1.1.2.38.5.3 Return Type

BOOL

1.1.2.39.6 Related Functions

MLPipeAct


MLCNVDisconnect

PipeNetwork(MLPN_DEACTIVATE)

MLPipeAddBlock

1.1.2.40.7 Example1.1.2.41.8.1 Structured Text

```
//Deactivate a Pipe
MLPipeDeact( PipeAXIS1 );
```

1.1.2.42.9.2 Ladder Diagram1.1.2.43.10.3 Function Block Diagram**1.1.3 Motion Library - Block**

Name	Description	Return type
"MLBlkCreate" (see page 46)	Creates a new Pipe Block object	None
"MLBlkIsReady" (see page 50)	Checks if a Pipe Block currently has a function running	BOOL

Name	Description	Return type
"MLBIkReadModPos" (see page 48)	Gets the value of the period of a block in user units	None
"MLBIkReadOutVal" (see page 47)	Gets the output value of a selected Pipe Block	None
"MLBIkWriteModPos" (see page 51)	Sets the value of the period of a block in user units	BOOL

1.1.3.1 MLBIkCreate

1.1.3.2.1 Description

Creates a new Pipe Block object. Before a Pipe Block is Initialized the block needs to be created and assigned an ID number. MLBIkCreate function block is automatically called if a Block is added to the Pipe Network.

NOTE

Pipe Blocks are normally created in the Pipe Network using the graphical engine. Then you do not have to add MLBIkCreate function blocks to their programs. Blocks are created graphically, and the code with MLBIkCreate commands are automatically generated and called in a program with Pipe Network(MLPN_CREATE_OBJECTS).

TIP

This function must be called or executed before MLMotionStart is called.

1.1.3.3.2 Arguments

1.1.3.4.3.1 Input

Name	Description	Desired name for the newly created Pipe Block
	Data type	String
	Range	—
	Unit	n/a
	Default	—
Type	Description	Type of Pipe Block to create (ex. MASTER, GEAR, PHASER, etc.)
	Data type	String
	Range	—
	Unit	n/a
	Default	—

1.1.3.5.4.2 Output

ID	Description	Assigned ID number of the created Block
	Data type	DINT
	Unit	n/a
	Default	—


1.1.3.6.5 Related Functions

PipeNetwork(MLPN_CREATE_OBJECTS)

MLAxisInit

1.1.3.7.6 Example**1.1.3.8.7.1 Structured Text**

```
//Create a new Pipe Block
MyGear := MLBlkCreate( 'MyGear', 'GEAR' );
```

1.1.3.9.8.2 Ladder Diagram**1.1.3.10.9.3 Function Block Diagram****1.1.3.11 MLBlkReadOutVal****1.1.3.12.1 Description**

Get the output value a selected Pipe Block.

1.1.3.13.2 Arguments**1.1.3.14.3.1 Input**

ID	Description	ID number of a created Pipe Block
Data type	DINT	
Range	[-2147483648, 2147483648]	
Unit	n/a	
Default	—	

1.1.3.15.4.2 Output

Value	Description	Current output value of the selected Pipe Block
	Data type	LREAL
	Unit	n/a
	Default	—



1.1.3.16.5 Related Functions

MLBlkReadModPos


MLBlkCreate

1.1.3.17.6 Example1.1.3.18.7.1 Structured Text

```
//Save the output of a Gear Pipe Block
BlockOutput := MLBlkReadOutVal( PipeNetwork.MyGear );
```

1.1.3.19.8.2 Ladder Diagram1.1.3.20.9.3 Function Block Diagram**1.1.3.21 MLBlkReadModPos**1.1.3.22.1 Description

Get the value of the period of a block in user units. The output value of a block is reset each time it reaches its period value.

**Figure 1-4:** MLBlkReadModPos**1.1.3.23.2 Arguments****1.1.3.24.3.1 Input**

ID	Description	ID number of a created Pipe Block
Data type	DINT	
Range	[-2147483648, 2147483648]	
Unit	n/a	
Default	—	

1.1.3.25.4.2 Output

ModuloPosition	Description	Current Period Value for selected Pipe Block
	Data type	LREAL
	Unit	User unit
	Default	—

1.1.3.26.5 Related Functions


MLBlkWriteModPos

MLBlkCreate

MLBlkReadOutVal

1.1.3.27.6 Example**1.1.3.28.7.1 Structured Text**

```
//Return and save the Period of a Pipe Block
GearPeriod := MLBlkReadModPos( PipeNetwork.MyGear );
```

1.1.3.29.8.2 Ladder Diagram1.1.3.30.9.3 Function Block Diagram**1.1.3.31 MLBIkIsReady****1.1.3.32.1 Description**

Check if a block is ready. Returns FALSE if the selected Pipe Block has a function running. Returns TRUE if no function of a specified Pipe Block is running.

NOTE Same return value as the .Q output of a specific function itself

1.1.3.33.2 Arguments**1.1.3.34.3.1 Input**

ID	Description	ID number of a created Pipe Block
Data type	Description	DINT
Range	Description	[-2147483648, 2147483648]
Unit	Description	n/a
Default	Description	—

1.1.3.35.4.2 Output

Default (.Q)	Description	Returns TRUE if no function of a specified Pipe Block is running.
	Data type	BOOL
	Unit	n/a

1.1.3.36.5.3 Return Type

BOOL


1.1.3.37.6 Related Functions

MLBIkReadOutVal

MLBIkReadModPos

1.1.3.38.7 Example**1.1.3.39.8.1 Structured Text**

```
//Check if a Pipe Block has a function running
IsReady := MLBlkIsReady( PipeNetwork.MASTER );
```

1.1.3.40.9.2 Ladder Diagram**1.1.3.41.10.3 Function Block Diagram****1.1.3.42 MLBlkWriteModPos****1.1.3.43.1 Description**

Set the value of the period of a block in user units. The output value of a block is reset each time it reaches its period value.




Figure 1-5: MLBlkReadModPos

1.1.3.44.2 Arguments**1.1.3.45.3.1 Input**

ID	Description	ID number of a created Pipe Block
Data type	Description	DINT
Range	Description	[-2147483648, 2147483648]

	Unit	n/a
	Default	—
ModuloPosition	Description	Desired new Period Value for selected Pipe Block
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

1.1.3.46.4.2 Output

Default (.Q)	Description	Returns TRUE if the function block executes
	Data type	BOOL
	Unit	n/a

1.1.3.47.5.3 Return Type

BOOL

1.1.3.48.6 Related Functions


MLBlkReadModPos


MLBlkCreate

MLBlkReadOutVal

1.1.3.49.7 Example1.1.3.50.8.1 Structured Text

```
//Set the Period of a Pipe Block to 300
MLBlkWriteModPos( PipeNetwork.MyGear, 300 );
```

1.1.3.51.9.2 Ladder Diagram

1.1.3.52.10.3 Function Block Diagram1.1.4 Motion Library - Adder

Name	Description	Return type
MLAddInit	Initializes an Adder Pipe Block with user-defined settings	BOOL
MLAddReadOff1	Returns the offset value of the first entry of an Adder block	None
MLAddReadOff2	Returns the offset value of the second entry of an Adder block	None
MLAddReadRatio1	Returns the ratio value of the first entry of an Adder block	None
MLAddReadRatio2	Returns the ratio value of the second entry of an Adder block	None
MLAddWriteInput	Sets the source of an input of an adder Pipe Block	BOOL
MLAddWriteOff1	Sets the offset value of the first entry of the Adder block	BOOL
MLAddWriteOff2	Sets the offset value of the second entry of the Adder block	BOOL
MLAddWriteRat1	Sets the ratio value of the first entry of the Adder block	BOOL
MLAddWriteRat2	Sets the ratio value of the second entry of the Adder block	BOOL

1.1.4.1 MLAddInit1.1.4.2.1 Description

Initializes an Adder Pipe Block for use in a PLC Program. Function block is automatically called if an Adder Block is added to the Pipe Network, with user-defined settings entered in the Pipe Blocks Properties screen.

The Pipe Block is assigned ratios and offsets for both inputs. After an Adder block is initialized, the inputs still need to be selected using the MLAddWriteInput function block or graphically using the Pipe Network.

$$\text{Adder Block Output} = \text{Ratio1} * \text{Input1} + \text{Offset1} + \text{Ratio2} * \text{Input2} + \text{Offset2}$$




Figure 1-6: MLAddInit

Note

Adder objects are normally created in the Pipe Network using the graphical engine. Then you do not have to add MLAddInit function blocks to their programs. Parameters are entered directly in pop-up windows, and the code is then automatically added to the current project.

1.1.4.3.2 Arguments**1.1.4.4.3.1 Input**

BlockID	Description	ID number of a created Pipe Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
Ratio1	Description	Sets the Ratio value of the first entry of an Adder object
	Data type	LREAL
	Range	—
	Unit	n/a
	Default	—
Offset1	Description	Sets the Offset value of the first entry of an Adder object
	Data type	LREAL
	Range	—
	Unit	n/a
	Default	—
Ratio2	Description	Sets the Ratio value of the second entry of an Adder object
	Data type	LREAL
	Range	—
	Unit	n/a
	Default	—

Offset2	Description	Sets the Offset value of the second entry of an Adder object
	Data type	LREAL
	Range	—
	Unit	n/a
	Default	—

1.1.4.5.4.2 Output

Default (.Q)	Description	Returns TRUE if the Adder Pipe Block is initialized
	Data type	BOOL
	Unit	n/a

1.1.4.6.5.3 Return Type

BOOL

1.1.4.7.6 Related Functions

MLBlkCreate



MLAddWriteInput

MLAddReadOff1

MLAddReadRatio1

1.1.4.8.7 Example1.1.4.9.8.1 Structured Text

```
//Create and Initiate a Trigger object
MyAdder := MLBlkCreate( 'MyAdder', 'ADDER' );
MLAddInit( MyAdder, 1.0, 0.0, 1.0, 0.0 );
```

1.1.4.10.9.2 Ladder Diagram1.1.4.11.10.3 Function Block Diagram**1.1.4.12 MLAddReadOff1****1.1.4.13.1 Description**

Returns the offset value of the first entry of an Adder block. Can change the offset value with MLAddWriteOff1 function block. Offset1 shifts the value of the first input to the block before its added to the second input.

Adder Block Output = $\text{Ratio1} * \text{Input1} + \text{Offset1} + \text{Ratio2} * \text{Input2} + \text{Offset2}$




Figure 1-7: MLAddReadOff1

1.1.4.14.2 Arguments**1.1.4.15.3.1 Input**

BlockID	Description	ID number of an initiated Adder object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a

Default —**1.1.4.16.4.2 Output**

Offset	Description	Returns the offset value of the first entry of an Adder object
	Data type	LREAL
	Unit	n/a

1.1.4.17.5 Related Functions

MLAddWriteOff1


MLAddReadOff2

MLAddReadRatio1

MLAddWriteRat1

1.1.4.18.6 Example**1.1.4.19.7.1 Structured Text**

```
//Save the offset value of first entry to the Adder block
AdderOffset := MLAddReadOff1( PipeNetwork.MyAdder );
```

1.1.4.20.8.2 Ladder Diagram**1.1.4.21.9.3 Function Block Diagram**

1.1.4.22 MLAddReadOff2

1.1.4.23.1 Description

Returns the offset value of the second entry of an Adder block. Can change the offset value with MLAddWriteOff2 function block. Offset2 shifts the value of the second input to the block before its added to the first input.

Adder Block Output = Ratio1*Input1 + Offset1 + Ratio2*Input2 + Offset2




Figure 1-8: MLAddReadOff2

1.1.4.24.2 Arguments

1.1.4.25.3.1 Input

BlockID	Description	ID number of an initiated Adder object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—

1.1.4.26.4.2 Output

Offset	Description	Returns the offset value of the second entry of an Adder object
	Data type	LREAL
	Unit	n/a

1.1.4.27.5 Related Functions

MLAddWriteOff2


MLAddReadOff1

MLAddReadRatio2

MLAddWriteRat2

1.1.4.28.6 Example**1.1.4.29.7.1 Structured Text**

```
//Save the offset value of second entry to the Adder block
AdderOffset := MLAddReadOff2( PipeNetwork.MyAdder );
```

1.1.4.30.8.2 Ladder Diagram**1.1.4.31.9.3 Function Block Diagram****1.1.4.32 MLAddReadRatio1****1.1.4.33.1 Description**

Returns the ratio value of the first entry of an Adder block. Can change the ratio value with MLAddWriteRat1 function block. Ratio1 amplifies the value of the first input to the block before its added to the second input.

Adder Block Output = Ratio1*Input1 + Offset1 + Ratio2*Input2 + Offset2




Figure 1-9: MLAddReadRatio1

1.1.4.34.2 Arguments**1.1.4.35.3.1 Input**

BlockID	Description	ID number of an initiated Adder object
----------------	--------------------	--

Data type	DINT
Range	[-2147483648, 2147483648]
Unit	n/a
Default	—

1.1.4.36.4.2 Output

Ratio	Description	Returns the Ratio value of the first entry of an Adder object
	Data type	LREAL

1.1.4.37.5 Related Functions

MLAddWriteRat1


MLAddReadRatio2

MLAddReadOff1

MLAddReadOff2

1.1.4.38.6 Example**1.1.4.39.7.1 Structured Text**

```
//Save the ratio value of first entry to the Adder block
AdderRatio := MLAddReadRatio1( PipeNetwork.MyAdder );
```

1.1.4.40.8.2 Ladder Diagram**1.1.4.41.9.3 Function Block Diagram****1.1.4.42 MLAddReadRatio2****1.1.4.43.1 Description**

Returns the ratio value of the second entry of an Adder block. Can change the ratio value with MLAddWriteRat2 function block. Ratio2 amplifies the value of the second input to the block

before its added to the first input.

Adder Block Output = Ratio1*Input1 + Offset1 + Ratio2*Input2 + Offset2




Figure 1-10: MLAddReadRatio2

1.1.4.44.2 Arguments

1.1.4.45.3.1 Input

BlockID	Description	ID number of an initiated Adder object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—

1.1.4.46.4.2 Output

Ratio	Description	Returns the Ratio value of the second entry of an Adder object
	Data type	LREAL
	Unit	n/a

1.1.4.47.5 Related Functions

MLAddWriteRat2

MLAddReadRatio1

MLAddReadOff1


MLAddReadOff2

1.1.4.48.6 Example

1.1.4.49.7.1 Structured Text

```

//Save the ratio value of second entry to the Adder block
AdderRatio := MLAddReadRatio2( PipeNetwork.MyAdder );
  
```

1.1.4.50.8.2 Ladder Diagram1.1.4.51.9.3 Function Block Diagram**1.1.4.52 MLAddWriteInput**1.1.4.53.1 Description

Sets the source of an input of an adder Pipe Block. Function block is automatically called if an Adder Block is connected to other blocks in the Pipe Network.

Adder Block Output = $\text{Ratio1} * \text{Input1} + \text{Offset1} + \text{Ratio2} * \text{Input2} + \text{Offset2}$




Figure 1-11: MLAddWriteInput

NOTE

Adder objects are normally created in the Pipe Network using the graphical engine. Then you do not have to add MLAddWriteInput function blocks to their programs. Blocks are connected with lines in the Pipe Network, and the code is then automatically added to the current project.

1.1.4.54.2 Arguments1.1.4.55.3.1 Input

BlockID	Description	ID number of an initiated Adder object
Data type	DINT	
Range	[-2147483648, 2147483648]	
Unit	n/a	

	Default	—
InputID	Description	Select first or second input to the Adder object
	Data type	DINT
	Range	[1, 2]
	Unit	n/a
	Default	—
InputBlockID	Description	ID number of an initiated Pipe Block which is an input to the Adder object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—

1.1.4.56.4.2 Output
Default (.Q)

Description	Returns TRUE if the input to the Adder object is set
Data type	BOOL
Unit	n/a

1.1.4.57.5.3 Return Type

BOOL

1.1.4.58.6 Related Functions

MLBlkCreate

MLAddInit

MLAddReadOff1



MLAddReadRatio1

1.1.4.59.7 Example**1.1.4.60.8.1 Structured Text**

```

//Set the inputs to an Adder object
MLAddWriteInput( MyAdder, 1, GEAR );
DoneGEAR :=TRUE;
MLAddWriteInput( MyAdder, 2, CAM );
DoneCAM :=TRUE;

```

1.1.4.61.9.2 Ladder Diagram1.1.4.62.10.3 Function Block Diagram**1.1.4.63 MLAddWriteOff1****1.1.4.64.1 Description**

Set the offset value of the first entry of the Adder block. Offset1 shifts the value of the first input to the block before its added to the second input.

Adder Block Output = Ratio1*Input1 + Offset1 + Ratio2*Input2 + Offset2




Figure 1-12: MLAddWriteOff1

① IMPORTANT Changes made to the Offset of an Adder block are executed immediately and can cause an axis position to jump.

1.1.4.65.2 Arguments**1.1.4.66.3.1 Input**

BlockID	Description	ID number of an initiated Adder object
	Data type	DINT

	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
Offset	Description	Desired new value for the Adder Object's Offset1
	Data type	LREAL
	Range	—
	Unit	n/a
	Default	—

1.1.4.67.4.2 Output

Default (.Q)	Description	Returns TRUE if the Offset value for input one is set
	Data type	BOOL
	Unit	n/a

1.1.4.68.5.3 Return Type

BOOL

1.1.4.69.6 Related Functions

MLAddReadOff1

MLAddWriteOff2


MLAddReadRatio1

MLAddWriteRat1


1.1.4.70.7 Example1.1.4.71.8.1 Structured Text

```
//Change the offset value of first entry to the Adder block to
10

MLAddWriteOff1( PipeNetwork.MyAdder, 10 );
```

1.1.4.72.9.2 Ladder Diagram

1.1.4.73.10.3 Function Block Diagram



1.1.4.74 MLAddWriteOff2

1.1.4.75.1 Description

Set the offset value of the second entry of the Adder block. Offset2 shifts the value of the second input to the block before its added to the first input.

Adder Block Output = Ratio1*Input1 + Offset1 + Ratio2*Input2 + Offset2




Figure 1-13: MLAddWriteOff2

(**IMPORTANT)** Changes made to the Offset of an Adder block are executed immediately and can cause an axis position to jump.

1.1.4.76.2 Arguments

1.1.4.77.3.1 Input

BlockID	Description	ID number of an initiated Adder object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
Offset	Description	Desired new value for the Adder Object's Offset2
	Data type	LREAL
	Range	—
	Unit	n/a
	Default	—

1.1.4.78.4.2 Output

Default (.Q)	Description	Returns TRUE if the Offset value for input two is set
	Data type	BOOL
	Unit	n/a

1.1.4.79.5.3 Return Type

BOOL

1.1.4.80.6 Related Functions

MLAddReadOff2

MLAddWriteOff1



MLAddReadRatio2

MLAddWriteRat2

1.1.4.81.7 Example1.1.4.82.8.1 Structured Text

```
//Change the offset value of second entry to the Adder block
to 10

MLAddWriteOff2( PipeNetwork.MyAdder, 10 );
```

1.1.4.83.9.2 Ladder Diagram1.1.4.84.10.3 Function Block Diagram**1.1.4.85 MLAddWriteRat1****1.1.4.86.1 Description**

Set the ratio value of the first entry of the Adder block. Ratio1 amplifies the value of the first input to the block before its added to the second input.

Adder Block Output = Ratio1*Input1 + Offset1 + Ratio2*Input2 + Offset2




Figure 1-14: MLAddWriteRat1

IMPORTANT Changes made to the Ratio of an Adder block are executed immediately and can cause an axis position to jump.

1.1.4.87.2 Arguments

1.1.4.88.3.1 Input

BlockID	Description	ID number of an initiated Adder object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
Ratio	Description	Desired new value for the Adder Object's Ratio1
	Data type	LREAL
	Range	—
	Unit	n/a
	Default	—

1.1.4.89.4.2 Output

Default (.Q)	Description	Returns TRUE if the Ratio value for input one is set
	Data type	BOOL
	Unit	n/a

1.1.4.90.5.3 Return Type

BOOL

1.1.4.91.6 Related Functions

MLAddReadRatio1



MLAddWriteRat2

MLAddReadOff1

MLAddWriteOff1

1.1.4.92.7 Example**1.1.4.93.8.1 Structured Text**

```
//Change the ratio value of first entry to the Adder block to
2
MLAddWriteRat1( PipeNetwork.MyAdder, 2 );
```

1.1.4.94.9.2 Ladder Diagram**1.1.4.95.10.3 Function Block Diagram****1.1.4.96 MLAddWriteRat2****1.1.4.97.1 Description**

Set the ratio value of the second entry of the Adder block. Ratio2 amplifies the value of the second input to the block before its added to the first input.

Adder Block Output = Ratio1*Input1 + Offset1 + Ratio2*Input2 + Offset2




Figure 1-15: MLAddWriteRat2

① IMPORTANT Changes made to the Ratio of an Adder block are executed immediately

!IMPORTANT and can cause an axis position to jump.

1.1.4.98.2 Arguments

1.1.4.99.3.1 Input

BlockID	Description	ID number of an initiated Adder object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
Ratio	Description	Desired new value for the Adder Object's Ratio2
	Data type	LREAL
	Range	—
	Unit	n/a
	Default	—

1.1.4.100.4.2 Output

Default (.Q)	Description	Returns TRUE if the Ratio value for input two is set
	Data type	BOOL
	Unit	n/a

1.1.4.101.5.3 Return Type

BOOL

1.1.4.102.6 Related Functions

MLAddReadRatio2

MLAddWriteRat1

MLAddReadOff2



MLAddWriteOff2

1.1.4.103.7 Example

1.1.4.104.8.1 Structured Text

```
//Change the ratio value of second entry to the Adder block to
2

MLAddWriteRat2 ( PipeNetwork.MyAdder, 2 );
```

1.1.4.105.9.2 Ladder Diagram1.1.4.106.10.3 Function Block Diagram**1.1.5 Motion Library - Axis**

For usage example about Axis Functions, click here...

Function sorted by types:

Power Stage	Motion Control	Inquiry Functions	Position setting
MLAxisPower	MLAxisAbs	MLAxisGenPos	
MLAxisPowerDOff	MLAxisAdd	MLAxisPipePos	MLAxisReAlign
	MLAxisMoveVel	MLAxisCmdPos	
	MLAxisRel	MLAxisReadActPos	
	MLAxisStop	MLAxisFBackPos	
		MLAxisStatus	
		MLAxisReadGenStatus	
		MLAxisGenIsRdy	
		MLAxisTimeStamp	

Functions sorted in alphabetical order:

Name	Description	Return type
MLAxisAbs	Performs a move to an absolute position	BOOL
MLAxisAdd	Performs an additive move relative for a specified distance from the endpoint of the previous move	BOOL
MLAxisAddress	Returns the motion bus address of the axis	DINT
MLAxisAddTq	Sets additive torque	BOOL

Name	Description	Return type
MLAxisCfgFastIn	Initializes the Fast Input capability for the axis	BOOL
MLAxisCmdPos	Returns the reference position of the axis	None
MLAxisCreate	Creates a new axis object	None
MLAxisFBackPos	Returns the feedback position of the axis	None
MLAxisGenEN	Enables or disables the internal TMP generator of the axis	BOOL
MLAxisGenIsEN	Checks if the internal TMP generator of the axis is enabled	BOOL
MLAxisGenIsRdy	Checks if an axis is ready	BOOL
MLAxisGenPos	Returns the generator position of the axis	None
MLAxisGenReadAcc	Gets the acceleration of the internal generator of an axis	None
MLAxisGenReadDec	Gets the deceleration of the internal generator of an axis	None
MLAxisGenReadSpd	Gets the speed of the internal generator of an axis	None
MLAxisGenWriteAcc	Sets the acceleration of the internal generator of an axis	BOOL
MLAxisGenWriteDec	Sets the deceleration of the internal generator of an axis	BOOL
MLAxisGenWriteSpd	Sets the speed of the internal generator of an axis	BOOL
MLAxisInit	Initializes an axis object	BOOL
MLAxisIsCnctd	Checks if a pipe is currently connected to the axis	BOOL
MLAxisIsTriggered	Checks if the axis got a trigger event	BOOL
MLAxisMoveVel	Jogs at the specified speed	BOOL
MLAxisPipePos	Returns the pipe position of the axis	None
MLAxisPower	Powers up the axis. Enables Axis Servo Drive.	BOOL
MLAxisPowerDOff	Returns the adjustment of position done by the last power on to avoid bumps	None
MLAxisRatedTq	Sets rated motor torque	BOOL
MLAxisRead2ndFB	Read secondary feedback	None
MLAxisReadActPos	Returns the actual position of the axis	None
MLAxisReadFBUnit	Gets the feedback units per revolution value of the axis	None
MLAxisReadFEUU	Read following error in user units	None

Name	Description	Return type
MLAxisReadGenStatus	Returns the status of the internal generator of the axis	DINT
MLAxisReadModPos	Get the value period of the axis	None
MLAxisReadTq	Read actual torque	None
MLAxisReadUUnits	Get the user units per revolution value of the axis	None
MLAxisReadVel	Read actual velocity	None
MLAxisReAlignRdy	Checks if an axis is ready. Returns TRUE if the internal realignment axis is ready.	BOOL
MLAxisReAlign	Realigns the actual position with the reference position by moving the axis by the specified delta position	BOOL
MLAxisRel	Performs a relative move for a specified distance from the current position	BOOL
MLAxisResetErrors	Clears errors of the specified axis	BOOL
MLAxisRstFastIn	Resets the Fast Input	BOOL
MLAxisStatus	Returns the status of the axis	DINT
MLAxisStop	Stop with the specified deceleration	None
MLAxisTimeStamp	Returns the timestamp of the triggered axis	DINT
MLAxisWriteModPos	Sets the value period of the axis	BOOL
MLAxisWritePipPos	Forces the pipe position internal value. This function is working only when no pipe is connected.	BOOL
MLAxisWritePos	Sets the logical zero position of an axis	BOOL
MLAxisWriteUUnits	Sets the user units per revolution value of the axis	BOOL

1.1.6 Motion Library - Cam Profile

Name	Description	Return type
MLCamInit	Initializes a cam Pipe Block with user-defined settings	BOOL
MLCamSwitch	Switches profiles of the selected cam object	BOOL
MLPrfReadIOffset	Returns the Input Offset value of a selected cam profile	None
MLPrfReadIScale	Returns the Input Ratio value of a selected cam profile	None
MLPrfReadOOffset	Returns the Output Offset value of a selected cam profile	None

Name	Description	Return type
MLPrfReadOScale	Returns the Output Ratio value of a selected cam profile	None
MLPrfWriteOffset	Sets the Input Offset value of a selected cam profile	BOOL
MLPrfWriteIScale	Sets the Input Ratio value of a selected cam profile	BOOL
MLPrfWriteOOffset	Sets the Output Offset value of a selected cam profile	BOOL
MLPrfWriteOScale	Sets the Output Ratio value of a selected cam profile	BOOL
MLProfileBuild	Builds a cam profile from application data	See Output
MLProfileCreate	Creates a new cam profile object	None
MLProfileInit	Initializes a previously created cam profile object	BOOL
MLProfileRelease	Removes a Profile so the Profile ID may be used by a different or new Profile.	See Output

1.1.7 Motion Library - Comparator




For usage example about Comparator Functions, see page 83

Name	Description	Return type
MLCompCheck	Checks if the reference of a comparator Pipe Block has been crossed. Returns TRUE if the reference has been crossed	BOOL
MLComInit	Initializes a comparator Pipe Block with user-defined settings	BOOL
MLCompReadRef	Returns the reference position of a comparator block	None
MLCompReset	Clears the Transition Flag of a comparator Pipe Block	BOOL
MLCompWriteRef	Sets the reference position of a comparator block	BOOL

1.1.7.1 MLCompCheck

1.1.7.2.1 Description

Check if the reference of a comparator Pipe Block has been crossed. Returns the Transition Flag of a comparator object, which turns TRUE if the input position to the comparator is greater or equal to the reference. The Comparator Transition Flag stays TRUE until it is reset.

**Figure 1-16:** MLCompCheck

1.1.7.3.2 Arguments

1.1.7.4.3.1 Input

BlockID	Description	ID number of an initiated Comparator object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—

1.1.7.5.4.2 Output

Default (.Q)	Description	Returns TRUE if reference position of the Comparator object has been crossed
	Data type	BOOL
	Unit	n/a

1.1.7.6.5.3 Return Type

BOOL

1.1.7.7.6 Related Functions



MLCompReset

MLCompWriteRef

MLCompReadRef

1.1.7.8.7 Example**1.1.7.9.8.1 Structured Text**

```
//Check if Comparator Reference has been reached
bCrossed := MLCompCheck( PipeNetwork.MyComp );
```

1.1.7.10.9.2 Ladder Diagram**1.1.7.11.10.3 Function Block Diagram****1.1.7.12 MLComplInit****1.1.7.13.1 Description**

Initializes a comparator Pipe Block for use in a PLC Program. Function block is automatically called if a Comparator Block is added to the Pipe Network, with user-defined settings entered in the Pipe Blocks Properties screen.

The Transition Flag of a comparator object turns TRUE if the input position to the comparator is greater or equal to the reference. The Comparator Transition Flag stays TRUE until it is reset.

If the input ThroughZero is set to TRUE, system must cross zero and then the reference position before the Transition Flag is set. If ThroughZero is FALSE, Transition Flag is set immediately if the input pipe position is greater or equal to the Reference value.



Comparator objects are normally created in the Pipe Network using the graphical engine. Then you do not have to add MLComplInit function blocks to their programs. Parameters are entered directly in pop-up windows, and the code is then automatically added to the current project.

1.1.7.14.2 Arguments**1.1.7.15.3.1 Input**

BlockID	Description	ID number of a created Comparator Pipe Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
ModuloPosition	Description	Value of the period of a cyclic system
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
ThroughZero	Description	When TRUE, system must cross zero and then the reference position before the Transition Flag is set. If FALSE, Transition Flag is set immediately if the input pipe position is greater then or equal to the Reference value.
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Reference	Description	Set the reference position in the new Comparator object
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

1.1.7.16.4.2 Output

Default (.Q)	Description	Returns TRUE when function starts to execute
	Data type	BOOL

1.1.7.17.5.3 Return Type

BOOL

1.1.7.18.6 Related Functions

MLBlkCreate



MLCompCheck

MLCompReset

MLCompWriteRef

1.1.7.19.7 Example**1.1.7.20.8.1 Structured Text**

```
//Create and Initiate a Trigger object
MyComp := MLBlkCreate( 'MyComp', 'COMPARATOR' );
MLCompInit( MyComp, 360.0, TRUE, 45.0 );
```

1.1.7.21.9.2 Ladder Diagram**1.1.7.22.10.3 Function Block Diagram****1.1.7.23 MLCompReadRef****1.1.7.24.1 Description**

Returns the reference position of a comparator block. The Transition Flag of a comparator object turns TRUE if the input position to the comparator is greater or equal to the reference. The Comparator Transition Flag stays TRUE until it is reset.

1.1.7.25.2 Arguments**1.1.7.26.3.1 Input**

BlockID	Description	ID number of an initiated Comparator object
	Data type	DINT

Range	[-2147483648, 2147483648]
Unit	n/a
Default	—

1.1.7.27.4.2 Output

Reference	Description	Returns the current reference position of the Comparator object
	Data type	LREAL
	Unit	User unit

1.1.7.28.5 Related Functions

MLCompWriteRef

MLCompReset


MLCompCheck

1.1.7.29.6 Example

1.1.7.30.7.1 Structured Text

```
//Return the Comparator Reference value
CompRef := MLCompReadRef( PipeNetwork.MyComp );
```

1.1.7.31.8.2 Ladder Diagram



1.1.7.32.9.3 Function Block Diagram



1.1.7.33 MLCompReset

1.1.7.34.1 Description

Clear the Transition Flag of a comparator Pipe Block. The Transition Flag of a comparator object turns TRUE if the input position to the comparator is greater or equal to the reference. The Comparator Transition Flag stays TRUE until it is reset.

1.1.7.35.2 Arguments**1.1.7.36.3.1 Input**

BlockID	Description	ID number of an initiated Comparator object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—

1.1.7.37.4.2 Output

Default (.Q)	Description	Returns TRUE when function starts to execute
	Data type	BOOL
	Unit	n/a

1.1.7.38.5.3 Return Type

BOOL

1.1.7.39.6 Related Functions


MLCompCheck

MLCompReadRef

MLCompWriteRef

1.1.7.40.7 Example**1.1.7.41.8.1 Structured Text**

```
//Clear the Transition Flag of a Comparator object
MLCompReset( PipeNetwork.MyComp );
```

1.1.7.42.9.2 Ladder Diagram**1.1.7.43.10.3 Function Block Diagram**

1.1.7.44 MLCompWriteRef

1.1.7.45.1 Description

Set the reference position of a comparator block. The Transition Flag of a comparator object turns TRUE if the input position to the comparator is greater or equal to the reference. The Comparator Transition Flag stays TRUE until it is reset.

If the input ThroughZero is set to TRUE, system must cross zero and then the reference position before the Transition Flag is set. If ThroughZero is FALSE, Transition Flag is set immediately if the input pipe position is greater then or equal to the Reference value.




Figure 1-17: MLCompWriteRef

1.1.7.46.2 Arguments

1.1.7.47.3.1 Input

BlockID	Description	ID number of an initiated Comparator object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
ThroughZero	Description	When TRUE, system must cross zero and then the reference position before the Transition Flag is set. If FALSE, Transition Flag is set immediately if the input pipe position is greater then or equal to the Reference value.
	Data type	BOOL
	Range	0, 1

	Unit	n/a
	Default	—
Reference	Description	New reference position to set in the selected Comparator object
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

1.1.7.48.4.2 Output

Default (.Q)	Description	Returns TRUE when function starts to execute
	Data type	BOOL
	Unit	n/a

1.1.7.49.5.3 Return Type

BOOL

1.1.7.50.6 Related Functions

MLCompCheck

MLCompReadRef


MLCompReset


1.1.7.51.7 Example

1.1.7.52.8.1 Structured Text



```
// Set the Comparator Reference value
MLCompWriteRef( PipeNetwork.MyComp , TRUE , 45 );
```

1.1.7.53.9.2 Ladder Diagram




1.1.7.54.10.3 Function Block Diagram**1.1.7.55 Usage example of Comparator Functions**


When you call the **MLCompWriteRef** function, the output for **MLCompCheck** becomes True as soon as the input value reaches the reference.



The same function can also be called for a cyclic input value.



When the THROUGH_ZERO parameter is set to YES, the output for MLCompCheck becomes True as soon as the input value reaches the reference, but not before it has passed through zero.

**Figure 1-18:** Comparator Functions Usage**1.1.8 Motion Library - Convertor**

Name	Description	Return type
MLCNVConnect	Connects a converter Pipe Block to the specified axis	BOOL
MLCNVConnectEx	Connects an extra converter Pipe Block to the specified axis. This function connects the output of a pipe to an axis data other than the control position.	BOOL
MLCNVDisconnect	Disconnects a converter Pipe Block from its associated axis	BOOL
MLCNVInit	Initializes a converter Pipe Block in Position or Speed mode	BOOL

1.1.8.1 MLCNVConnect

1.1.8.2.1 Description

Connect a converter Pipe Block to the specified axis. When using the Pipe Network for coordinated motion, Pipe Blocks have to be Activated, Connected, and then Powered On before move commands work.

The Converter block changes the incoming flow of values to continuous position output with no periodicity. If a converter block is not connected to an Axis, it does not send position output values to its assigned Axis. Every pipe branch must end in a converter, whether or not it is connected to a destination Axis object, as seen in Figure 1 below.




Figure 1-19: MLCNVConnect

NOTE

All converters in the Pipe Network can be connected at once with the command PipeNetwork(MLPN_Connect). This calls automatically generated code with MLCNVConnect commands for each Converter block. Therefore, in a multi-axis program only one command can be used to connect Pipe Blocks instead of writing code for each Axis separately.

TIP

The converter block has the ability to control the analog output on the AKD. See for information on the parameters.

1.1.8.3.2 Arguments

1.1.8.4.3.1 Input

BlockID	Description	ID number of an initiated Converter object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
AxisID	Description	ID number of an initiated Axis object
	Data type	DINT
	Range	[-2147483648, 2147483648]

Unit	n/a
Default	—

1.1.8.5.4.2 Output

Default (.Q)	Description	Returns TRUE if the converter is connected to the Axis object
	Data type	BOOL
	Unit	n/a

1.1.8.6.5.3 Return Type

BOOL

1.1.8.7.6 Related Functions



MLCNVConnectEx

MLCNVDisconnect

MLCNVInit

1.1.8.8.7 Example1.1.8.9.8.1 Structured Text

```
//Connect a converter Pipe Block to Axis1
MLCNVConnect( CNV1, AXIS1 );
```

1.1.8.10.9.2 Ladder Diagram1.1.8.11.10.3 Function Block Diagram

1.1.8.12 MLCNVConnectEx

1.1.8.13.1 Description

Connect a converter Pipe Block to the specified axis. This function connects the output of a pipe to an axis data other than the control position. With this function, several converter Pipe Blocks can connect to the same axis and acts on different data.

Normally a Converter block sends position values to an Axis. However, some cases exist that require additional information such as torque feed-forward (IDN 3056) that needs to be provided by a second converter.

-  NOTE** This FB does not work when you choose to simulate the device. In such a case, the FB continuously generates error messages displayed in the Controller log window.
-  NOTE** Need to add 16#8000 to desired IDN number for ValueID input. 8000 in hexadecimal signals a vendor-specific IDN value.

1.1.8.14.2 Arguments

1.1.8.15.3.1 Input

BlockID	Description	ID number of an initiated Converter object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
AxisID	Description	ID number of an initiated Axis object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—

ValueID Description (for EtherCAT motion bus)

EtherCAT:

Specify the following constant:

- EC_ADDITIVE_TORQUE_VALUE
(for torque feed-forward)
- EC_ANALOG_OUTPUT
(for control of Analog Output: AKD parameter: "AOUT.VALUEU")

 **NOTE**

If the Analog Output is mapped to a PLC variable, the connection to the analog output by EC_ANALOG_OUTPUT will not work as the output value will be overwritten by the PLC mapped variable data. In order to function properly the AOUT.MODE must be set to "User Mode (mode = 0)".

 **TIP**

The PDO values will be overwritten by Mapped PLC variables including a possible link to the mapping of variables or the section on MLPParamWrite() warning indicating that the function block write of Analog output will be overwritten by the MLCnvConnectEx function.

Precedence rules:

1. A PLC variable mapped to Analog Output takes precedence.
2. If MLCNVConnect assigns a Pipe output to Analog Output it will take precedence over a DriveParamWrite function call.
3. DriveParamWrite will modify the Analog Output but get overwritten by the higher precedent options if they are present.

Data type DINT

Range [-2147483648, 2147483648]

Unit n/a

Default —

ValueInfo

Description

EtherCAT:

This value is ignored and must be set to **zero**

Data type DINT

Range [-2147483648, 2147483648]

Unit	n/a
Default	—

1.1.8.16.4.2 Output

Default (.Q)	Description	Returns TRUE if the converter is connected to the Axis object
	Data type	BOOL
	Unit	n/a

1.1.8.17.5.3 Return Type

BOOL

1.1.8.18.6 Related Functions


MLCNVConnect

MLCNVDisconnect

MLCNVInit

1.1.8.19.7 Example1.1.8.20.8.1 Structured Text

```
//Connect a converter Pipe Block to Axis1 to send feed-forward
MLCNVConnectEx( PipeNetwork.CNV1, PipeNetwork.AXIS1, EC_
ADDITIVE_TORQUE_VALUE, 0 );
```

1.1.8.21.9.2 Ladder Diagram1.1.8.22.10.3 Function Block Diagram

1.1.8.23 MLCNVDisconnect**1.1.8.24.1 Description**

Disconnect a converter Pipe Block from its associated axis.

If a converter block is not connected to an Axis, it does not send position output values to its assigned Axis. Can disconnect one or multiple Axis from the Pipe Network and still send single-axis motion commands. Axis can be disconnected while the Pipe Positions are reset to different values or if coordinated motion is only not needed with every axis in the project in a certain state.

1.1.8.25.2 Arguments**1.1.8.26.3.1 Input**

BlockID	Description	ID number of an initiated Converter object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—

1.1.8.27.4.2 Output

Default (.Q)	Description	Returns TRUE if the converter is disconnected from the Axis object
	Data type	BOOL
	Unit	n/a

1.1.8.28.5.3 Return Type

BOOL


1.1.8.29.6 Related Functions

MLCNVConnect

MLCNVInit

1.1.8.30.7 Example**1.1.8.31.8.1 Structured Text**

```
//Disconnect a converter Pipe Block from its axis
MLCNVDisconnect( CNV1);
```

1.1.8.32.9.2 Ladder Diagram1.1.8.33.10.3 Function Block Diagram**1.1.8.34 MLCNVInit**1.1.8.35.1 Description

Initializes a converter Pipe Block. Function block is automatically called if a Convertor Block is added to the Pipe Network, with the input mode (position or speed) entered in the Pipe Blocks Properties screen. The Converter block changes the incoming flow of speed or position values to continuous position output with no periodicity.

NOTE Converter objects are normally created in the Pipe Network using the graphical engine. Then you do not have to add MLCNVInit function blocks to their programs. Parameters are entered directly in pop-up windows, and the code is then automatically added to the current project.

1.1.8.36.2 Arguments1.1.8.37.3.1 Input

BlockID	Description	ID number of a created Pipe Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
Mode	Description	1 for Position mode, 2 for Speed mode. Determines the type of input to the Converter Object.
	Data type	DINT
	Range	[1, 2]
	Unit	n/a
	Default	—

1.1.8.38.4.2 Output

Default (.Q)	Description	Returns TRUE if the Convertor Pipe Block is initialized
--------------	-------------	---

Data type	BOOL
Unit	n/a

1.1.8.39.5.3 Return Type

BOOL



1.1.8.40.6 Related Functions

MLBlkCreate

MLCNVConnect

1.1.8.41.7 Example1.1.8.42.8.1 Structured Text

```
//Create and Initiate a Convertor object
CNV1 := MLBlkCreate( 'CNV1', 'CONVERTOR' );
MLCNVInit( CNV1, 1 );
```

1.1.8.43.9.2 Ladder Diagram1.1.8.44.10.3 Function Block Diagram**1.1.9 Motion Library - Delay**

Name	Description	Return type
MLDelayInit	Initializes a delay object	BOOL

1.1.9.1 MLDelayInit**1.1.9.2.1 Description**

Initializes a delay object. Returns TRUE if the function succeeded. This FB is automatically created in the compiled code of a Pipe Network. It is included in the MLPN_CREATE_OBJECT

(created in ST) which is typically executed in a project as part of the startup sequence of the Pipe Network.

1.1.9.3.2 Arguments

1.1.9.4.3.1 Input


BlockID	Description	ID number of a created Pipe Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
CycleDelay	Description	Number of delay cycles
	Data type	DINT
	Range	[0 , 9]
	Unit	Cycle
	Default	0

1.1.9.5.4.2 Example

1.1.9.6.5.3 Structured Text

```
MLDelayInit(PipeNetwork.DELAY1, 2);
```

1.1.9.7.6.4 Ladder Diagram



End of Module

1.1.9.8.7.5 Function Block Diagram



1.1.10 Motion Library - Derivator

Name	Description	Return type
MLDerInit	Initializes a derivator object	BOOL
MLDerReadInModPos	Returns the input MODULO_POSITION of the Derivator block	None
MLDerWriteInModPos	Sets the input MODULO_POSITION of the Derivator block	BOOL

1.1.10.1 MLDerInit

1.1.10.2.1 Description

Initializes an derivator object. Function block is automatically called if a Derivator Block is added to the Pipe Network, with user-defined settings entered in the Pipe Blocks Properties screen. Input ModuloPosition is defined to manage the periodicity (modulo) of the input values.

NOTE Derivator objects are normally created in the Pipe Network using the graphical engine. Then you do not have to add MLDerInit function blocks to their programs. Parameters are entered directly in pop-up windows, and the code is then automatically added to the current project.




Figure 1-20: MLDerInit

1.1.10.3.2 Arguments

1.1.10.4.3.1 Input

BlockID	Description	ID number of a created Pipe Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
ModuloPosition	Description	Input ModuloPosition of Derivator object
	Data type	LREAL
	Range	—

Unit	User unit
Default	360.0

1.1.10.5.4.2 Output

Default (.Q)	Description	Returns TRUE if the Derivator object is initialized
	Data type	BOOL
	Unit	n/a

1.1.10.6.5.3 Return Type

BOOL

1.1.10.7.6 Related Functions


MLBlkCreate

MLDerReadInModPos

MLDerWriteInModPos

1.1.10.8.7 Example1.1.10.9.8.1 Structured Text

```
//Create and Initiate a Derivator object
MyDerivator := MLBlkCreate( 'MyDerivator', 'DERIVATOR' );
MLDerInit( MyDerivator, 360.0 );
```

1.1.10.10.9.2 Ladder Diagram1.1.10.11.10.3 Function Block Diagram

1.1.10.12 MLDerReadInModPos

1.1.10.13.1 Description

Returns the Input ModuloPosition of the derivator block. Input ModuloPosition is defined to manage the periodicity (modulo) of the input values.

For example, if the input value increases each millisecond by one degree then the output value is 1000 degrees per second. Now lets imagine that the input value skips suddenly from 359 to 0

- If Input ModuloPosition = 360, the output continues to indicate 1000 degrees per second, indicating that rollover into the next period has been properly handled

- If Input ModuloPosition = 1000, the output then indicates 359,000 degrees per second, indicating that the input has incorrectly interpreted roll-over as a 359 degree move in one millisecond




Figure 1-21: MLDerReadInModPos



The first calculation of a Derivator Pipe Block just after the pipe installation indicates zero regardless of the initial input value.

1.1.10.14.2 Arguments

1.1.10.15.3.1 Input

ID	Description	ID number of an initiated Derivator object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—

1.1.10.16.4.2 Output

ModuloPosition	Description	Current Input ModuloPosition of the selected Derivator object
	Data type	LREAL
	Unit	User unit
	Default	—

1.1.10.17.5 Related Functions

MLDerWriteInModPos

MLDerInit

1.1.10.18.6 Example**1.1.10.19.7.1 Structured Text**

```
//save the current input MODULO_POSITION of a Derivator object
DerInputPeriod := MLDerReadInModPos ( PipeNetwork.MyDerivator );
```

1.1.10.20.8.2 Ladder Diagram**1.1.10.21.9.3 Function Block Diagram****1.1.10.22 MLDerWriteInModPos****1.1.10.23.1 Description**

Sets the Input ModuloPosition of the Derivator block. Input ModuloPosition is defined to manage the periodicity (modulo) of the input values.

For example, if the input value increases each millisecond by one degree then the output value is 1000 degrees per second. Now lets imagine that the input value skips suddenly from 359 to 0

- If Input ModuloPosition = 360, the output continues to indicate 1000 degrees per second, indicating that rollover into the next period has been properly handled

- If Input ModuloPosition = 1000, the output then indicates 359,000 degrees per second, indicating that the input has incorrectly interpreted roll-over as a 359 degree move in one millisecond




Figure 1-22: MLDerWriteInModPos



NOTE The first calculation of a Derivator Pipe Block just after the pipe installation indicates zero regardless of the initial input value.

1.1.10.24.2 Arguments

1.1.10.25.3.1 Input

ID	Description	ID number of an initiated Derivator object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
ModuloPosition	Description	Desired new value of Input ModuloPosition of the selected Derivator object
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

1.1.10.26.4.2 Output

Default (.Q)	Description	Returns TRUE if the Input ModuloPosition value is changed
	Data type	BOOL
	Unit	n/a

1.1.10.27.5.3 Return Type

BOOL



1.1.10.28.6 Related Functions

MLDerReadInModPos

MLDerInit

1.1.10.29.7 Example**1.1.10.30.8.1 Structured Text**


```
//change the input MODULO_POSITION of a Derivator object to 720
MLDerWriteInModPos ( PipeNetwork.MyDerivator, 720 );
```

1.1.10.31.9.2 Ladder Diagram**1.1.10.32.10.3 Function Block Diagram****1.1.11 Motion Library - Gear**


Name	Description	Return type
MLGearInit	Initializes a Gear Pipe Block with user-defined settings	BOOL
MLGearReadOffset	Returns the offset value of selected Gear Block	None
MLGearReadOffSlp	Returns the Offset Slope value of selected Gear Block	None
MLGearReadRatio	Returns the ratio value of a gear block	None
MLGearReadRatSlp	Returns the ratio slope value of a gear block	None
MLGearWriteOff	Sets the Offset value of a selected Gear Pipe Block	BOOL
MLGearWriteOSlp	Sets the Offset Slope value of a selected Gear Pipe Block	BOOL
MLGearWriteRatio	Sets the Ratio value of a selected Gear Pipe Block	BOOL
MLGearWriteRatSlp	Sets the Ratio Slope value of a selected Gear Pipe Block	BOOL

1.1.11.1 Usage example of Gear Functions


The output value starts with offset = 0 and gain = 1 (blue line)



You can call the **MLGearWriteOff** function to modify the Offset (where Offset_Slope is set with the **MLGearWriteOSlp** function).



After setting the Offset (Q=TRUE in the previous figure), you can call the **MLGearWriteRatio** function to modify the gear Ratio (where Gain_Slope is set with the **MLGearWriteRatSlp** function).



The output value is finally adapted with the gear offset and ratio (blue line).




Figure 1-23: Gear Functions Usage

1.1.12 Motion Library - Integrator

Name	Description	Return type
MLIntInit	Initializes an integrator object	BOOL
MLIntWriteOutVal	Sets the output value of an integrator object	BOOL

1.1.12.1 MLIntInit

1.1.12.2.1 Description

Initializes an integrator object. Function block is automatically called if an Integrator Block is added to the Pipe Network, with user-defined settings entered in the Pipe Blocks Properties screen.

Integrator object can operate in Modulo or not modulo mode. While in Modulo mode, the output values are adapted according to the entered ModuloPosition value.




Figure 1-24: MLIntInit

NOTE

Integrator objects are normally created in the Pipe Network using the graphical engine. Then you do not have to add MLIntInit function blocks to their programs. Parameters are entered directly in pop-up windows, and the code is then automatically added to the current project.

1.1.12.3.2 Arguments

1.1.12.4.3.1 Input

BlockID	Description	ID number of a created Pipe Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
ModuloPosition	Description	Output ModuloPosition of Integrator object
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	360.0
Modulo	Description	TRUE when mode is modulo. Modulo mode adapts the output values according to the ModuloPosition (modulo)
	Data type	BOOL

Range	0, 1
Unit	n/a
Default	TRUE

1.1.12.5.4.2 Output

Default (.Q)	Description	Returns TRUE if the Integrator object is initialized
	Data type	BOOL

1.1.12.6.5.3 Return Type

BOOL



1.1.12.7.6 Related Functions

MLBlkCreate

MLIntWriteOutVal

1.1.12.8.7 Example1.1.12.9.8.1 Structured Text

```
//Create and Initiate an Integrator object
MyIntegrator := MLBlkCreate( 'MyIntegrator', 'INTEGRATOR' );
MLIntInit(MyIntegrator, 360.0, true );
```

1.1.12.10.9.2 Ladder Diagram1.1.12.11.10.3 Function Block Diagram

1.1.12.12 MLIntWriteOutVal

1.1.12.13.1 Description

Sets the output value of an integrator object. This function can force the output to an entered value not dependent on the input value from the Pipe Network.



NOTE Output value can jump to another value instantly after the function is executed if the Pipe Network is running.

1.1.12.14.2 Arguments

1.1.12.15.3.1 Input

BlockID	Description	ID number of an initiated Integrator object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
Value	Description	Desired new output value of the selected Integrator object
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

1.1.12.16.4.2 Output

Default (.Q)	Description	Returns TRUE if the output value if the Integrator object is changed
	Data type	BOOL
	Unit	n/a

1.1.12.17.5.3 Return Type

BOOL



1.1.12.18.6 Related Functions

MLIntInit

1.1.12.19.7 Example

1.1.12.20.8.1 Structured Text

```
//change the output value of an integrator object to 35
MLIntWriteOutVal ( PipeNetwork.MyIntegrator, 35.0 );
```

1.1.12.21.9.2 Ladder Diagram1.1.12.22.10.3 Function Block Diagram1.1.13 Motion Library - Master

For usage example about Master Functions, see page 131

Function sorted by types:

Motion Control	Inquiry Functions	Position setting
MLMstInit	MLMstReadAccel	MLMstAbs
MLMstRun	MLMstReadDecel	MLMstAdd
MLMstWriteAccel	MLMstReadInitPos	MLMstForcePos
MLMstWriteDecel	MLMstReadSpeed	MLMstRel
MLMstWriteSpeed	MLMstStatus	

Functions sorted in alphabetical order:

Name	Description	Return type
MLMstAbs	Does an absolute move	BOOL
MLMstAdd	Does an additive move relative for a specified distance from the endpoint of the previous move	BOOL
MLMstForcePos	Forces the specified position. Possible only when the block is not moving.	BOOL
MLMstInit	Initializes a master object (TMP generator)	BOOL
MLMstReadAccel	Gets the present acceleration value of a master block	None
MLMstReadDecel	Gets the present deceleration value of a master block	None
MLMstReadInitPos	Gets the initial position of a master block	None
MLMstReadSpeed	Gets the speed of a master block	None

Name	Description	Return type
MLMstRel	Does an Relative move for a specified distance from the current position	BOOL
MLMstRun	Jogs at the specified speed. Returns TRUE if the function succeeded	BOOL
MLMstStatus	Returns the status of the generator	DINT
MLMstWriteAccel	Sets the acceleration of a master block	BOOL
MLMstWriteDecel	Sets the deceleration of a master block	BOOL
MLMstWriteInitPos	Sets the initial position of a master block	BOOL
MLMstWriteSpeed	Sets the speed of a master block	BOOL

1.1.13.1 MLMstAbs

1.1.13.2.1 Description


Performs a move to an absolute position. Returns TRUE if the function succeeded.

1.1.13.3.2 Arguments

1.1.13.4.3.1 Input

BlockID	Description	ID name of the Master Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—

Position	Description	Sets the value of the absolute destination position. When the Modulo is turned on, the Master Block moves to the targeted position during the corresponding period, calculated as follows:
		<ul style="list-style-type: none"> • If the Position input is between 0 and the Modulo Position, then the Master Block moves within the current period (no position rollover). • If the Position input is greater than the Modulo Position, then the Master Block moves during one of the next period (positive position rollover).



The Master Block works similarly for negative positions: if the Position input is less than zero, then the Master Block moves during one of the **previous** period (negative position rollover).

Data type	LREAL
Range	—
Unit	User unit
Default	—

1.1.13.5.4.2 Output

Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL

Unit n/a

1.1.13.6.5 Related Functions

MLMstWriteSpeed

MLMstWriteDecel

MLMstWriteSpeed

1.1.13.7.6 Example**1.1.13.8.7.1 Structured Text**

```
MLMstAbs( PipeNetwork.MASTER, 1000.0 );
```

1.1.13.9.8.2 Ladder Diagram**1.1.13.10.9.3 Function Block Diagram****1.1.13.11 MLMstAdd****1.1.13.12.1 Description**

Performs a move for a specified distance relative to the endpoint of the previous move. Returns TRUE if the function succeeded.

1.1.13.13.2 Arguments**1.1.13.14.3.1 Input**

EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Block ID	Description	ID name of the Master Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—

DeltaPos	Description	Relative distance to move
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

1.1.13.15.4.2 Output

Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	n/a

1.1.13.16.5 Related Functions

MLMstWriteSpeed

MLMstWriteDecel

1.1.13.17.6 Example

1.1.13.18.7.1 Structured Text


```
MLMstAdd( PipeNetwork.MASTER, 750.0 );
```

1.1.13.19.8.2 Ladder Diagram



You must use a pulse contact to start the FB

1.1.13.20.9.3 Function Block Diagram



1.1.13.21 MLMstForcePos**1.1.13.22.1 Description**

Forces the position of a Master Block to a specified position. This block can only be executed when motion is not occurring. It can be used to force the master starting position to the desired values from which to start motion.

1.1.13.23.2 Arguments**1.1.13.24.3.1 Input**

EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Block ID	Description	ID name of the Master Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
Position	Description	Defines the Master starting position when the motion starts
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	n/a

1.1.13.25.4.2 Output

Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL

1.1.13.26.5 Related Functions


MLMstReadInitPos

1.1.13.27.6 Example**1.1.13.28.7.1 Structured Text**


```
MLMstForcePos( PipeNetwork.MASTER, 2500.0 );
```

1.1.13.29.8.2 Ladder Diagram

NOTE You must use a pulse contact to start the FB

1.1.13.30.9.3 Function Block Diagram**1.1.13.31 MLMstInit****1.1.13.32.1 Description**

Initializes a Master TMP (trapezoidal motion profile) generator block. This function is automatically created when the MLMaster Block is included in the Pipe Network Editor. Based on the parameters defined in the Master pipe block (see figure below), the Inputs for this function are initialized by default.

**Figure 1-25:** TMP Initialization

1.1.13.33.2 Arguments

1.1.13.34.3.1 Input

Block ID	Description	ID name of the Master Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
ModuloPosition	Description	Modulo Position for cyclic motion systems expressed in user logical units (Position Rollover Value)
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
Period	Description	Sampling period of the generator expressed according to the update cycle (e.g. 2.0 means the sampling is done once every 2 cycles)
	Data type	LREAL


	Range	—
	Unit	User unit
	Default	—
Speed	Description	Travel speed value expressed in user logical units per second. The travel speed value is used to set the constant speed part of the trapezoidal motion profile
	Data type	LREAL
	Range	—
	Unit	User unit/sec
	Default	—
Acceleration	Description	Acceleration value expressed in user logical units per second squared. The acceleration value is always used to generate the first part of the trapezoidal motion profile
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Deceleration	Description	Deceleration value expressed in user logical units per second squared. The deceleration value is always used to generate the last part of the trapezoidal motion profile
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Initial Position	Description	Initial position value expressed in user logical units. Used only at the pipe activation to initialize the position starting point
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
Modulo	Description	The available modes are Modulo (True) or No modulo (False)
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—


1.1.13.35.4.2 Output

Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	n/a

1.1.13.36.5 Example1.1.13.37.6.1 Structured Text

```
MLMstInit( PipeNetwork.MASTER, 360.0, 1.0, 1000.0, 10000.0,
10000.0, 0.0, true );
```

1.1.13.38.7.2 Ladder Diagram

1.1.13.39.8.3 Function Block Diagram**1.1.13.40 MLMstReadAccel**1.1.13.41.1 Description

Get the presently used value for acceleration of a master block.

1.1.13.42.2 Arguments1.1.13.43.3.1 Input

EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Block ID	Description	ID name of the Master Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—

1.1.13.44.4.2 Output

OK	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	n/a
Acceleration	Description	Returns Acceleration value
	Data type	LREAL
	Unit	User unit/sec ²



1.1.13.45.5 Related Functions

MLMstReadSpeed

MLMstReadDecel

1.1.13.46.6 Example**1.1.13.47.7.1 Structured Text**

```
MLMstReadAccel( PipeNetwork.MASTER );
```

1.1.13.48.8.2 Ladder Diagram**1.1.13.49.9.3 Function Block Diagram****1.1.13.50 MLMstReadDecel****1.1.13.51.1 Description**

Get the presently used value for deceleration of a master block.

1.1.13.52.2 Arguments**1.1.13.53.3.1 Input**

EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Block ID	Description	ID name of the Master Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—

1.1.13.54.4.2 Output

OK	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	n/a


Deceleration	Description	Returns Deceleration value
	Data type	LREAL
	Unit	User unit/sec ²

1.1.13.55.5 Example


1.1.13.56.6.1 Structured Text

```
MLMstReadDecel( PipeNetwork.MASTER );
```

1.1.13.57.7.2 Ladder Diagram



1.1.13.58.8.3 Function Block Diagram



1.1.13.59 MLMstReadInitPos

1.1.13.60.1 Description

Get the presently used value for initial position of a master block.

1.1.13.61.2 Arguments

1.1.13.62.3.1 Input

EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Block ID	Description	PipeNetwork Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—

1.1.13.63.4.2 Output

OK	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	n/a
Position	Description	Returns Intial Postion
	Data type	LREAL
	Unit	User unit

1.1.13.64.5 Example1.1.13.65.6.1 Structured Text

```
MstInitPos := MLMstReadInitPos( PipeNetwork.MASTER );
```

1.1.13.66.7.2 Ladder Diagram1.1.13.67.8.3 Function Block Diagram**1.1.13.68 MLMstReadSpeed**1.1.13.69.1 Description

Get the presently used value for speed of a master block.

1.1.13.70.2 Arguments1.1.13.71.3.1 Input

EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Block ID	Description	ID name of the Master Block
	Data type	DINT

Range	[-2147483648, 2147483648]
Unit	n/a
Default	—

1.1.13.72.4.2 Output

OK	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	n/a
Speed	Description	Returns current Speed
	Data type	LREAL
	Unit	User unit/sec

1.1.13.73.5 Related Functions

MLMstReadAccel


MLMstReadDecel

1.1.13.74.6 Example

1.1.13.75.7.1 Structured Text

```
MstSpeed := MLMstReadSpeed( PipeNetwork.MASTER );
```

1.1.13.76.8.2 Ladder Diagram



1.1.13.77.9.3 Function Block Diagram



1.1.13.78 MLMstRel

1.1.13.79.1 Description

Performs a move for a specified distance relative to the current position. Returns TRUE if the function succeeded.

1.1.13.80.2 Arguments

1.1.13.81.3.1 Input

EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Block ID	Description	ID name of the Master Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
DeltaPos	Description	Relative distance to move
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

1.1.13.82.4.2 Output

Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	n/a

1.1.13.83.5 Related Functions

[MLMstWriteSpeed](#)

[MLMstWriteDecel](#)


1.1.13.84.6 Example

1.1.13.85.7.1 Structured Text

```
MLMstRel( PipeNetwork.MASTER, 750.0 );
```

1.1.13.86.8.2 Ladder Diagram

NOTE You must use a pulse contact to start the FB

1.1.13.87.9.3 Function Block Diagram**1.1.13.88 MLMstRun****1.1.13.89.1 Description**

Jog at the specified speed. Returns TRUE if the function succeeded.

1.1.13.90.2 Arguments**1.1.13.91.3.1 Input**

EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Block ID	Description	ID name of the Master Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
Speed	Description	Speed to jog motor
	Data type	LREAL
	Range	—
	Unit	User unit/sec
	Default	—

1.1.13.92.4.2 Output

Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	n/a


1.1.13.93.5 Related Functions

MLMstWriteSpeed

MLMstWriteDecel

1.1.13.94.6 Example1.1.13.95.7.1 Structured Text

```
MLMstRun( PipeNetwork.MASTER, 1250.0 );
```

1.1.13.96.8.2 Ladder Diagram1.1.13.97.9.3 Function Block Diagram1.1.13.98 MLMstStatus1.1.13.99.1 Description

The value returned is the state being executed by the TMP generator as it processes the various motion commands. Some states are transitory, others are stable until the next event takes place. The following terms are relevant to the returned values.

Term	Definition
Running	Speed is non-zero
Stopped	Speed is zero
Positioning	A target position has been programmed with a relative, additive or absolute command.

Status	Definition
0	(New speed programmed) is entered when a jog move (MLMstRun) is commanded and the current speed is not at the commanded speed.
1	(Stable state Running or Stopped) is entered when a jog move (MLMstRun) is commanded and the current speed is at the commanded speed. (Stable state Running or Stopped) is entered when a position move is programmed and motion is completed.
2	(Speed change) is entered when the current speed is greater than the commanded speed.
3	(Speed reversal while positioning) is entered when a position move is programmed and the distance to go requires a speed reversal.
4	(Acceleration while positioning) current speed is below the travel speed
5	(Constant Speed while positioning) is entered when a positioning move is commanded and the current speed is at the commanded speed.
6	(Deceleration while positioning) is entered when a positioning move is commanded and the current speed is changing to achieve the target position at zero speed.
7	(Micro step) is entered when a small change in position is required and the current speed is zero.

1.1.13.100.2 Arguments

1.1.13.101.3.1 Input


EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Block ID	Description	ID name of the Master Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—

1.1.13.102.4.2 Output

OK	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	n/a
Default (.Q)	Description	Returns the status of the generator
	Data type	DINT
	Unit	n/a

1.1.13.103.5 Example**1.1.13.104.6.1 Structured Text**

```
MasterStatus := MLMstStatus( PipeNetwork.MASTER );
```

1.1.13.105.7.2 Ladder Diagram**1.1.13.106.8.3 Function Block Diagram****1.1.13.107 MLMstWriteAccel****1.1.13.108.1 Description**

Set the acceleration of a master block. Returns TRUE if the function succeeded.

1.1.13.109.2 Arguments**1.1.13.110.3.1 Input**

EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—

Block ID	Description	ID name of the Master Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—

Acceleration	Description	Acceleration value expressed in user logical units per second squared
	Data type	LREAL
	Range	—

Unit	User unit/sec ²
Default	—

1.1.13.111.4.2 Output

Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	n/a

1.1.13.112.5 Related Functions

MLMstAbs


MLMstRel

MLMstWriteSpeed

MLMstWriteDecel

1.1.13.113.6 Example**1.1.13.114.7.1 Structured Text**

```
MLMstWriteAccel( PipeNetwork.MASTER, 40000.0 );
```

1.1.13.115.8.2 Ladder Diagram**1.1.13.116.9.3 Function Block Diagram****1.1.13.117 MLMstWriteDecel****1.1.13.118.1 Description**

Set the deceleration of a master block. Returns TRUE if the function succeeded.

1.1.13.119.2 Arguments**1.1.13.120.3.1 Input**

EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Block ID	Description	ID name of the Master Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
Deceleration	Description	Deceleration value
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—

1.1.13.121.4.2 Output

Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	n/a

1.1.13.122.5 Related Functions

MLMstWriteSpeed

1.1.13.123.6 Example**1.1.13.124.7.1 Structured Text**

```
MLMstWriteDecel( PipeNetwork.MASTER, 40000.0 );
```

1.1.13.125.8.2 Ladder Diagram



1.1.13.126.9.3 Function Block Diagram



1.1.13.127 MLMstWriteInitPos

1.1.13.128.1 Description

Set the initial position of a master block. Returns TRUE if the function succeeded.

1.1.13.129.2 Arguments

1.1.13.130.3.1 Input


EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Block ID	Description	ID name of the Master Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
Position	Description	Initial position
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

1.1.13.131.4.2 Output

Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	n/a

1.1.13.132.5 Example1.1.13.133.6.1 Structured Text

```
MLMstWriteInitPos( PipeNetwork.MASTER, 120.0 );
```

1.1.13.134.7.2 Ladder Diagram1.1.13.135.8.3 Function Block Diagram**1.1.13.136 MLMstWriteSpeed**1.1.13.137.1 Description

Set the speed of a master block. Returns TRUE if the function succeeded.

1.1.13.138.2 Arguments1.1.13.139.3.1 Input

EN	Description	Enables FB to be executed
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—

Block ID	Description	ID name of the Master Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
Speed	Description	Speed of the motion
	Data type	LREAL
	Range	—
	Unit	User unit/sec
	Default	—

1.1.13.140.4.2 Output

Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL
	Unit	n/a

1.1.13.141.5 Related Functions

MLMstWriteSpeed

MLMstWriteDecel


1.1.13.142.6 Example

1.1.13.143.7.1 Structured Text

```
MLMstWriteSpeed( PipeNetwork.MASTER, 400.0 );
```

1.1.13.144.8.2 Ladder Diagram



1.1.13.145.9.3 Function Block Diagram**1.1.13.146 Usage example of Master Functions**

MLMstRun(0.0) reduce the speed down to 0.




Figure 1-26: Master Functions Usage

1.1.14 Motion Library - Phaser

For usage example about Phaser Functions, see page 132

Names	Description	Return type
MLPhalnit	Initializes a phaser Pipe Block	BOOL
MLPhaReadPhase	Gets the phase value of a phaser block	None

Names	Description	Return type
MLPhaReadSlope	Gets the phase slope value of a phaser block	None
MLPhaWritePhase	Sets the phase value of a phaser block	BOOL
MLPhaWriteSlope	Sets the phase slope value of a phaser block	BOOL
MLPhaReadActPhase		

① TIP

There is a delay when using an external encoder. The delay is five cycles (2 cycles to read the encoder from the AKD via EtherCAT, 1 cycle for computing, 2 cycles for sending the new position set point to the AKD). This lag error is speed proportional (5 cycles * speed). A Phaser block can be used to compensate for this lag.

When executing, the phaser block is in one of three states: **Standby**, **Changing phase**, or **Applying phase**.

Standby	Entered when the Block is initialized. Exits to the State "Changing Phase" when the Phase value is changed via the MLPhaWritePhase command
Changing Phase	Entered when a new value is programmed, and exits to "Applying phase" state when the programmed phase offset is reached. The current Phase offset value is slewed to the new phase offset by the amount of the slew value.
Applying Phase	Entered when the programmed Phase value is reached. Exits to the Changing phase state whenever a new value is programmed via the MLPhaWritePhase function changes the Phase Offset target.

1.1.14.1 Usage example of Phaser Functions

You can call MLPhaWritePhase function to modify the Phase value..

You can call MLPhaWriteSlope to modify the rate of change of phase, or slope, applied when the Phase value is changed.




Figure 1-27: Phaser Functions Usage



NOTE % **MODULO_POSITION** is in the equation to take into account the modulo (periodicity) of the value.

1.1.15 Motion Library - PMP

Name	Description	Return type
MLPmpAbs	Moves to an Absolute Position	BOOL

Name	Description	Return type
MLPmpForcePos	Forces the specified position. Possible only when the block is not moving.	BOOL
MLPmpInit	Initializes a PMP object (Parabolic Motion Profile generator) with user-defined settings	BOOL
MLPmpReadAccel	Gets the Acceleration parameter of a PMP block	None
MLPmpReadFstSpd	Gets the FirstTravelSpeed parameter of a PMP block	None
MLPmpReadInitPos	Gets the InitialPosition parameter of a PMP block	None
MLPmpReadJerk	Gets the Jerk parameter of a PMP block	None
MLPmpReadLstSpd	Gets the LastTravelSpeed parameter of a PMP block	None
MLPmpRel	Does two subsequent relative moves	BOOL
MLPmpRun	Jog the generator at the specified speed	BOOL
MLPmpStatus	Returns the status of the PMP block generator	None
MLPmpWriteAccel	Sets the acceleration parameter of a PMP block	BOOL
MLPmpWriteFstSpd	Sets the FirstTravelSpeed parameter of a PMP block	BOOL
MLPmpWriteJerk	Sets the jerk parameter of a PMP block	BOOL
MLPmpWriteLstSpd	Sets the LastTravelSpeed parameter of a PMP block	BOOL

1.1.16 Motion Library - Sampler

Name	Description	Return type
MLSmpConnect	Connects a sampler to a pipe network axis or pipe block	BOOL
MLSmpConnectEx	Connects a sampler to the specified external data source	BOOL
MLSmpInit	Initializes a sampler object	BOOL

① TIP

There is a delay when using an external encoder. The delay is five cycles (2 cycles to read the encoder from the AKD via EtherCAT, 1 cycle for computing, 2 cycles for sending the new position set point to the AKD). This lag error is speed proportional (5 cycles * speed). A Phaser block can be used to compensate for this lag.

1.1.16.1 MLSmpConnect

1.1.16.2.1 Description

Connect a sampler to an axis or pipe block as a value source. Returns TRUE if the function succeeded.

1.1.16.3.2 Arguments**1.1.16.4.3.1 Input**

BlockID	Description	ID Name of the SMP function block in the Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
AxisID	Description	ID Name of the Axis or Pipe Block the sampler is connected to
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—

1.1.16.5.4.2 Output


Default (Q)	Description	Returns True if the Sampler is connected
	Data type	BOOL
	Unit	n/a


1.1.16.6.5.3 Return Type

BOOL

1.1.16.7.6 Example**1.1.16.8.7.1 Structured Text**

```
MLSmpConnect( PipeNetwork.EncoderMaster1, AxisID(*DINT*) ) ;
```

1.1.16.9.8.2 Ladder Diagram

1.1.16.10.9.3 Function Block Diagram**1.1.16.11 MLSmpConnectEx****1.1.16.12.1 Description**

Connect a sampler to the specified data source. Returns TRUE if the function succeeded.

1.1.16.13.2 Arguments**1.1.16.14.3.1 Input**


BlockID	Description	ID Name of the SMP function block in the Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
DriverName	Description	Driver name of the external source or Axis Name. Examples: 'EtherCATDriver' 'AXIS1' 'PLCOpenAxis1'
	Data type	STRING
	Range	—
	Unit	n/a
	Default	—

SourceConfig	Description	Configuration of the source (for EtherCAT motion bus) or the specific variable inside an axis object.
---------------------	--------------------	---

EtherCAT:

The string must have the form '<EtherCAT address>:<source type>'
 For example: '1001:Position actual value 2'

- This maps the secondary feedback from an axis in the created pipe network
- The <EtherCAT address> can be found by looking in *EtherCATcode* item in the project Dictionary. For example:

**Example for AXIS1 'PipePosition'**

(One of the following:

- 'PipePosition'
- 'ReferencePosition'
- 'GeneratorPosition'
- 'ActualPosition'
- 'FeedbackPosition'
- '2ndFeedbackPosition'
- 'ActualVelocity'
- 'ActualTorque'
- 'FollowingError'
- 'CurrentPosition')

PLCOpen Axis:**Example: PLCOpenAxis1 'ActualPosition'**

(One of the following:

- 'ActualPosition'
- 'CommandPosition'
- 'NormalCmdPos'
- 'SuperimposedCmdPos'
- 'PhaseCmdPos')

Data Type STRING

Range —

Unit n/a

Default —

1.1.16.15.4.2 Output

Default (.Q)	Description	Function block is operational
---------------------	--------------------	-------------------------------


Data type	BOOL
Unit	n/a

1.1.16.16.5.3 Return Type

BOOL

1.1.16.17.6 Example**1.1.16.18.7.1 Structured Text**

```
MLSmpConnectEx(PipeNetwork.Feedback2, 'EtherCATDriver',
'1001:Position actual value 2');
```

1.1.16.19.8.2 Ladder Diagram**1.1.16.20.9.3 Function Block Diagram****1.1.16.21 MLSmpInit****1.1.16.22.1 Description**

The purpose of the sampler block is to periodically sample and place into a pipe some output of a source object. The sampled output can typically be the POSITION or SPEED of a source object measured by a resolver, an encoder or some other types of sensor.

The sampler implements the logical connection between an encoder on a physical master axis (the source object) and one or more pipes and performs the function of periodically sampling the source and placing the sampled values into the pipe.

This function block is automatically called by the Function PipeNetwork(MLPN_CREATE_OBJECTS) if a Smp Block is added to the Pipe Network, with user-defined settings entered in the Pipe Blocks Properties screen.

The Smp Pipe Block is assigned a Name, SAMPLING_PERIOD, MODE, INPUT_VALUE_PERIOD and OUTPUT_VALUE_PERIOD.


1.1.16.23.2 Arguments

1.1.16.24.3.1 Input

BlockID	Description	ID Name of the PMP function block in the Pipe Network
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
SamplingPeriod	Description	period that the device is sampled
	Data type	LREAL
	Range	0.25 to ?
	Unit	millisecond
	Default	1.0
Mode	Description	Sampled output can be either position or velocity
	Data type	DINT
	Range	[1 , 2] Position or Speed
	Unit	n/a
	Default	position
InputModuloPosition	Description	Period of the input signal. This should be set equal to 2^{32} (4294967296).
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	360.0
OutputModuloPosition	Description	Period of the output signal
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	360.0
<u>1.1.16.25.4.2 Output</u>		
Default (.Q)	Description	Smp Block successfully initiated
	Data type	BOOL
	Unit	n/a

1.1.16.26.5 Example**1.1.16.27.6.1 Structured Text**

```
MLSmplInit( PipeNetwork.EncoderMaster1, SamplingPeriod(*LREAL*),
Mode (*DINT*),
InputModuloPosition (*LREAL*), OutputModuloPosition (*LREAL*) ) );
```

1.1.16.28.7.2 Ladder Diagram**1.1.16.29.8.3 Function Block Diagram****1.1.17 Motion Library - Synchronizer**

For usage example about Synchronizer Functions, see page 148

Name	Description	Return type
<code>MLSyncInit</code>	Initializes a synchronizer Pipe Block	BOOL
<code>MLSyncReadDeltaS</code>	Gets the output phasing value of a synchronizer block	None
<code>MLSyncStart</code>	Starts a synchronization of a synchronizer Pipe Block	BOOL
<code>MLSyncStop</code>	De-synchronizes a synchronizer Pipe Block	BOOL
<code>MLSyncWriteDeltaS</code>	Sets the output phasing value of a synchronizer block	BOOL

1.1.17.1 MLSyncInit**1.1.17.2.1 Description**

Initializes a synchronizer Pipe Block. Returns TRUE if the function succeeded.

This FB is automatically created in the compiled code of a Pipe Network.

This function block is part of the MLPN_CREATE_OBJECT to initialize the Pipe Network. It is called at the beginning of an application program with the function call:

```
PipeNetwork (MLPN_CREATE_OBJECTS) ;
```

1.1.17.3.2 Arguments**1.1.17.4.3.1 Input**

BLockID	Description	Name of the Pipe Network Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
ModuloPosition	Description	The modulo distance
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
CurveType	Description	The curve type to the motion when starting and stopping synchronization. Option are Parabolic or Polynomial
	Data type	DINT
	Range	[1 , 2] (1 = Parabolic, 2 = Polynomial)
	Unit	n/a
	Default	—
DeltaS	Description	The Distance to get in or out of synchronization. This parameter is used in the MLSyncStart and MLSyncStop FunctionBlocks
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

1.1.17.5.4.2 Output



Default (.Q)	Description	Function Block Execute Successfully
	Data type	BOOL
	Unit	n/a

1.1.17.6.5 Related Functions



MLSyncWriteDeltaS

1.1.17.7.6 Example**1.1.17.8.7.1 Structured Text**

```
MLSyncInit( PipeNetwork.SYN, 360, 1, 30 );
```

1.1.17.9.8.2 Ladder Diagram**1.1.17.10.9.3 Function Block Diagram****1.1.17.11 MLSyncReadDeltaS****1.1.17.12.1 Description**

Gets the output phasing value of a synchronizer block. Output phasing is the distance or the slope the output takes to synchronize with the input when MLSyncStart Block is executed (see "Figure 1-28: Get Output Phasing after MLSyncStart " on page 143). It also affects the distance or the slope the output takes to desynchronize with the input and come to a stop when MLSyncStop Block is executed (see "Figure 1-29: Get Output Phasing after MLSyncStop " on page 143).

**Figure 1-28: Get Output Phasing after MLSyncStart****Figure 1-29: Get Output Phasing after MLSyncStop**

1.1.17.13.2 Arguments

1.1.17.14.3.1 Input

BlockID	Description	Name of the Pipe Network Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—

1.1.17.15.4.2 Output



DeltaS	Description	Present Delta Slope value
	Data type	LREAL
	Unit	User unit

1.1.17.16.5 Related Functions

MLSyncWriteDeltaS

1.1.17.17.6 Example**1.1.17.18.7.1 Structured Text**

```
ActScope := MLSyncReadDeltas( PipeNetwork.SYN );
```

1.1.17.19.8.2 Ladder Diagram**1.1.17.20.9.3 Function Block Diagram****1.1.17.21 MLSyncStart****1.1.17.22.1 Description**

Start a synchronization of a synchronizer Pipe Block. Returns TRUE if the function succeeded.




Figure 1-30: MLSyncStart

1.1.17.23.2 Arguments**1.1.17.24.3.1 Input**

BlockID	Description	Name of the Pipe Network Block
---------	-------------	--------------------------------

Data type	DINT
Range	[-2147483648, 2147483648]
Unit	n/a
Default	—

1.1.17.25.4.2 Output


Default (.Q)	Description	Function Block Execute Successfully
	Data type	BOOL
	Unit	n/a

1.1.17.26.5 Example1.1.17.27.6.1 Structured Text

```
MLSyncStart( PipeNetwork.SYN );
```

1.1.17.28.7.2 Ladder Diagram1.1.17.29.8.3 Function Block Diagram**1.1.17.30 MLSyncStop**1.1.17.31.1 Description

De-synchronizes a synchronizer Pipe Block. Returns TRUE if the function succeeded.

**Figure 1-31: MLSyncStop****1.1.17.32.2 Arguments****1.1.17.33.3.1 Input**

Position	Description	Motion Stop Position
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

1.1.17.34.4.2 Output

Default (.Q)	Description	Function Block Execute Successfully
	Data type	BOOL
	Unit	n/a

1.1.17.35.5 Example**1.1.17.36.6.1 Structured Text**

```
MLSyncStop( PipeNetwork.SYN , 120 );
```

1.1.17.37.7.2 Ladder Diagram

1.1.17.38.8.3 Function Block Diagram



1.1.17.39 MLSyncWriteDeltasS

1.1.17.40.1 Description

Set the output phasing value of a synchronizer block. Returns TRUE if the function succeeded. Output phasing is the distance or the slope the output takes to synchronize with the input when MLSyncStart Block is executed. It also affects the distance or the slope the output takes to desynchronize with the input and come to a stop when MLSyncStop Block is executed.




Figure 1-32: Set output phasing after MLSyncStart




Figure 1-33: Set output phasing after MLSyncStop

1.1.17.41.2 Arguments**1.1.17.42.3.1 Input**

BlockID	Description	Name of the Pipe Network Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
DeltaS	Description	Slope to be used during Start and stop of Synchronization
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

1.1.17.43.4.2 Output

Default (.Q)	Description	Function Block Execute Successfully
	Data type	BOOL
	Unit	n/a

1.1.17.44.5 Example**1.1.17.45.6.1 Structured Text**


```
MLSyncWriteDeltas( PipeNetwork.SYN, 45 );
```

1.1.17.46.7.2 Ladder Diagram**1.1.17.47.8.3 Function Block Diagram**

1.1.17.48 Usage example of Synchronizer Functions

When you call the **MLSyncStop** function, the output value is adapted according to the specified Stop-Position (point B).

The **OUTPUT_PHASING** parameter is used to define point A, where the flow follows a curve in order to smooth the output value.



When you call the **MLSyncStart** function, the output value is adapted to catch up with the input value.

The **OUTPUT_PHASING** parameter is also used to define a curve in order to smooth the output value.




Figure 1-34: Synchronizer Functions Usage

1.1.18 Motion Library - Trigger



For usage example about Trigger Functions, see page 161

Name	Description	Return type
MLTrigClearFlag	Clears the flag of an initiated Trigger block	BOOL
MLTrigInit	Initializes a Trigger object	BOOL
MLTrigIsTriggered	Checks if the selected block has been triggered	BOOL
MLTrigReadDelay	Returns the time that the trigger block uses to compensate the delay of the sensor that captures the triggering signal	None
MLTrigReadPos	Returns the position of the block at the moment when it was triggered	None
MLTrigReadTime	Returns the time of the moment where the block was triggered in milliseconds	None
"MLTrigSetEdge" (see page 159)	Sets the edge configuration for a Trigger object	BOOL
MLTrigWriteDelay	Sets the time that the trigger block uses to compensate for the delay introduced by the sensor that captures the triggering signal	BOOL

1.1.18.1 MLTrigClearFlag

1.1.18.2.1 Description

Clears the flag of an initiated Trigger block so the block can capture the position and time of the next event. Once triggered, a block has to be reset with this command before it can be triggered again. All events that are sent to a block while in a triggered state are ignored and the position and time information is lost.

IMPORTANT The Fast Input assigned to a Trigger block has to be reset as well before information on a new event can be captured. MLAxisRstFastIn is generally used at the same time as MLTrigClearFlag

1.1.18.3.2 Arguments

1.1.18.4.3.1 Input

BlockID	Description	ID number of an initiated Trigger object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—

1.1.18.5.4.2 Output

Default (.Q)	Description	Returns TRUE if function block is executed
	Data type	BOOL
	Unit	n/a

1.1.18.6.5.3 Return Type

BOOL

1.1.18.7.6 Related Functions

MLAxisRstFastIn

MLTrigIsTriggered

MLTrigReadPos

MLTrigReadTime

1.1.18.8.7 Example**1.1.18.9.8.1 Structured Text**

```
//Clear Trigger Flag
MLTrigClearFlag( PipeNetwork.TRIGGER );
```

1.1.18.10.9.2 Ladder Diagram**1.1.18.11.10.3 Function Block Diagram****1.1.18.12 MLTrigInit****1.1.18.13.1 Description**

Initializes a Trigger object for use in a PLC Program. Function block is automatically called if a Trigger Block is added to the Pipe Network, with user-defined settings entered in the Pipe Blocks Properties screen.

The Trigger object monitors a selected Fast Input and captures the time of a rising or falling edge event. With the time and pipe position information the Trigger object extrapolates the axis position when the Fast Input event occurred.

Parameters to enter include the name of the Pipe Block, the Axis where the Fast Input is located, the number of the desired Fast Input, and whether to trigger on the rising or falling edge of the input.

NOTE Trigger objects are normally created in the Pipe Network using the

NOTE

graphical engine. Then you do not have to add MLTrigInit function blocks to their programs. Parameters are entered directly in pop-up windows, and the code is then automatically added to the current project.

1.1.18.14.2 Arguments**1.1.18.15.3.1 Input**

BlockID	Description	ID number of a created Pipe Block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
Input_Axis	Description	Name of the axis where the Fast Input is located
	Data type	STRING
	Range	—
	Unit	n/a
	Default	—
InputID	Description	ID number of the Fast Input 0 = Capture Engine 0 1 = Capture Engine 1 Range is [0,1] For information on configuring the capture engines, refer to AKD Capture Engine Configuration.
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
EdgeID	Description	Trigger at rising or falling edge of Fast Input. Enter 1 for rising edge, 2 for falling edge, and 0 disables the Fast Input
	Data type	DINT
	Range	[0 , 2]
	Unit	n/a
	Default	1 (Rising edge)

1.1.18.16.4.2 Output

Default (.Q)	Description	Returns TRUE if function block is executed
	Data type	BOOL
	Unit	n/a

1.1.18.17.5.3 Return Type

BOOL

1.1.18.18.6 Related Functions

MLTrigIsTriggered



MLTrigReadPos

MLTrigClearFlag

MLAxisRstFastIn

1.1.18.19.7 Example**1.1.18.20.8.1 Structured Text**

```
//Create and Initiate a Trigger object
TRIGGER := MLBlkCreate( 'TRIGGER', 'TRIGGER' );
MLTrigInit( TRIGGER, 'Axis1', 0, 1 );
```

1.1.18.21.9.2 Ladder Diagram**1.1.18.22.10.3 Function Block Diagram**

1.1.18.23 MLTrigIsTriggered

1.1.18.24.1 Description

Checks if the selected block has been triggered. When a block has been triggered, it contains the time and position when a Fast Input event occurred. The application has to reset the block before the block can be triggered again. All trigger events that are sent to the block during its triggered state are lost.




Figure 1-35: MLTrigIsTriggered

NOTE

Once triggered, a block has to be reset before it can be triggered again. All events that are sent to a block while in a triggered state are ignored and the position and time information is lost.

1.1.18.25.2 Arguments

1.1.18.26.3.1 Input

BlockID	Description	ID number of an initiated Trigger object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—

1.1.18.27.4.2 Output

Default (.Q)	Description	Returns TRUE if the selected Trigger Object has Triggered
	Data type	BOOL
	Unit	n/a

1.1.18.28.5.3 Return Type

BOOL

1.1.18.29.6 Related Functions


MLTrigReadPos

MLTrigReadTime

1.1.18.30.7 Example

//Check if a Trigger Block has been triggered, then save position

```
IF MLTrigIsTriggered( PipeNetwork.TRIGGER ) THEN
    Trig_Position := MLTrigReadPos( PipeNetwork.TRIGGER );
END_IF
```

1.1.18.31.8.1 Ladder Diagram1.1.18.32.9.2 Function Block Diagram**1.1.18.33 MLTrigReadDelay**1.1.18.34.1 Description

Electronic sensors are not able to respond immediately to a signal. Sensors usually require a certain amount of time to process a change of state in their input signal. This function returns the delay that has been programmed in a trigger block by the `MLTrigWriteDelay` function to compensate for this reaction time required by the sensor.

1.1.18.35.2.1 Input

<code>BlockID</code>	Description	Identifier of the trigger block whose delay is requested
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
<code>En</code>	Description	Enables execution

Data type	BOOL
Unit	n/a
Default	-

1.1.18.36.3.2 Output

Delay	Description	Value of the delay compensation currently applied by the trigger block
OK	Data type	LREAL
	Unit	microseconds
	Description	Returns true when the function successfully executes
	Data type	BOOL
	Unit	n/a

1.1.18.37.4 Related Functions

MLTrigWriteDelay

1.1.18.38 MLTrigReadPos

1.1.18.39.1 Description

Returns the position of the block at the moment when it was triggered by the Trigger Block's selected Fast Input. This value is only valid when TrigIsTriggered() returns TRUE. The Trigger block extrapolates the output value based on the timestamp of the Fast Input event to provide an accurate position even if the event occurs in the middle of a program cycle.

Once triggered, a block has to be reset before it can be triggered again. All events that are sent to a block while in a triggered state are ignored and the position and time information is lost.




Figure 1-36: MLTrigReadPos

1.1.18.40.2 Arguments**1.1.18.41.3.1 Input**

BlockID	Description	ID number of an initiated Trigger object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a

Default —

1.1.18.42.4.2 Output

Position	Description	Returns the position of the selected block's Axis at the moment when it was triggered
	Data type	LREAL

Unit User unit

1.1.18.43.5 Related Functions

MLTrigIsTriggered

MLTrigReadTime

MLTrigClearFlag


MLAxisRstFastIn


1.1.18.44.6 Previous Function Name

MLTrigGetPos

1.1.18.45.7 Example**1.1.18.46.8.1 Structured Text**

```
//Save position of Axis when Fast Input event occurs
Trig_Position := MLTrigReadPos( PipeNetwork.TRIGGER );
```

1.1.18.47.9.2 Ladder Diagram

1.1.18.48.10.3 Function Block Diagram**1.1.18.49 MLTrigReadTime****1.1.18.50.1 Description**

Returns the time of the moment where the block was triggered in milliseconds. This value is only valid when TrigIsTriggered() returns TRUE. The output is computed from the timestamp of a Fast Input time event

Once triggered, a block has to be reset before it can be triggered again. All events that are sent to a block while in a triggered state are ignored and the position and time information is lost.




Figure 1-37: MLTrigReadTime

1.1.18.51.2 Arguments**1.1.18.52.3.1 Input**

BlockID	Description	ID number of an initiated Trigger object
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—

1.1.18.53.4.2 Output

Time	Description	Returns the time that the Trigger Block's selected Fast Input was triggered
	Data type	LREAL
	Unit	milliseconds

1.1.18.54.5 Related Functions

MLTrigIsTriggered

MLTrigReadPos

MLTrigClearFlag

MLAxisRstFastIn


1.1.18.55.6 Previous Function Name

MLTrigGetTime

1.1.18.56.7 Example

//Save time when Fast Input event occurs

Trig_Time := MLTrigReadTime(PipeNetwork.TRIGGER);

1.1.18.57.8.1 Ladder Diagram1.1.18.58.9.2 Function Block Diagram1.1.18.59 MLTrigSetEdge1.1.18.60.1 Description

Sets the edge configuration (rising, falling, etc.) for a trigger block. This block should be called prior to calling MLAxisCfgFastIn. Also the value at the Edge input must match the value at MLAxisCfgFastIn's Mode input.

1.1.18.61.2 Arguments**1.1.18.62.3.1 Input**



BlockID	Description	Identifier of the trigger block
	Data type	DINT
	Range	[-2147483648, 2147483647]
	Unit	n/a
	Default	—
Edge	Description	The edge on which to trigger
		0 = disable the fast input 1 = rising edge 2 = falling edge
	Data type	DINT
	Range	[0,2]
	Unit	n/a
	Default	1 (rising edge)

1.1.18.63.4.2 Output

Q	Description	True if block executed successfully False if execution is not successful
	Data type	BOOL
	Unit	n/a

1.1.18.64.5.3 Return Type

BOOL

1.1.18.65.6 Examples**1.1.18.66.7.1 Function Block Diagram****1.1.18.67.8.2 Ladder Diagram****1.1.18.68.9.3 Structured Text**

```
TrigEdgeChanged := MLTrigSetEdge(TrigBlockID, TrigEdge);
```

1.1.18.69 MLTrigWriteDelay

1.1.18.70.1 Description

Electronic sensors are not able to respond immediately to a signal. Sensors usually require a certain amount of time to process a change of state in their input signal. This function allows the trigger block to calculate the exact moment at which a signal was triggered by letting you specify the delay introduced by the sensor.

1.1.18.71.2.1 Input

BlockID	Description	Identifier of the trigger block
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—
Delay	Description	Reaction time of the sensor that the trigger block has to compensate
	Data type	LREAL
	Range	—
	Unit	microseconds
	Default	—

1.1.18.72.3.2 Output

Default (.Q)	Description	Returns TRUE if the delay is successfully set
	Data type	BOOL
	Unit	n/a

1.1.18.73.4.3 Return Type


BOOL

1.1.18.74.5 Related Functions


MLTrigReadDelay

1.1.18.75 Usage example of Trigger Functions


When you call the **MLTrigClearFlag** function, the flag for trigger is reset to False.



When a Fast Input is set, the **MLTrigIsTriggered** function returns True.



Then you can call the **MLTrigReadPos** and **MLTrigReadTime** functions to get more details.

**Figure 1-38:** Trigger Functions Usage

IMPORTANT The trigger delay has to be calculated by **you** and set with the MLTrigWriteDelay function block.
This delay belongs to the sensor and it is additional to the MLTrigReadTime / MLTrigReadPos.

1.2 Motion Library / PLCopen

Functions sorted in alphabetical order:

Name	Description
MC_AbortTrigger	Abort MC_TouchProbe
MC_AddSuperAxis	Add an axis to the axis's list of assigned, superimposed axes.
MC_CamIn	Performs a slave axis move based on the Cam Table
MC_CamOut	Disengages the slave axis from a MC_CamIn move
MC_CamResumePos	Returns the slave axis position for resuming an MC_CamIn move
MC_CamStartPos	Returns the slave axis position for starting an MC_CamIn move
MC_CamTblSelect	Defined to read and initialize the specified profile
MC_ClearFaults	Clear Drive Faults
MC_CreateAxis	Creates a PLCopen Axis
MC_EStop	Performs a Emergency stop
MC_ErrorDescription	Converts the PLCopen error IDs into message strings.
MC_GearIn	Performs a slave axis move based on the ratio
MC_GearInPos	Performs a slave axis move based on the ratio

Name	Description
MC_GearOut	Disengages the slave axis from a MC_GearIn or MC_GearInPos move
MC_Halt	Decelerates an axis to zero velocity
MC_InitAxis	Initializes a PLCopen Servo Axis' data
MC_MachRegist	Runs Mark-to-Machine registration
MC_MarkRegist	Runs Mark-to-Mark registration
MC_MoveAbsolute	Performs a single-axis move to a specified endpoint position
MC_MoveAdditive	Performs a single-axis move for a specified distance from the endpoint of the previous move
"MC_MoveRelative" (see page 215)	Performs a single-axis move for a specified distance
MC_MoveSuperimp	Performs a single-axis move which is superimposed upon the active move
MC_MoveVelocity	Performs a single-axis non-ending move at a specified velocity
MC_Phasing	Performs a master position phase shift for the slave axis
MC_Power	Requests to enable the drive and close the loop, or disable the drive and open the loop
MC_ReadActPos	Reads the actual position of the axis
MC_ReadActVel	Reads the actual velocity of the axis
MC_ReadAxisErr	Returns the error status of the specified axis
MC_ReadBoolPar	Returns the value of the specified Boolean axis parameter
MC_ReadParam	Returns the value of the specified axis parameter
MC_ReadStatus	Returns the state of the specified axis
MC_Reference	Defines the position at the reference location for PLCopen Axis
MC_RemSuperAxis	Remove an axis from the axis's list of assigned, superimposed axes.
MC_ResetError	Resets the errors of the specified axis
MC_SetOverride	Writes velocity and acceleration override factors
MC_SetPosition	Deprecated by MC_SetPos
MC_SetPos	Sets a new axis position
MC_Stop	Aborts the active move, removes the next move from the queue, performs a controlled stop, and switches the axis to Stopping state
MC_StopRegist	Turns off registration for the specified axis
MC_SyncSlaves	Specifies synchronized slaves
MC_TouchProbe	Arm a Fast Input and capture an axis position
MC_WriteBoolPar	Writes the specified axis Boolean parameter
MC_WriteParam	Writes the specified axis parameter

1.2.1 Control

1.2.1.1 MC_ClearFaults (Function)

1.2.1.2.1 Description

MC_ClearFaults sends a request to the drive to clear any drive faults that exists.

 **NOTE**

The condition causing the drive fault has to be corrected before calling this function. If the fault condition still exists when this function is called, this function sends a request to the drive but the drive faults remain.

This function does **not** reset axis errors. MC_ResetError is required to reset axis errors.



Figure 1-39: MC_ClearFaults

1.2.1.3.2 Arguments

1.2.1.4.3.1 Input

En	Description	Function enable – execute function. This Input must be on shot.
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Axis	Description	AXIS_REF.AXIS_NUM is the master axis number
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—

1.2.1.5.4.2 Output

OK	Description	Boolean output to indicate successful request. This output does not indicate that the fault are cleared, but simply indicates the request was made.
	Data type	BOOL

1.2.1.6.5 Usage

Upon the positive transition of the EN input, this function requests a Fault Reset of the Drive for the Axis defined in the axis input of this function.

1.2.1.7.6 Related Functions


MC_ResetError

1.2.1.8.7 Example**1.2.1.9.8.1 Structured Text**

```
(* MC_ClearFaults ST example *)
MC_ClearFaults( Axis1); //clear drive faults for Axis 1
```


1.2.1.10.9.2 Ladder Diagram

Reset the Fault of the Drive for the current Axis when the button is pressed

**1.2.1.11 MC_CreateAxis****1.2.1.12.1 Description**

This function creates a PLCopen Axis. A call to this function is automatically generated when the application is compiled, based on the data entered in the PLCopen Axis Data dialog.

IMPORTANT MC_CreateAxis must be called between MLMotionInit and MLMotionStart.

**Figure 1-40: MC_CreateAxis****1.2.1.13.2 Arguments****1.2.1.14.3.1 Input****En****Description** Requests to create a PLCopen axis

	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
AxisName	Description	Axis name
	Data type	STRING
	Range	—
	Unit	n/a
	Default	—
BusInterface	Description	Bus interface identifier: “EtherCATDriver” = EtherCAT interface “MSBusDriver” = KAS Simulator interface
	Data type	STRING
	Range	—
	Unit	n/a
	Default	—
BusAddress	Description	Address of the drive on the bus
	Data type	DINT
	Range	bus dependent
	Unit	n/a
	Default	—
AxisNumber	Description	Axis number
	Data type	UINT
	Range	[1,256]
	Unit	n/a
	Default	—
AxisType	Description	Axis type: 0 (MC_AXIS_TYPE_SERVO) denotes servo 1 (MC_AXIS_TYPE_DIGITIZING) denotes digitizing 2 (MC_AXIS_TYPE_VIRTUAL_ SERVO) denotes virtual servo
	Data type	USINT
	Range	[0,1]
	Unit	n/a
	Default	—


UserUnits	Description	User unit portion of the user unit/feedback unit ratio
	Data type	UDINT
	Range	[1,4294967296]
	Unit	User unit
	Default	—
FeedbackUnits	Description	Feedback unit portion of the user unit/feedback unit ratio
	Data type	UDINT
	Range	[1,4294967296]
	Unit	feedback units. Note: The FeedbackUnits input must be a power of 2. If input FeedbackUnits is not a power of two, the axis will not be created, and the OK output will be FALSE.
	Default	—
Rollover	Description	Rollover position (0 = no rollover)
	Data type	UDINT
	Range	[0, 4294967296]
	Unit	User unit
	Default	—
UpdateRate	Description	Servo update rate (0, 1, and 2 are reserved for future enhancements) 3 = 125 µsec 4 = 250 µsec 5 = 500 µsec 6 = 1 msec 7 = 2 msec 8 = 4 msec 9 = 8 msec
	Data type	UINT
	Range	[3,9]
	Unit	n/a
	Default	—

1.2.1.15.4.2 Output

OK	Description	Indicates the axis has been created
	Data type	BOOL

1.2.1.16.5 Example**1.2.1.17.6.1 Structured Text**

```
(* MC_CreateAxis ST example *)
MC_CreateAxis( 'PLCopenAxis1', 'EtherCATDriver', 1001, 1, MC_AXIS_
TYPE_SERVO, 360, 1048576, 0, 3 );
```

1.2.1.18.7.2 Ladder Diagram**1.2.1.19 MC_EStop****1.2.1.20.1 Description**

This function causes an emergency stop (E-stop). An E-stop stops motion interpolation, clear all moves from the queue (active and next), change the axis state to ErrorStop, and request the drive to open the position loop and disable the drive. The E-stop remains in effect until the application calls MC_ResetError to reset the E-stop.



Figure 1-41: MC_EStop

1.2.1.21.2 Arguments**1.2.1.22.3.1 Input**

En	Description	A positive transition of this input causes an E-stop on the specified axis
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Axis	Description	Axis identifier
	Data type	AXIS_REF

Range	1-256
	The AXIS_NUM element of the AXIS_REF structure must be in the range [1-256]
Unit	n/a
Default	—

1.2.1.23.4.2 Output

OK	Description	Indicates the E-stop was executed. If an invalid Axis input was specified, this output is not energized and no E-stop is performed.
	Data type	BOOL

1.2.1.24.5 Usage

Call MC_EStop to generate an emergency stop for an axis.

Call MC_ResetError to reset the emergency stop.

1.2.1.25.6 Related Functions

MC_ResetError


1.2.1.26.7 Example

1.2.1.27.8.1 Structured Text

```
(* MC_Estop ST example *)
MC_Estop( Axis1 ); //E-Stop Axis 1
```

1.2.1.28.9.2 Ladder Diagram

E-stop both axes when the E-stop button is pressed



1.2.1.29 MC_InitAxis (Function)

1.2.1.30.1 Description

MC_InitAxis initializes a PLCopen Servo Axis' data. A call to this function is automatically generated when the application is compiled, based on the data entered in the PLCopen Axis Data dialog.




Figure 1-42: MC_InitAxis

1.2.1.31.2 Arguments

1.2.1.32.3.1 Input

En	Description	Request to initialize a PLCopen servo axis
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
AxisNumber	Description	Servo axis number
	Data type	UINT
	Range	[1,256]
	Unit	none
	Default	—
VelocityLimit	Description	Velocity limit
	Data type	LREAL
	Range	—
	Unit	User unit/sec
	Default	—
LowerLimit	Description	Lower position limit
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
UpperLimit	Description	Upper position limit
	Data type	LREAL
	Range	—


	Unit	User unit
	Default	—
LimitControl	Description	Establishes how position limits are applied 0 = apply position limits 1 = ignore position limits 2 = ignore limits until referenced
	Data type	UINT
	Range	[0,2]
	Unit	n/a
	Default	—
PosErrorLimit	Description	Position error limit – when the Position Error (command position – actual position) exceeds this value, an E-stop is generated
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
InPositionBand	Description	In-position bandwidth – when the axis actual position is within this distance from its programmed endpoint, the axis is considered “in position”
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

1.2.1.33.4.2 Output**OK**

Description	Indicates the initialization is complete
Data type	BOOL

1.2.1.34.5 Example1.2.1.35.6.1 Structured Text

```
(* MC_InitAxis ST example *)
MC_InitAxis( 1, 0, 0, 0, 2, 0, 0 );
```

1.2.1.36.7.2 Ladder Diagram**1.2.1.37 MC_Power**1.2.1.38.1 Description

This function block requests to enable the drive and close the position loop, or disable the drive and open the position loop. The Status output indicates the state of the position loop. If the position loop is open, the axis command position is set to the actual position of the axis and tracks the actual position.




Figure 1-43: MC_Power

 NOTE

You must be careful if you have more than one instance of MC_Power FB for the same drive, scanned in the same cycle. The problem arises when one instance requests the drive to enable and the other requests the same drive to disable.

To avoid this trap, it is recommended to have only one instance of MC_Power for all of your active programs.

1.2.1.39.2 Arguments**1.2.1.40.3.1 Input**

Enable	Description	When this transitions go to high, the control closes the servo loop and sends a command to the drive to enable.
	Description	When this transitions go to low, the control opens the servo loop and sends a command to the drive to disable.
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function.
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—
Enable Positive	Description	<i>for future enhancement</i>
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Enable Negative	Description	<i>for future enhancement</i>
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
BufferMode	Description	Unused
	Data type	SINT
	Range	[0]
	Unit	n/a
	Default	—

1.2.1.41.4.2 Output

Status	Description	Indicates the enabled/disabled state of the drive
	Data type	BOOL
Busy	Description	<i>for future enhancement – always false</i>
	Data type	BOOL

Error	Description	Indicates an invalid input was specified
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT

1.2.1.42.5 Example

1.2.1.43.6.1 Structured Text

```
(* MC_Power ST example *)


Inst_MC_Power( CloseLoopReq, Axis1, TRUE, TRUE, 0 );

//Inst_MC_Power is an instance of MC_Power function block

DriveIsOn := Inst_MC_Power.Status; //store the Status output
into a user defined variable
```

1.2.1.44.7.2 Ladder Diagram

Close the servo loop and enable the drive when CloseLoop is high.
Open the servo loop and disable the drive when CloseLoop is low.



1.2.1.45 MC_ResetError

1.2.1.46.1 Description

The function MC_ResetError resets the errors of a specified axis.

This function performs in sequence the following tasks:

- It sends a request to the drive to clear any drive faults that exists
- Then it resets the axis errors

NOTE The condition causing the axis error has to be corrected before calling this function. The axis error still remains until the error condition exists when this function is called.

See also transition 15 in the status machine of the CANopen protocol.




Figure 1-44: MC_ResetError

1.2.1.47.2 Arguments

1.2.1.48.3.1 Input

En	Description	Requests to reset the axis errors
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function)
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—

1.2.1.49.4.2 Output

OK	Description	Indicates the function has completed successfully
	Data type	BOOL


1.2.1.50.5 Example

1.2.1.51.6.1 Structured Text

```

//reset the axis and drive errors for Axis 1
MC_ResetError( Axis1 );
  
```

1.2.1.52.7.2 Ladder Diagram



1.2.1.53 MC_Stop

1.2.1.54.1 Description

This function block aborts the active move, removes the next move from the queue, performs a controlled stop at the specified deceleration rate, and switches the axis to Stopping state.

MC_Stop cannot be aborted. This means that, while in Stopping state, no function block can command any motion on the axis. The axis remains in Stopping state until it reaches zero velocity and the Execute input is low. The application program can hold the axis in Stopping state even after it reaches zero velocity by leaving the Execute input high.





Figure 1-45: MC_Stop

1.2.1.55.2 Time Diagram

The example below shows the behavior of the combination of a MC_Stop FB with a MC_MoveVelocity FB.

- A rotating axis is ramped down with FB2 MC_Stop
 - The axis rejects motion commands as long as MC_Stop parameter “Execute” = TRUE
- FB1 MC_MoveVelocity reports an error indicating the busy MC_Stop command.



1.2.1.56.3 Arguments

1.2.1.57.4.1 Input

Execute	Description	Requests to stop the axis. It can be held high to prevent any other moves from being queued
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function.
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—
Deceleration	Description	Trapezoidal: Deceleration rate S-curve: Maximum deceleration
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²

Jerk	Default	—
	Description	Trapezoidal: 0 S-curve: Constant jerk
	Data type	LREAL
	Range	—
	Unit	User unit/sec ³
	Default	—
1.2.1.58.5.2 Output		
Done	Description	Indicates the axis has reached zero velocity AND the Execute input is low
	Data type	BOOL
Busy	Description	High from the time the Execute input goes high until the axis reaches zero velocity AND the Execute input is low
	Data type	BOOL
Active	Description	High from the time the MC_Stop move becomes the active move, until the axis reaches zero velocity AND the Execute input is low
	Data type	BOOL
Error	Description	Indicates an invalid input was specified
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT

1.2.1.59.6 Example

1.2.1.60.7.1 Structured Text

```
(* MC_Stop ST example *)

Inst_MC_Stop( StopRequest , Axis1, 100.0, 100.0 ); //Inst_MC_
Stop is an instance of MC_Stop function block


StopComplete := Inst_MC_Stop.Done;           //store the Done output
into a user defined variable

StopActive := Inst_MC_Stop.Active;          //store the Active out-
put into a user defined variable

StopError := Inst_MC_Stop.Error;            //store the Error output
into a user defined variable
```

1.2.1.61.8.2 Ladder Diagram

Put Axis 1 into Stopping Mode



1.2.2 I/O

1.2.2.1 MC_AbortTrigger (Function Block)

1.2.2.2.1 Description

When the Execute input transitions from low to high, this function block aborts an MC_TouchProbe function block.

1.2.2.3.2 Arguments

1.2.2.4.3.1 Input

Execute	Description	Enables execution
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Axis	Description	Specifies the axis that was specified in the MC_TouchProbe function block which is to be aborted
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—

TriggerInput	Description	Specifies the Fast Input that was specified in the MC_TouchProbe function block which is to be aborted. The elements of TriggerInput are as follows:
	INT TriggerInput.InputID	0 = Capture Engine 0 1 = Capture Engine 1 Range is [0,1] For information on configuring the capture engines, refer to AKD Capture Engine Configuration.
	INT TriggerInput.Direction	1 = rising edge 2 = falling edge Range is [1,2]
	INT TriggerInput.TrigID	is the axis number of the input. 0 indicates that the trigger axis is to be the same as Axis.AXIS_NUM. Range is [0,256]
	Data type	TRIGGER_REF
	Range	See Description above
	Unit	n/a
	Default	—

1.2.2.5.4.2 Output

Done	Description	Function block has completed
	Data type	BOOL
Busy	Description	Indicates the function block is currently executing
	Data type	BOOL
Error	Description	Indicates the function block did not complete due to an error. The ErrorID output indicates the type of error when this output is high
	Data type	BOOL

ErrorID	Description	When the Error output is high, this output indicates the type of error. When the Error output is low, this output is undefined
	Data type	INT

1.2.2.6.5 Usage

This function block is used to abort an MC_TouchProbe function block.

1.2.2.7.6 Related Functions

MC_TouchProbe

1.2.2.8.7 Example

1.2.2.9.8.1 Structured Text

```
(* MC_AbortTrigger ST example *)
Inst_MC_AbortTrigger( AbortReq, Axis1, TriggerInputRef );
//Inst_MC_AbortTrigger is an instance of MC_AbortTrigger
```

1.2.2.10.9.2 Ladder Diagram



1.2.2.11 MC_TouchProbe (Function Block)

1.2.2.12.1 Description


This function block arms a Fast Input and returns the latched position when the Fast Input event occurs. This function block causes no motion.

When the Execute input transitions from low to high, the control requests the drive to arm its Fast Input to latch the axis position when a Fast Input occurs. The Axis input specifies which axis's position to latch and the TriggerInput input specifies which Fast Input to use and whether to trigger on the rising or falling edge of the Fast Input. When the Fast Input event occurs, the drive latches the axis's position. This function block then returns the latched position at the RecordedPosition output and set the Done output high. This process can be canceled with the AbortTrigger function block.

If the WindowOnly input is high, the FirstPosition input and the LastPosition input define a window in which a Fast Input is accepted. Any Fast Input events that occur outside the window is ignored.


If First Position <= LastPosition, the window in which a Fast Input is accepted is:

FastInputPosition >= FirstPosition AND FastInputPosition <= LastPosition.



If First Position > LastPosition, the window in which a Fast Input is accepted is:

FastInputPosition >= FirstPosition OR FastInputPosition <= LastPosition.



The following figure shows the ladder diagram view of the MC_TouchProbe function block:




Figure 1-46: MC_TouchProbe

1.2.2.13.2 Arguments

1.2.2.14.3.1 Input

Execute	Description	Enables execution
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—

Axis	Description	Selects the axis for which the position is latched
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—
TriggerInput	Description	Selects the axis which contains the specified input to be armed. The elements of TriggerInput are as follows:
		INT TriggerInput.InputID 0 = Capture Engine 0 1 = Capture Engine 1 Range is [0,1] For information on configuring the capture engines, refer to AKD Capture Engine Configuration.
		INT TriggerInput.Direction 1 = rising edge 2 = falling edge Range is [1,2]
		INT TriggerInput.TrigID is the axis number of the input. 0 indicates that the trigger axis is to be the same as Axis.AXIS_NUM. Range is [0,256]
WindowOnly	Data type	TRIGGER_REF
	Range	See Description above
	Unit	n/a
	Default	—
	Description	Enables a position latching window. When this input is set, a window is defined by the FirstPosition and LastPosition inputs. Any Fast Input event that occurs outside the window is ignored. The first Fast Input event that occurs within the window latches the axis position
	Data type	BOOL
	Range	—
	Unit	n/a
	Default	—

FirstPosition	Description	See the function block Description above for an explanation of how this input and the LastPosition input define the window. This input is only applicable when the WindowOnly input is high. If the WindowOnly input is low, this input is ignored
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
LastPosition	Description	See the function block Description above for an explanation of how this input and the FirstPosition input define the window. This input is only applicable when the WindowOnly input is high. If the WindowOnly input is low, this input is ignored
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—

1.2.2.15.4.2 Output

Done	Description	Function block has completed and the RecordedPosition output is valid
Busy	Data type	BOOL
	Description	Indicates that the specified input is arming or is armed, and waiting for the trigger and recording of the position to occur
CommandAborted	Data type	BOOL
	Description	A TriggerAbort function block has executed and canceled this function
Error	Data type	BOOL
	Description	The function block has not completed successfully due to an error. The ErrorID output indicates the type of error
ErrorID	Data type	BOOL
	Description	When the Error output is high, this output indicates the type of error. When the Error output is low, this output is undefined
	Data type	INT

RecordedPosition	Description	When the Done output goes high, this output returns the latched position. When the Done output is low, this output is undefined
	Data type	LREAL
	Unit	User unit

1.2.2.16.5 Usage

This function block can be used to:

- Perform registration
- Determine the position of a product
- Measure product length

1.2.2.17.6 Related Functions

MC_AbortTrigger

1.2.2.18.7 Example


1.2.2.19.8.1 Structured Text

```
(* MC_TouchProbe ST example *)

TriggerInputRef.InputID := 1; //configure InputID
TriggerInputRef.Direction := 1; //configure Direction
TriggerInputRef.TrigID := 0; //configure TrigID
Inst_MC_TouchProbe( ArmProbe, Axis1, TriggerInputRef, FALSE, 0.0,
0.0 );
//Inst_MC_TouchProbe is an instance of MC_TouchProbe function
block

ProbeIsDone := Inst_MC_TouchProbe.Done; //store Done output into
a user defined variable

ProbeValue := Inst_MC_TouchProbe.RecordedPosition; //store
RecordedPosition output into a user defined variable
```

1.2.2.20.9.2 Ladder Diagram1.2.3 Info1.2.3.1 MC_ReadActPos1.2.3.2.1 Description

The MC_ReadActPos function block reads the actual position of the axis.

MC_ReadActPos	
Enable Axis	Valid Busy Error ErrorID Position

Figure 1-47: MC_ReadActPos

1.2.3.3.2 Arguments1.2.3.4.3.1 Input

Enable	Description	Request to read the axis's actual position Keeps continuously to read the actual position every PLC cycle, as long as the Enable remains high
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function.)
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—

1.2.3.5.4.2 Output

Valid	Description	Indicates the value at the Position output is available
	Data type	BOOL
Busy	Description	Indicates this function block is executing
	Data type	BOOL
Error	Description	Indicates an invalid input
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE.
	Data type	INT
Position	Description	Actual position of the axis.
	Unit	User unit
	Data type	LREAL

1.2.3.6.5 Example1.2.3.7.6.1 Structured Text

```
(* MC_ReadActPos ST example *)
Inst_MC_ReadActPos( TRUE, Axis1 );
//Inst_MC_ReadActPos is an instance of MC_ReadActPos function
block

ActualPos := Inst_MC_ReadActPos.Position;
//store Position output into a user defined variable
```

1.2.3.8.7.2 Ladder Diagram

Get the Axis 1 actual position for the Control Panel to display

1.2.3.9 MC_ReadActVel1.2.3.10.1 Description

The MC_ReadActVel function block reads the actual velocity of the axis.

MC_ReadActVel	
Enable	Valid
Axis	Busy
	Error
	ErrorID
	ActualVelocity

Figure 1-48: MC_ReadActVel**1.2.3.11.2 Arguments****1.2.3.12.3.1 Input**

Enable	Description	Requests to read the axis's actual velocity
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function.
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—

1.2.3.13.4.2 Output

Valid	Description	Indicates the value at the ActualVelocity output is available
	Data type	BOOL
Busy	Description	Indicates this function block is executing
	Data type	BOOL
Error	Description	Indicates an invalid input
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE.
	Data type	INT
ActualVelocity	Description	Actual velocity of the axis.

NOTE

Oscillations may be seen due to this being an instant velocity, not an average velocity.

Unit	User unit/sec
Data type	LREAL


1.2.3.14.5 Example**1.2.3.15.6.1 Structured Text**

```
* MC_ReadActVel ST example *);
Inst_MC_ReadActVel( TRUE, Axis1 ); //Inst_MC_ReadActVel is an
instance of MC_ReadActVel function block

ActualVel := Inst_MC_ReadActVel.ActualVelocity; // store Actual-
alVelocity output into a user defined variable
```

1.2.3.16.7.2 Ladder Diagram

Read Axis 1 actual velocity

**1.2.3.17 MC_ReadAxisErr****1.2.3.18.1 Description**

The Function Block MC_ReadAxisErr returns the error status of the specified axis.




Figure 1-49: MC_ReadAxisErr

1.2.3.19.2 Arguments**1.2.3.20.3.1 Input**

Enable	Description	requests to read the error status of the axis
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—

Axis	Description	Name of a declared instance of the AXIS_REF library function.
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—

1.2.3.21.4.2 Output

Valid	Description	Indicates the AxisErrorID output is valid
	Data type	BOOL
Busy	Description	Indicates this function block is executing
	Data type	BOOL
Error	Description	Indicates an invalid input
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT
AxisErrorID	Description	Indicates the error status of the axis. Each bit indicates a specific error. Both emergency-stop (E-stop) and controlled-stop (C-stop) errors are indicated. The table below defines the bits of this output.
	Data type	INT

Hexadecimal	Decimal	Description
0000H	0	No Error
0001H	1	User-set E-stop via MC_EStop, E-stop
0002H	2	Loss of Feedback, E-stop
0004H	4	Drive Fault, E-stop
0008H	8	Drive Communication Failure, E-stop
0400H	1024	Synchronization Error, C-stop




Multiple errors can be active at the same time. For example, if a User-set E-stop and an Excess Position Error E-stop are both active, the value would be 00000011H (17 decimal).

1.2.3.22.5 Example**1.2.3.23.6.1 Structured Text**

```
(* MC_ReadAxisErr ST example *)

Inst_MC_ReadAxisErr( TRUE, Axis1 );
//Inst_MC_ReadAxisErr is an instance of MC_ReadAxisErr function
block

AxisErrorBits := Inst_MC_ReadAxisErr.AxisErrorID; //AxisErrorID
contains the error bits
```

1.2.3.24.7.2 Ladder Diagram**Read Axis 1 error****1.2.3.25 MC_ReadBoolPar (Function Block)****1.2.3.26.1 Description**

MC_ReadBoolPar returns the value of the specified Boolean axis parameter.

MC_ReadBoolPar	
Enable	Valid
Axis	Busy
ParameterNumber	Error
	ErrorID
	Value

Figure 1-50: MC_ReadBoolPar

1.2.3.27.2 Arguments**1.2.3.28.3.1 Input**

Enable	Description	Requests to read the Boolean axis parameter
--------	-------------	---

	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function.)
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—
ParameterNumber	Description	Parameter number, see table in § "Motion Library (PLCopen)"
	Data type	INT
	Range	—
	Unit	n/a
	Default	—

1.2.3.29.4.2 Output

Valid	Description	Indicates the Value output is valid
	Data type	BOOL
Busy	Description	Indicates this function block is executing
	Data type	BOOL
Error	Description	Indicates an invalid input
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT
Value	Description	State of the Boolean parameter
	Data type	BOOL


1.2.3.30.5 Example

1.2.3.31.6.1 Structured Text

```
(* MC_ReadBoolPar ST example *)
Inst_MC_ReadBoolPar( EnableRead, Axis1, 3 );
//Inst_MC_ReadBoolPar is an instance of MC_ReadBoolPar function
block
BoolParm := Inst_MC_ReadBoolPar.Value; //store the Value output
into a user defined variable
```

1.2.3.32.7.2 Ladder Diagram

Read Axis 1 in-position state

**1.2.3.33 MC_ReadParam (Function Block)**1.2.3.34.1 Description

MC_ReadParam returns the value of the specified axis parameter.

MC_ReadParam	
Enable	Valid
Axis	Busy
ParameterNumber	Error
	ErrorID
	Value

Figure 1-51: MC_ReadParam

1.2.3.35.2 Arguments1.2.3.36.3.1 Input

Enable	Description	Requests to read the axis parameter
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function.)
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—
ParameterNumber	Description	Parameter number, see table in § "Axis Parameters"
	Data type	INT
	Range	—

Unit	n/a
Default	—

1.2.3.37.4.2 Output

Valid	Description	Indicates the Value output is valid
	Data type	BOOL
Busy	Description	Indicates this function block is executing
	Data type	BOOL
Error	Description	Indicates an invalid input
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT
Value	Description	Value of the parameter
	Data type	LREAL

1.2.3.38.5 Example1.2.3.39.6.1 Structured Text

```
(* MC_ReadParam ST example *)

ParameterNumber := 3; //configure the parameter to read


Inst_MC_ReadParam( EnableRead, Axis1, ParameterNumber );

//Inst_MC_ReadParam is an instance of MC_ReadParam function block

ParmVal := Inst_MC_ReadParam.Value; //store the Value output
into a user defined variable
```

1.2.3.40.7.2 Ladder Diagram

Read Axis 1 command position

**1.2.3.41 MC_ReadStatus**1.2.3.42.1 Description

The function block **MC_ReadStatus** returns the state of the specified axis.

MC_ReadStatus	
Enable	Valid
Axis	Busy
	Error
	ErrorID
	ErrorStop
	Disabled
	Stopping
	StandStill
	DiscreteMotion
	ContinuousMotion
	SynchonizedMotion
	Homing
	ConstantVelocity
	Accelerating
	Decelerating

Figure 1-52: MC_ReadStatus

1.2.3.43.2 Arguments1.2.3.44.3.1 Input

Enable	Description	Requests to read and return the axis status
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—

Axis	Description	Name of a declared instance of the AXIS_REF library function. click here...
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—

1.2.3.45.4.2 Output

Valid	Description	Indicates the outputs are valid
	Data type	BOOL
Busy	Description	Indicates this function block is executing
	Data type	BOOL
Error	Description	Indicates an invalid input
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT
ErrorStop	Description	Indicates Error Stop state – E-stop or C-stop
	Data type	BOOL
Disabled	Description	Indicates Disabled state – open loop and drive is disabled
	Data type	BOOL
Stopping	Description	Indicates Stopping state – MC_Stop command
	Data type	BOOL
StandStill	Description	Indicates Stand Still state – no move, closed loop, drive enabled
	Data type	BOOL
DiscreteMotion	Description	Indicates Discrete Motion state – programmed endpoint move is active
	Data type	BOOL
ContinuousMotion	Description	Indicates Continuous Motion state – unending, single-axis move is active
	Data type	BOOL
SynchronizedMotion	Description	Indicates Synchronized Motion state – slave move is active
	Data type	BOOL
Homing	Description	Indicates Homing state – a homing cycle is currently executing
	Data type	BOOL

ConstantVelocity	Description	Indicates the axis is moving at a constant velocity
	Data type	BOOL
Accelerating	Description	Indicates the axis is accelerating
	Data type	BOOL
Decelerating	Description	Indicates the axis is decelerating
	Data type	BOOL

1.2.3.46.5 Example

1.2.3.47.6.1 Structured Text

```
(* MC_ReadStatus ST example *)


Inst_MC_ReadStatus( EnableRead, Axis1 );

//Inst_MC_ReadStatus is an instance of MC_ReadStatus function
block

AxisStopping := Inst_MC_ReadStatus.Stopping; // store Stopping
output to a user defined variable

AxisAccelerating := Inst_MC_ReadStatus.Accelerating; // store
Accelerating output to a user defined variable
```

1.2.3.48.7.2 Ladder Diagram



1.2.3.49 MC_WriteBoolPar (Function Block)

1.2.3.50.1 Description

MC_WriteBoolPar writes the specified axis Boolean parameter.

1.2.3.51.2 Arguments**1.2.3.52.3.1 Input**

<code>Execute</code>	Description	Requests to write a Boolean axis parameter
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
<code>Axis</code>	Description	Name of a declared instance of the AXIS_REF library function.
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—
<code>ParameterNumber</code>	Description	Parameter number, see table in § "Motion Library (PLCopen)"
	Data type	INT
	Range	—
	Unit	n/a
	Default	—
<code>Value</code>	Description	State to write
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—

1.2.3.53.4.2 Output


<code>Done</code>	Description	Indicates the Boolean parameter has been written
	Data type	BOOL
<code>Busy</code>	Description	Indicates this function block is executing
	Data type	BOOL
<code>Error</code>	Description	Indicates an invalid input
	Data type	BOOL
<code>ErrorID</code>	Description	Indicates the error if Error output is set to TRUE
	Data type	INT

1.2.3.54.5 Example**1.2.3.55.6.1 Structured Text**

```
(* MC_WriteBoolPar ST example *)

WriteBool := TRUE; //value to write to the boolean parameter #1

Inst_MC_WriteBoolPar( WriteReq, Axis1, 1, WriteBool ); //Inst_
MC_WriteBoolPar is an instance of MC_WriteBoolPar
```

1.2.3.56.7.2 Ladder Diagram

Currently, MC_WriteBoolPar does not support any parameters (1050 is an arbitrary number chosen for example)

1.2.3.57 MC_WriteParam (Function Block)**1.2.3.58.1 Description**

MC_WriteParam writes the specified axis parameter.

1.2.3.59.2 Arguments**1.2.3.60.3.1 Input**

Execute	Description	Requests to write the axis parameter
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function.
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—

ParameterNumber	Description	Parameter number, see table in § "Motion Library (PLCopen)"
	Data type	INT
	Range	—
	Unit	n/a
	Default	—
Value	Description	Value to write
	Data type	LREAL
	Range	—
	Unit	n/a
	Default	—

1.2.3.61.4.2 Output

Done	Description	Indicates the parameter has been written
	Data type	BOOL
Busy	Description	Indicates this function block is executing
	Data type	BOOL
Error	Description	Indicates an invalid input
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT

1.2.3.62.5 Example

1.2.3.63.6.1 Structured Text


```
(* MC_WriteParam ST example *)

WriteValue := 1234.2; //value to write to parameter 1002

Inst_MC_WriteParam( WriteReq, Axis1, 1002, WriteValue); //Inst_
MC_WriteParam is an instance of MC_WriteParam
```

1.2.3.64.7.2 Ladder Diagram

Increment the master offset delta by 24

1.2.4 PLCopenMotion1.2.4.1 MC_Halt (Function Block)1.2.4.2.1 Description

This function block decelerates an axis to zero velocity. It is a queued single-axis move. The move is complete when the axis reaches zero velocity. It is typically used with Abort at the BufferMode input to terminate a move. To execute a stop that cannot be aborted, see MC_Stop.


MC_Halt	
Execute	Done
Axis	Busy
Deceleration	Active
Jerk	CommandAborted
BufferMode	Error
	ErrorID

Figure 1-53: MC_Halt1.2.4.3.2 Time Diagram

The example below shows the behavior in combination with a MC_MoveVelocity.

- A rotating axis is ramped down with FB2 MC_Halt
- Another motion command overrides the MC_Halt command

MC_Halt allows this, in contrast to MC_Stop. The axis can accelerate again without reaching standstill.



1.2.4.4.3 Arguments

1.2.4.5.4.1 Input

Execute	Description	Requests to queue the move
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—
Deceleration	Description	Trapezoidal: Deceleration rate S-curve: Maximum deceleration
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Jerk	Description	Trapezoidal: 0 S-curve: Constant jerk

	Data type	LREAL
	Range	—
	Unit	User unit/sec ³
	Default	—
BufferMode	Description	0 = abort 1 = buffer 2 = blend to active 3 = blend to next 4 = blend to low velocity 5 = blend to high velocity
	Data type	SINT
	Range	[0,5]
	Unit	n/a
	Default	—

1.2.4.6.5.2 Output

Done	Description	Indicates the move completed successfully. The Command Position has reached the endpoint.
Busy	Description	High from the moment the Execute input is one-shot to the time the move is ended
Active	Data type	BOOL
CommandAborted	Description	Indicates this move was aborted
	Data type	BOOL
Error	Description	Indicates an invalid input was specified or the move was terminated due to an error
ErrorID	Data type	BOOL
	Description	Indicates the error if Error output is set to TRUE
	Data type	INT

1.2.4.7.6 Example

1.2.4.8.7.1 Structured Text


```
(* MC_Halt ST example *)

Inst_MC_Halt( HaltReq, Axis1,100.0, 100.0, 0 );
//Inst_MC_Halt is an instance of MC_halt function block

HaltComplete := Inst_MC_Halt.Done; //store Done output into
user defined variable
```

1.2.4.9.8.2 Ladder Diagram


Stop both axes when the Run/Stop switch is set to Stop



1.2.4.10 MC_MoveAbsolute


1.2.4.11.1 Description


This function block performs a single-axis move to a specified endpoint position based on Axis, Position, Velocity, Acceleration, Deceleration, Jerk, and Direction parameters.

**Figure 1-54:** MC_MoveAbsolute**1.2.4.12.2 Time Diagram**

The following figure shows two examples of the combination of two absolute move Function Blocks:

- The left part of timing diagram illustrates the case if the Second Function Block is called **after** the First one. If First reaches the commanded position of 6000 (and the velocity is 0) then the output Done causes the Second FB to move to the position 10000
- The right part of the timing diagram illustrates the case if the Second move Function Block starts the execution **while** the First FB is still executing. In this case the First motion is interrupted and aborted by the Test signal during the constant velocity of the First FB. The Second FB moves directly to the position 10000 although the position of 6000 is not yet reached





1.2.4.13.3 Arguments

1.2.4.14.4.1 Input

	Execute	Description	Requests to queue the move
		Data type	BOOL
		Range	0, 1
		Unit	n/a
		Default	—
	Axis	Description	Name of a declared instance of the AXIS_REF library function
		Data type	AXIS_REF
		Range	[1,256]
		Unit	n/a
		Default	—
	Position	Description	Endpoint position. If Rollover Position is nonzero, this value must be in the range $0 \leqslant \text{Position} < \text{Rollover Position}$ When not in Rollover mode, the input accepts a 64-bit floating point value. When converted to feedback units, the range is $[-2^{51}, 2^{51}-1]$ feedback units.
		Data type	LREAL
		Range	[see Description]
		Unit	User unit

	Default	—
Velocity	Description	Velocity setpoint
	Data type	LREAL
	Range	—
	Unit	User unit/sec
	Default	—
Acceleration	Description	Trapezoidal: Acceleration rate S-curve: Maximum acceleration See also "Selection of Acceleration and Jerk Parameters for Function Blocks"
		 NOTE If Acceleration is not valid, ErrorID is set to 21
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Deceleration	Description	Trapezoidal: Deceleration rate S-curve: Unused
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Jerk	Description	Trapezoidal: 0 S-curve: Constant jerk See also "Selection of Acceleration and Jerk Parameters for Function Blocks"
		 NOTE If Jerk is not valid, ErrorID is set to 21
	Data type	LREAL
	Range	—
	Unit	User unit/sec ³
	Default	—

Direction	Description
	When Rollover Position is zero, a value of 0 must be specified. When Rollover Position is nonzero, a value of 1, 2, 3, or 4 must be specified.

Value	Description
0	no direction specification
1	positive direction. The axis travels in the positive direction to the endpoint
2	shortest distance. The axis travels in the direction that provides the shortest distance to the endpoint
3	negative direction. The axis travels in the negative direction to the endpoint
4	last direction. The axis travels to the endpoint in the same direction as its previous move

NOTE

If the Position input is the same as the axis's current position, then:

- when Direction = **2** (shortest distance), the axis does not move and the Done output goes high indicating that the move has been completed.
- when

		 NOTE	Direction = 1, 3, or 4, the axis travels in the specified direction, through one rollover cycle, and arrives back at the same position.
BufferMode		<p>Data type SINT Range [0,4] Unit n/a Default — Description 0 = abort 1 = buffer 2 = blend to active 3 = blend to next 4 = blend to low velocity 5 = blend to high velocity</p>	
		<p>Data type SINT Range [0,5] Unit n/a Default —</p>	

1.2.4.15.5.2 Output

Done	Description	Indicates the move completed successfully. The Command Position has reached the endpoint.
Busy	Data type Description	BOOL High from the moment the Execute input is one-shot to the time the move is ended
Active	Data type Description	BOOL Indicates this move is the active move
CommandAborted	Data type Description Data type	BOOL Indicates the move was aborted BOOL

Error	Description	Indicates an invalid input was specified or the move was terminated due to an error
ErrorID	Data type	BOOL
	Description	Indicates the error if Error output is set to TRUE
	Data type	INT

1.2.4.16.6 Example

1.2.4.17.7.1 Structured Text

```
(* MC_MoveAbsolute ST example *)

Inst_MC_MoveAbsolute( MovAbsReq, Axis1, 1234.567, 100.0, 100.0,
100.0, 0, 0, 0 ); //instance of MC_MoveAbsolute

MovAbsDone := Inst_MC_MoveAbsolute.Done; //store done output
into user defined variable

MovAbsBusy := Inst_MC_MoveAbsolute.Busy;

MovAbsActive := Inst_MC_MoveAbsolute.Active;


MovAbsAborted := Inst_MC_MoveAbsolute.CommandAborted;

MovAbsError := Inst_MC_MoveAbsolute.Error;

MovAbsErrID := Inst_MC_MoveAbsolute.ErrorID;
```

1.2.4.18.8.2 Ladder Diagram

Move Axis 1 to 1000



1.2.4.19 MC_MoveAdditive (Function Block)

1.2.4.20.1 Description

This function block performs a single-axis move for a specified distance from the endpoint of the previous move. It is typically used with Abort specified at the BufferMode input. If BufferMode is

not Abort, this move is identical to an MC_MoveRelative.


MC_MoveAdditive	
Execute	Done
Axis	Busy
Distance	Active
Velocity	CommandAborted
Acceleration	Error
Deceleration	ErrorID
Jerk	
BufferMode	


Figure 1-55: MC_MoveAdditive

1.2.4.21.2 Time Diagram

The following figure shows two examples of the combination of two Function Blocks while the axis is in Discrete Motion state:

- The left part of timing diagram illustrates the case if the Second Function Block is called **after** the First one. If First reaches the commanded distance 6000 (and the velocity is 0) then the output **Done** causes the Second FB to move to the distance 10000
- The right part of the timing diagram illustrates the case if the Second move Function Blocks starts the execution **while** the First FB is still executing. In this case the First motion is interrupted and aborted by the Test signal during the constant velocity of the First FB. The Second FB **adds on the previous commanded position** of 6000 the distance 4000 and moves the axis to the resulting position of 10000





1.2.4.22.3 Arguments

1.2.4.23.4.1 Input

Execute	Description	Requests to queue the move
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function.)
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—
Distance	Description	Distance to add to the endpoint of the previous move
	Data type	REAL
	Range	—
	Unit	User unit
	Default	—
Velocity	Description	Velocity setpoint
	Data type	LREAL
	Range	—
	Unit	User unit/sec
	Default	—

Acceleration	Description	Trapezoidal: Acceleration rate S-curve: Maximum acceleration
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Deceleration	Description	Trapezoidal: Deceleration rate S-curve: Unused
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Jerk	Description	Trapezoidal: 0 S-curve: Constant jerk
	Data type	LREAL
	Range	—
	Unit	User unit/sec ³
	Default	—
BufferMode	Description	0 = abort 1 = buffer 2 = blend to active 3 = blend to next 4 = blend to low velocity 5 = blend to high velocity
	Data type	SINT
	Range	[0,5]
	Unit	n/a
	Default	—

1.2.4.24.5.2 Output

Done	Description	Indicates the move completed successfully. The Command Position has reached the endpoint.
	Data type	BOOL
Busy	Description	High from the moment the Execute input is one-shot to the time the move is ended
	Data type	BOOL
Active	Description	Indicates this move is the active move
	Data type	BOOL
CommandAborted	Description	Indicates the move was aborted
	Data type	BOOL

Error	Description	Indicates an invalid input was specified or the move was terminated due to an error
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT

1.2.4.25.6 Example

1.2.4.26.7.1 Structured Text


```
(* MC_MoveAdditive ST example *) //Inst_MC_MoveAdditive is an
instance of MC_MoveAdditive function block

Inst_MC_MoveAdditive( MovAddReq, Axis1, 123.456, 100.0, 100.0,
100.0, 0, 0 );

MovAddDone := Inst_MC_MoveAdditive.Done; //store Done output
into user defined variable
```

1.2.4.27.8.2 Ladder Diagram


Move Axis 1 an additive distance of 300



1.2.4.28 MC_MoveRelative


1.2.4.29.1 Description


This function block executes a single-axis move for a specified distance to perform incremental motion.

**Figure 1-56:** MC_MoveRelative**1.2.4.30.2 Time Diagram**

The following figure shows the example of the combination of two relative move Function Blocks:

- The left part of timing diagram illustrates the case if the Second Function Block is called **after** the First one. If First reaches the commanded distance 6000 (and the velocity is 0) then the output **Done** causes the Second FB to move to the distance 10000
- The right part of the timing diagram illustrates the case if the Second move Function Blocks starts the execution **while** the First FB is still executing. In this case the First motion is interrupted and aborted by the Test signal during the constant velocity of the First FB. The Second FB **adds on the actual position** of 3250 the distance 4000 and moves the axis to the resulting position of 7250





1.2.4.31.3 Arguments

1.2.4.32.4.1 Input

Execute	Description	Requests to queue the move
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function.
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—

Distance	Description	Distance
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
Velocity	Description	Velocity setpoint
	Data type	LREAL
	Range	—
	Unit	User unit/sec
	Default	—
Acceleration	Description	Trapezoidal: Acceleration rate S-curve: Maximum acceleration
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Deceleration	Description	Trapezoidal: Deceleration rate S-curve: Unused
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Jerk	Description	Trapezoidal: 0 S-curve: Constant jerk
	Data type	LREAL
	Range	—
	Unit	User unit/sec ³
	Default	—
BufferMode	Description	0 = abort 1 = buffer 2 = blend to active 3 = blend to next 4 = blend to low velocity 5 = blend to high velocity
	Data type	SINT
	Range	[0,5]
	Unit	n/a
	Default	—

1.2.4.33.5.2 Output

Done	Description	Indicates the move completed successfully. The Command Position has reached the endpoint.
Busy	Data type	BOOL
Active	Description	High from the moment the Execute input is one-shot to the time the move is ended
	Data type	BOOL
CommandAborted	Description	Indicates this move is the active move
	Data type	BOOL
Error	Description	Indicates an invalid input was specified or the move was terminated due to an error
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT

1.2.4.34.6 Example1.2.4.35.7.1 Structured Text


```
(* MC_MoveRelative ST example *)

Inst_MC_MoveRelative( MovRelReq, Axis1, 10.0, 200.0, 150.0,
150.0, 0, 0 );

MovRelDone := Inst_MC_MoveRelative.Done; //store Done output
into user defined variable
```

See also how this function is used in the Hole punch project here

1.2.4.36.8.2 Ladder Diagram



1.2.4.37 MC_MoveSuperimp (Function Block)


1.2.4.38.1 Description


This function block performs a relative single-axis move which is superimposed upon the active move. Superimposed moves have their own Profile Generator and queue. Superimposed moves can be aborted by and blended with other superimposed moves. The distance of the superimposed move is an addition to the existing motion.

MC_MoveSuperimp	
Execute	Done
Axis	Busy
Distance	Active
VelocityDiff	CommandAborted
Acceleration	Error
Deceleration	ErrorID
Jerk	
BufferMode	

Figure 1-57: MC_MoveSuperimp

1.2.4.39.2 Time Diagram



***Note***

1. The CommandAborted is not visible here, because the new command works on the same instance
2. The end position is between 7000 and 8000, depending on the timing of the aborting of the second command set for the MC_MoveSuperimposed

1.2.4.40.3 Arguments**1.2.4.41.4.1 Input**

Execute	Description	Requests to queue the superimposed move
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function.
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—
Distance	Description	Distance

	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
Velocity	Description	Velocity rate
	Data type	LREAL
	Range	—
	Unit	User unit/sec
	Default	—
Acceleration	Description	Trapezoidal: Acceleration rate S-curve: Maximum acceleration
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Deceleration	Description	Trapezoidal: Deceleration rate S-curve: Unused
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Jerk	Description	Trapezoidal: 0 S-curve: Constant jerk
	Data type	LREAL
	Range	—
	Unit	User unit/sec ³
	Default	—
BufferMode	Description	0 = abort 1 = buffer 2 = blend to active 3 = blend to next 4 = blend to low velocity 5 = blend to high velocity
	Data type	SINT
	Range	[0,5]
	Unit	n/a
	Default	—

1.2.4.42.5.2 Output

Done	Description	Indicates the move completed successfully. The Command Position has reached the endpoint.
	Data type	BOOL

Busy	Description	High from the moment the Execute input is one-shot to the time the move is ended
	Data type	BOOL
Active	Description	Indicates this move is the active superimposed move
	Data type	BOOL
CommandAborted	Description	Indicates the move was aborted
	Data type	BOOL
Error	Description	Indicates an invalid input was specified or the move was terminated due to an error
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT

1.2.4.43.6 Example

1.2.4.44.7.1 Structured Text


```
(* MC_MoveSuperimp ST example *)

Inst_MC_MoveSuperimp( MovSupReq, Axis1, 123.555, 10.0, 100.0,
100.0, 0, 0 );

MovSupDone := Inst_MC_MoveSuperimp.Done; //store Done output
into user defined variable
```

1.2.4.45.8.2 Ladder Diagram

Move Axis 1 a superimposed distance of 500



1.2.4.46 MC_MoveVelocity (Function Block)

1.2.4.47.1 Description

This function block performs a single-axis non-ending move at a specified velocity. This type of move can be terminated with the MC_Halt function block or by aborting it with another move.





Figure 1-58: MC_MoveVelocity


1.2.4.48.2 Time Diagram

The example below shows the behavior of the combination of a MC_Stop FB with a MC_MoveVelocity FB.

- A rotating axis is ramped down with FB2 MC_Stop
- The axis rejects motion commands as long as MC_Stop parameter “Execute” = TRUE

FB1 MC_MoveVelocity reports an error indicating the busy MC_Stop command.





1.2.4.49.3 Arguments

1.2.4.50.4.1 Input

Execute	Description	Requests to queue the move
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—
Velocity	Description	Velocity rate
	Data type	LREAL
	Range	—
	Unit	User unit/sec
	Default	—
Acceleration	Description	Trapezoidal: Acceleration rate S-curve: Maximum acceleration
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Deceleration	Description	Trapezoidal: Deceleration rate S-curve: Unused
	Data type	LREAL
	Range	—

	Unit	User unit/sec ²
	Default	—
Jerk	Description	Trapezoidal: 0 S-curve: Constant jerk
	Data type	LREAL
	Range	—
	Unit	User unit/sec ³
	Default	—
Direction	Description	0 = positive direction 1 = negative direction
	Data type	SINT
	Range	[0,1]
	Unit	n/a
	Default	—
BufferMode	Description	0 = abort 1 = buffer 2 = blend to active 3 = blend to next 4 = blend to low velocity 5 = blend to high velocity
	Data type	SINT
	Range	[0,5]
	Unit	n/a
	Default	—

1.2.4.51.5.2 Output


InVelocity	Description	Indicates the command velocity has reached the programmed velocity
	Data type	BOOL
Busy	Description	High from the moment the Execute input is one-shot to the time the move is ended
	Data type	BOOL
Active	Description	Indicates this move is the active move
	Data type	BOOL
CommandAborted	Description	Indicates the move was aborted
	Data type	BOOL
Error	Description	Indicates an invalid input was specified or the move was terminated due to an error
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE

Data type INT

1.2.4.52.6 Example**1.2.4.53.7.1 Structured Text**

```
(* MC_MoveVelocity ST example *)

Inst_MC_MoveVelocity( MovVelReq , Axis1, 200.0, 100.0, 100.0, 0,
0, 0 );
```

1.2.4.54.8.2 Ladder Diagram**1.2.4.55 MC_SetOverride (Function Block)****1.2.4.56.1 Description**

This function block writes the velocity override factor. A change in the velocity override factor takes effect immediately on the active move.

The velocity override factor is applied to the programmed velocity to determine the command velocity:

$$\text{command velocity} = \text{programmed velocity} * \text{VelFactor}$$




Figure 1-59: MC_SetOverride

1.2.4.57.2 Arguments**1.2.4.58.3.1 Input**

Enable	Description	Request to write the override factors
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function.
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—
VelFactor	Description	Velocity override factor
	Data type	REAL
	Range	[0.0, 2.0]
	Unit	n/a
	Default	—

1.2.4.59.4.2 Output


Enabled	Description	Indicates the override values have been written
	Data type	BOOL
Busy	Description	Indicates the function block is executing
	Data type	BOOL
Error	Description	Indicates an invalid input is specified
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT

1.2.4.60.5 Example**1.2.4.61.6.1 Structured Text**

```
(* MC_SetOverride ST example *)

VelFactor := 1.25 ; //set the velocity factor to 1.25 (125%)
Inst_MC_SetOverride( TRUE , Axis1, VelFactor );
// Inst_MC_Setoverride is an instance of MC_SetOverride
```

1.2.4.62.7.2 Ladder Diagram



1.2.5 Profile

1.2.5.1 MC_CamIn

1.2.5.2.1 Description

This function block performs a slave axis move which follows the master axis based on the Cam Table specified by CamTableID.

This function block is used to either initiate a new MC_CamIn move or to resume a previously programmed MC_CamIn move. Refer to MC_CamStartPos and MC_CamResumePos for information on positioning the slave axis prior to calling MC_CamIn.

Add an image!

Figure 1-60: MC_CamIn

1.2.5.3.2 Arguments

1.2.5.4.3.1 Input

Execute	Description	Requests to queue the CamIn move
	Data type	BOOL
	Range	0, 1
	Unit	n/a
Master	Description	Name of a declared instance of the AXIS_REF library function
	Data type	AXIS_REF
	Range	1 - 256
	Unit	n/a
Slave	Description	AXIS_REF.AXIS_NUM is the slave axis number
	Data type	AXIS_REF
	Range	1-256
	Unit	n/a
MasterOffset	Description	Profile shift along the master axis. This input is not used if the StartMode input is set to 1 for Resume Mode.
	Data type	LREAL

	Range	—
	Unit	User unit
SlaveOffset	Description	Profile shift along the slave axis. This input is not used if the StartMode input is set to 1 for Resume Mode.
	Data type	LREAL
	Range	—
	Unit	User unit
MasterScaling	Description	Master axis profile range. This input is not used if the StartMode input is set to 1 for Resume Mode.
	Data type	LREAL
	Range	—
	Unit	User unit
SlaveScaling	Description	Slave axis profile range. This input is not used if the StartMode input is set to 1 for Resume Mode.
	Data type	LREAL
	Range	—
	Unit	User unit
Startmode	Description	<p>Starting mode of the cam profile. 0 = Start Mode. Start a cam profile move. 1 = Resume Mode. Resume the most recent MC_CamIn move.</p> <p>This input indicates whether the axis should start a MC_CamIn move as an initial cam start (StartMode = 0) or if the axis should resume the most recently programmed MC_CamIn move (StartMode = 1).</p> <p>It should be noted that in the case of Resume Mode (StartMode = 1) that the inputs MasterOffset, SlaveOffset, MasterScaling, and SlaveScaling are not used. The function block will use the values that were in effect during the most recently programmed MC_CamIn move for the slave axis.</p>
	Data type	INT
	Range	[0, 1]
	Unit	n/a

CamTableID	Description	ID number of the profile to be used with MC_CamIn
	Data type	INT
	Range	—
	Unit	n/a
BufferMode	Description	Buffer mode for CamIn block.
	Data type	SINT
	Range	0-5
	Unit	n/a

1.2.5.5.4.2 Output

InSync	Description	Indicates the slave axis is in sync with the profile
	Data type	BOOL
	Range	0, 1
	Unit	n/a
Busy	Description	Indicates this function block is executing
	Data type	BOOL
	Range	0, 1
	Unit	n/a
Active	Description	Indicates this move is the Active move
	Data type	BOOL
	Range	0, 1
	Unit	n/a
CommandAborted	Description	Indicates the move was aborted
	Data type	BOOL
	Range	0, 1
	Unit	n/a
Error	Description	Indicates an invalid input, or the move was terminated due to an error
	Data type	BOOL
	Range	0, 1
	Unit	n/a
ErrorID	Description	Indicates the error if the Error output is high.
	Data type	INT
	Range	—
	Unit	n/a

EndOfProfile	Description	Indicates the end of profile has been reached. If the profile is periodic this output is set to ON for one ladder scan. If the profile is not periodic, the output remains ON while outside the range of the profile.
	Data type	BOOL
	Range	0, 1
	Unit	n/a

1.2.5.6.5 Usage

The slave axis immediately locks on to the Cam Table profile.

The **Master Offset** is used to shift the profile along the master axis.

The **Master Scaling** defines the range of the profile along the master axis.

The **Slave Offset** is used to shift the profile along the Slave axis.

The **Slave Scaling** defines the range of the profile along the slave axis.

If the profile is periodic, when the end of profile reached, the profile continues at the start of the profile. The EndOfProfile output is ON for 1 ladder scan.

If the profile is not periodic, when the end of profile is reached, the slave axis stops and remains at the end of the profile until the master axis returns to within the profile range as defined by MasterScaling. The EndOfProfile output remains ON anytime the master axis is outside of the profile range.

Adjustments computation is done as follows:

When cam is first started, offsets are adjusted if necessary

- If slave is not absolute, then slave offset = slave offset + starting position
- If master is not absolute, then master offset = master offset + starting position.

At run-time

- Master position for profile = master position - master offset
- Use master position for profile table to obtain slave profile position
- Slave commanded position = slave profile position + slave offset

1.2.5.7.6 Related Functions

MC_CamResumePos

MC_CamStartPos

MC_CamTblSelect

MC_CamOut


1.2.5.8.7 Examples

1.2.5.9.8.1 Structured Text

```
(* MC_CamIn ST example *) //Inst_MC_CamIn is an instance of MC_CamIn
Inst_MC_CamIn( CamStartBool, Axis1, Axis2, 0.0, 0.0, 360.0, 360.0, 0,
```

```
CamTableID, 0 );
```

1.2.5.10.9.2 Ladder Diagram



The three following examples utilizes the screen shot below showing the cam profile "MyProfile"




Figure 1-61: MC_CamIn examples


1.2.5.11.10.3 Example 1

Profile	MyProfile
Cycle	NO
MasterAbsolute	YES
SlaveAbsolute	YES
MasterOffset	0.0
SlaveOffset	0.0
MasterScaling	360.0
SlaveScaling	360.0

Initial Master position	0.0
Initial Slave position	180.0

After `MC_CamTblSelect` and `MC_CamIn` are programmed with the above parameters, the slave axis is locked on to the profile. Since both have zero offsets, the profile is not shifted in either axis. The initial condition of the master axis at position 0, yields a slave command position of 180.0. As the master axis moves positive, the slave position follows the profile. When the master position is at 90.0, the slave is commanded to 324.0 (see curve below where in = 90, out = 324). The slave follows the profile as the master axis moves until the master axis reaches a position of 360.0. At this time the slave is commanded to 180.0.

If the master were to continue to move past 360.0 the slave commanded position would remain at 180.0 since the Cyclic input is false. If the master moves negative and its position returns to less than 360.0, then the slave follows the profile again.




1.2.5.12.11.4 Example 2

Profile	MyProfile
Cycle	YES
MasterAbsolute	NO
SlaveAbsolute	NO
MasterOffset	0.0
SlaveOffset	0.0
MasterScaling	360.0
SlaveScaling	360.0
Initial Master position	180
Initial Slave position	90.0

After `MC_CamTblSelect` and `MC_CamIn` are programmed with the above parameters, the slave axis is locked on to the profile. Since the both axes have zero offsets, the profile is not shifted in

either axis. Neither the *MasterAbsolute* nor *SlaveAbsolute* input is on, so the profile is relative to the axes initial positions. Specifically, the initial condition of the master axis at position 180 would represent a master profile position of 0 (180-180). This yields a slave command position of 270 (180 + 90). As the master axis moves positive, the slave position follows the profile. When the master position is at 270, the slave is commanded to 414.0 (324 + 90). The slave follows the profile as the master axis moves until the master axis reaches a position of 540. At this time the slave is commanded to 270.0 (180 + 90).

If the master continues to move past 540.0, the slave commanded position follows the profile from the beginning since the Cyclic input is TRUE. When the master reaches a position of 630, the slave is commanded to a position of 414.0 (324 + 90).



1.2.5.13.12.5 Example 3


Profile	MyProfile
Cycle	NO
MasterAbsolute	YES
SlaveAbsolute	YES
MasterOffset	90
SlaveOffset	-180
MasterScaling	360.0
SlaveScaling	360.0
Initial Master position	180
Initial Slave position	144

After `MC_CamTblSelect` and `MC_CamIn` are programmed with the above parameters, the slave axis is locked on to the profile. Since the both axes have offsets, the profile is shifted along both

axes. Specifically the master axis is shifted 90, and the slave axis is shifted -180. Initially the master axis position of 180 yields a master position for the profile calculation of 90 (master position 180 - Master offset 90), which yields a slave command position of 144 (slave profile command 324 + slave offset (-180)). As the master axis moves positive, the slave position follows the profile. When the master axis position is at 270, the master position for profile calculation is 180 (270 - 90). This yields a slave command position of 0 (180 + (-180)).

The slave follows the profile as the master axis moves until the master axis reaches a position of 450. The master axis position of 450 yields a master position for profile calculation of 360 (450 - 90). The slave command position is 0 (180 + (-180)).

When the master reaches a position of 450, the slave commanded position remains at 0 since the Cyclic input is false.



1.2.5.14 MC_CamOut

1.2.5.15.1 Description

This function block:

- aborts the active MC_CamIn move
- disengages the axis from its master
- and commands the axis to continue at its current velocity

Like a MC_MoveVelocity move, the control continues to command the axis to move at this velocity until this MC_CamOut move is aborted. If this function block is called and the active move is not a MC_CamIn move, this function block returns an error and the active move is not aborted.

MC_CamOut	
Execute	Done
Slave	Busy
Acceleration	Active
Deceleration	CommandAborted
Jerk	Error
	ErrorID

Figure 1-62: MC_CamOut**1.2.5.16.2 Arguments****1.2.5.17.3.1 Input**

Execute	Description	Requests to queue the CamOut move
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Slave	Description	Name of a declared instance of the AXIS_REF library function
	Data type	AXIS_REF
	Range	1 – 256
	Unit	n/a
	Default	—
Acceleration	Description	Trapezoidal: Acceleration rate S-curve: Maximum acceleration
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Deceleration	Description	Trapezoidal: Deceleration rate S-curve: Unused
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—

Jerk	Description	Trapezoidal: 0 S-curve: Constant jerk
	Data type	LREAL
	Range	—
	Unit	User unit/sec ³

1.2.5.18.4.2 Output

Done	Description	Indicates the axis is disengaged from its master
	Data type	BOOL
	Range	0, 1
	Unit	n/a
Busy	Description	Indicates this function block is executing
	Data type	BOOL
	Range	0, 1
	Unit	n/a
Active	Description	Indicates this move is the Active move
	Data type	BOOL
	Range	0, 1
	Unit	n/a
CommandAborted	Description	Indicates the move was aborted
	Data type	BOOL
	Range	0, 1
	Unit	n/a
Error	Description	Indicates an invalid input was specified or no MC_CamIn move was active
	Data type	BOOL
	Range	0, 1
	Unit	n/a
ErrorID	Description	Indicates the error if the Error output is high
	Data type	INT
	Range	—
	Unit	n/a

1.2.5.19.5 Usage

This function block disengages the slave axis from a MC_CamIn move and then leaves the axis running at its current velocity. The axis continues to run at this velocity until this move is aborted.

1.2.5.20.6 Related Functions

MC_CamIn

MC_CamTblSelect

1.2.5.21.7 Example


1.2.5.22.8.1 Structured Text

```
(* MC_CamOut ST example *)

Inst_MC_CamOut
(ExecCamOut1,Axis1,CamOut1Acc,CamOut1Dec,CamOut1Jerk);

//Inst_MC_CamOut is an instance of MC_CamOut
```

1.2.5.23.9.2 Ladder Diagram



See also MC_CamIn for examples.

1.2.5.24 MC_CamTblSelect

1.2.5.25.1 Description

This Function Block is defined to read and initialize the specified profile, returning an ID to be used with MC_CamIn function block.

1.2.5.26.2 Arguments

1.2.5.27.3.1 Input

Execute	Description	Requests to queue the slave gear ratio move
	Data type	BOOL
	Range	0, 1

	Unit	n/a
	Default	—
CamTable	Description	Profile name as defined in the CAM Profile Properties dialog
	Data type	STRING
	Range	—
	Unit	n/a
	Default	—
Periodic	Description	Selects if the profile is periodic (see also Usage section)
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
MasterAbsolute	Description	Selects if master profile is absolute or relative (see also Usage section)
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
SlaveAbsolute	Description	Selects if Slave profile is absolute or relative (see also Usage section)
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—

1.2.5.28.4.2 Output

Done	Description	Indicates the function block has completed successfully
	Data type	BOOL
	Range	0, 1
	Unit	n/a
Busy	Description	Indicates this function block is executing
	Data type	BOOL
	Range	0, 1
	Unit	n/a

Error	Description	Indicates an invalid input was specified
	Data type	BOOL
	Range	0, 1
	Unit	n/a
ErrorID	Description	Indicates the error if the Error output is high
	Data type	INT
	Range	—
	Unit	n/a
CamTableID	Description	Indicates the ID number of the profile to be used with MC_CamIn
	Data type	INT
	Range	0 - 255
	Unit	n/a

1.2.5.29.5 Usage

- Each positive transition of the **Enable** input will create a unique Cam ID and store the profile information in a table. The number of unique Cam IDs is limited to 256. If the application attempts to create more than 256 Cam IDs, the **Error** output will be true and the **ErrorID** output will be 22 (Too Many Profiles). It is only necessary to call MC_CamTblSelect once for each Profile/Periodic/MasterAbsolute/SlaveAbsolute configuration to be used.
- The **Periodic** input selects if the profile is to repeat each cycle. If the profile is not periodic and the master axis moves beyond the profile range, the slave stops at the end of the profile.



If the master axis moves back into the profile range, the slave resumes following the profile.

- If the **MasterAbsolute** input is ON, the profile is in reference to the Master axis position. If the MasterAbsolute input is OFF, the profile is in reference to the Master axis position at the time the MC_CamIn function block is executed.
- Similarly, the **SlaveAbsolute** input selects if the slave positions are in reference to the Slave axis position or the Slave axis position at the time the MC_CamIn function block is executed.



If the SlaveAbsolute input is set to TRUE, the axis jumps back to the starting position. If you set this input to FALSE, the axis will no longer jump back; but rather, as the profile repeats, the slave moves relative to the start of each period.

1.2.5.30.6 Related Functions

MC_CamIn

MC_CamOut

1.2.5.31.7 Example**1.2.5.32.8.1 Structured Text**

```
(* MC_CamTblSelect ST example *) //call this function block
every scan until "Done"


Inst_MC_CamTblSelect(DoSelect, 'Profileb', TRUE, TRUE, TRUE );
//Inst_MC_CamTblSelect is instance of MC_CamTblSelect

CamSelDone := Inst_MC_CamTblSelect.Done; //store Done output to
user defined variable

IF CamSelDone = TRUE THEN//when function block is "done" store
CamTableID := Inst_MC_CamTblSelect.CamTableID; //CamTableID in
user defined variable

END_IF;
```

See also how this function is used in the Hole punch project here

1.2.5.33.9.2 Ladder Diagram

See also MC_CamIn for examples.

1.2.5.34 MC_GearIn**1.2.5.35.1 Description**

This function block performs a slave axis move which follows the master axis based on the ratio specified by RatioNumerator and RatioDenominator.

```
SlaveCommandPosition = MasterActualPosition * RatioNumerator /
RatioDenominator
```

When this command is executed, the slave axis accelerates or decelerates (using the Acceleration, Deceleration, and Jerk) to the target velocity determined by the master axis velocity and the ratio. When the slave axis reaches a velocity within the “In Gear” bandwidth around the target velocity, it locks on to the master, and the InGear output goes high.

For example if the “In Gear” bandwidth is set to 0.1 User Units per second, the InGear output will turn on if the slave velocity is within +/- 0.1 User Units per second of the target velocity.

The slave axis then continues to follow the master axis until this move is aborted.

Time to Reach the Target Velocity

While following the master, gearing functions can generate large accelerations. If the gearing function is aborted while the axis is currently accelerating, and the aborting function block has small non-zero Jerk or small acceleration values, it can take a long time to reach the target velocity, or position of the aborting function block. If the Jerk and/or acceleration of the aborting function cannot be increased to suitable values, it may be desirable to:


- Abort the gearing function with an MC_GearOut with higher accelerations and/or Jerk values (or zero jerk value),
- Execute the next MC motion function block.

MC_GearIn	
Execute	InGear
Master	Busy
Slave	Active
RatioNumerator	CommandAborted
RatioDenominator	Error
Acceleration	ErrorID
Deceleration	
Jerk	
BufferMode	

Figure 1-63: MC_GearIn

1.2.5.36.2 Time Diagram

MC_GearIn	
Exe_1	Execute
MyMaster	Master
MySlave	Slave
1	RatioNumerator
1	RatioDenominator
10	Acceleration
10	Deceleration
0	Jerk
0	BufferMode
	InGear
	Busy
	Active
	CommandAborted
	Error
	ErrorID
	Abort_1
	Error_1



1.2.5.37.3 Arguments

1.2.5.38.4.1 Input

Execute	Description	Requests to queue the slave gear ratio move
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Master	Description	Name of a declared instance of the AXIS_REF library function
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—
Slave	Description	AXIS_REF.AXIS_NUM is the slave axis number
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—
RatioNumerator	Description	Numerator of master/slave ratio
	Data type	DINT
	Range	[-2147483648, 2147483647]
	Unit	n/a
	Default	—

RatioDenominator	Description	Denominator of master/slave ratio
	Data type	DINT
	Range	[-2147483648, 2147483647]
	Unit	n/a
	Default	—
Acceleration	Description	Trapezoidal: Acceleration rate S-curve: Maximum acceleration
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Deceleration	Description	Trapezoidal: Deceleration rate S-curve: Unused
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Jerk	Description	Trapezoidal: 0 S-curve: Constant jerk
	Data type	LREAL
	Range	—
	Unit	User unit/sec ³
	Default	—
BufferMode	Description	0 = abort 1 = buffer
	Data type	SINT
	Range	[0,1]
	Unit	n/a
	Default	—
Slave	Description	AXIS_REF.AXIS_NUM is the slave axis number
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—
RatioDenominator	Description	Denominator of master/slave ratio
	Data type	DINT
	Range	[-2147483648, 2147483647]

Unit	n/a
Default	—

1.2.5.39.5.2 Output

InGear	Description	Indicates the slave axis is locked on to the master axis
Busy	Data type	BOOL
Active	Description	High from the moment the Execute input goes high until the time the move is ended
CommandAborted	Data type	BOOL
Error	Description	Indicates this move is the Active move
ErrorID	Data type	BOOL
Active	Description	Indicates an invalid input was specified or the move was terminated due to an error
Active	Data type	BOOL
Active	Description	Indicates the error if Error output is set to TRUE
Active	Data type	INT
Active	Description	Indicates this move is the Active move
Active	Data type	BOOL


1.2.5.40.6 Example1.2.5.41.7.1 Structured Text

```
(* MC_GearIn ST example *)
Inst_MC_GearIn( GearInReq, Axis1, Axis2, 2, 1, 150.0, 150.
0, 0, 0 );
//Inst_MC_GearIn is an instance of MC_GearIn
```

See also how this function is used in the Hole punch project here

1.2.5.42.8.2 Ladder Diagram

When both axes are enabled, slave Axis 2 to Axis 1 at a 2:1 ratio



1.2.5.43 MC_GearInPos

1.2.5.44.1 Description

This function block performs a slave axis move which follows the master axis based on the ratio specified by RatioNumerator and RatioDenominator.

```

SlaveCommandPosition = MasterActualPosition *
RatioNumerator / RatioDenominator

```

This function block also allows the application to specify sync positions for the master and slave axes. It is the point in which the master and slave axes become engaged in synchronous motion. When the master axis reaches the MasterStartDistance from the MasterSyncPosition, the slave axis begins to accelerate to the target velocity determined by the master axis velocity and the ratio. The slave axis arrives at the target velocity and the SlaveSyncPosition at the same time the master axis arrives at the MasterSyncPosition. At that time, the slave is locked on to the master and follows the master at the ratio specified. The slave axis continues to follow the master axis until this move is aborted.

Time to Reach the Target Velocity


While following the master, gearing functions can generate large accelerations. If the gearing function is aborted while the axis is currently accelerating, and the aborting function block has small non-zero Jerk or small acceleration values, it can take a long time to reach the target velocity, or position of the aborting function block. If the Jerk and/or acceleration of the aborting function cannot be increased to suitable values, it may be desirable to:

- Abort the gearing function with an MC_GearOut with higher accelerations and/or Jerk values (or zero jerk value),
- Execute the next MC motion function block.

MC_GearInPos	
Execute	StartSync
Master	InSync
Slave	Busy
RatioNumerator	Active
RatioDenominator	CommandAborted
MasterSyncPosition	Error
SlaveSyncPosition	ErrorID
SyncMode	
MasterStartDistance	
BufferMode	

Figure 1-64: MC_GearInPos**1.2.5.45.2 Time Diagram**

MC_GearInPos		
Exe_1	Execute	StartSync
MyMaster	Master	InSync
MySlave	Slave	Busy
1	RatioNumerator	Active
1	RatioDenominator	CommandAborted
10	MasterSyncPosition	Error
10	SlaveSyncPosition	ErrorID
0	SyncMode	
0	MasterStartDistance	
1	BufferMode	



1.2.5.46.3 Arguments**1.2.5.47.4.1 Input**

Execute	Description	Requests to queue the slave gear ratio move
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Master	Description	Name of a declared instance of the AXIS_REF library function
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—
Slave	Description	AXIS_REF.AXIS_NUM is the slave axis number
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—
RatioNumerator	Description	Numerator of master/slave ratio
	Data type	DINT
	Range	[-2147483648, 2147483647]
	Unit	n/a
	Default	—
RatioDenominator	Description	Denominator of master/slave ratio
	Data type	DINT
	Range	[-2147483648, 2147483647]
	Unit	n/a
	Default	—
MasterSyncPosition	Description	Master axis sync position
	Data type	LREAL
	Range	—
	Unit	n/a
	Default	—
SlaveSyncPosition	Description	Slave axis sync position
	Data type	LREAL
	Range	—
	Unit	n/a
	Default	—
SyncMode	Description	for future enhancements

	Data type	INT
	Range	—
	Unit	n/a
	Default	—
MasterStartDistance	Description	When the master axis reaches this distance before MasterSyncPosition, the slave axis begins its lock-on process
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
BufferMode	Description	1 = buffer
	Data type	SINT
	Range	[1]
	Unit	n/a
	Default	—

1.2.5.48.5.2 Output

StartSync	Description	Indicates that the master axis has reached the MasterStartDistance from the MasterSyncPosition and the lock-on process has begun
	Data type	BOOL
InSync	Description	Indicated the slave axis is locked on to the master axis
	Data type	BOOL
Busy	Description	High from the moment the Execute input goes high until the time the move is ended
	Data type	BOOL
Active	Description	Indicates this move is the Active move
	Data type	BOOL

CommandAborted	Description	Indicates the move was aborted
		<p>NOTE If the abort arises because the inputs cause inconsistent motion, then this FB:</p> <ul style="list-style-type: none"> • performs no motion • sets an error flag • set the ErrorID to 13
Error	Data type	BOOL
ErrorID	Description	Indicates an invalid input was specified or the move was terminated due to an error
	Data type	BOOL
	Description	Indicates the error if Error output is set to TRUE
	Data type	INT

1.2.5.49.6 Example

1.2.5.50.7.1 Structured Text


```
(* MC_GearInPos ST example *)

Inst_MC_GearInPos( GearInPosReq, Axis1, Axis2, 2, 1, 0, 0, 0,
100.0, 0 );

//Inst_MC_GearInPos is instance of MC_GearInPos

GearInPosSync:= Inst_MC_GearInPos.InSync; //store InSync output
into user defined variable
```

1.2.5.51.8.2 Ladder Diagram



1.2.5.52 MC_GearOut

1.2.5.53.1 Description

This function block:

- aborts the active MC_GearIn or MC_GearInPos move,
- disengages the axis from its master,
- and commands the axis to continue at its current velocity.

Like a MC_MoveVelocity move, the control continues to command the axis to move at this velocity until this MC_GearOut move is aborted. The Acceleration, Deceleration and Jerk input parameters are applied if this command velocity is modified by the MC_SetOverride function block. If this function block is called and the active move is not a MC_GearIn or MC_GearInPos move, this function block returns an error and the active move is not aborted.



The MC_GearOut is done when the slave axis is disengaged from the master axis. Once done, the MC_GearOut will remain busy and active until it is aborted by a different motion function block. This is different behavior than most other motion function blocks. The MC_GearOut function block represents an exception to the exclusivity rule as the **Done** and **Active** outputs may be true at the same time.

MC_GearOut	
Execute	Done
Slave	Busy
Acceleration	Active
Deceleration	CommandAborted
Jerk	Error
	ErrorID

Figure 1-65: MC_GearOut**1.2.5.54.2 Arguments****1.2.5.55.3.1 Input**

Execute	Description	Requests to disengage the slave axis from a MC_GearIn or MC_GearInPos move
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Slave	Description	Name of a declared instance of the AXIS_REF library function
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—
Acceleration	Description	Trapezoidal: Acceleration rate S-curve: Maximum acceleration
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Deceleration	Description	Trapezoidal: Deceleration rate S-curve: Unused
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—

Jerk	Description	Trapezoidal: 0 S-curve: Constant jerk
	Data type	LREAL
	Range	—
	Unit	User unit/sec ³
	Default	—

1.2.5.56.4.2 Output

Done	Description	Indicates the axis is disengaged from its master
	Data type	BOOL
Busy	Description	Indicates the function is executing
	Data type	BOOL
Active	Description	Indicates this move is the Active move
	Data type	BOOL
CommandAborted	Description	Indicates the move was aborted
	Data type	BOOL
Error	Description	Indicates an invalid input was specified or no MC_GearIn or MC_GearInPos move is active
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT


1.2.5.57.5 Example

1.2.5.58.6.1 Structured Text

```
(* MC_GearOut ST example *)

Inst_MC_GearOut
(ExecGearOut1,Axis1,GearOut1Acc,GearOut1Dec,GearOut1Jerk);

//Inst_MC_GearOut is instance of MC_GearOut
```

1.2.5.59.7.2 Ladder Diagram**1.2.5.60 MC_Phasing****1.2.5.61.1 Description**

This function block performs a master position phase shift for the slave axis. The phase shift is applied like a traditional single-axis move with a velocity setpoint and acceleration and deceleration rates. Phasing has its own Profile Generator and its own queue. Phase shifts can be aborted and blended with additional phase shifts. The amount of phase shift is added to the total master offset as the phase shift is executing.

MC_Phasing	
Execute	Done
Master	Busy
Slave	Active
PhaseShift	CommandAborted
Velocity	Error
Acceleration	ErrorID
Deceleration	
Jerk	
BufferMode	

Figure 1-66: MC_Phasing

1.2.5.62.2 Arguments**1.2.5.63.3.1 Input**

Execute	Description	Requests to queue the phase shift
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Master	Description	Name of a declared instance of the AXIS_REF library function.)
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—

Slave	Description	AXIS_REF.AXIS_NUM is the slave axis number
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—
PhaseShift	Description	Amount of phase shift
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
Velocity	Description	Velocity setpoint
	Data type	LREAL
	Range	—
	Unit	User unit/sec
	Default	—
Acceleration	Description	Trapezoidal: Acceleration rate S-curve: Maximum acceleration
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Deceleration	Description	Trapezoidal: Deceleration rate S-curve: Unused
	Data type	LREAL
	Range	—
	Unit	User unit/sec ²
	Default	—
Jerk	Description	Trapezoidal: 0 S-curve: Constant jerk
	Data type	LREAL
	Range	—
	Unit	User unit/sec ³
	Default	—
BufferMode	Description	0 = abort 1 = buffer 2 = blend to active 3 = blend to next 4 = blend to low velocity 5 = blend to high velocity
	Data type	SINT
	Range	[0,5]
	Unit	n/a
	Default	—


1.2.5.64.4.2 Output

Done	Description	Indicates the phase shift has been completely applied
	Data type	BOOL
Busy	Description	High from the moment the Execute input is one-shot to the time the move is ended
	Data type	BOOL
Active	Description	Indicates this phase shift is the active phase shift
	Data type	BOOL
CommandAborted	Description	Indicates the move was aborted
	Data type	BOOL
Error	Description	Indicates an invalid input was specified or the move was terminated due to an error
	Data type	BOOL
ErrorID	Description	Indicates the error if Error output is set to TRUE
	Data type	INT

1.2.5.65.5 Example1.2.5.66.6.1 Structured Text

```
(* MC_Phasing ST example *) //Inst_MC_Phasing is an instance of
MC_Phasing function block

Inst_MC_Phasing(PhasingAxis1, Axis2, Axis1, 1000.0,100.0, 200.0,
200.0, 0, 0 );
```

1.2.5.67.7.2 Ladder Diagram**1.2.5.68 MC_SyncSlaves**1.2.5.69.1 Description

This function block allows the application to specify what slave axes are to be synchronized and which master they follow. After this function block is executed successfully, all the slave axes specified at the SlaveList input start their slave moves (i.e. MC_GearIn, MC_CamIn, etc.) on the same servo interrupt for a synchronized slave start. When a slave move is commanded for one of the slave axes listed, the slave move is queued but the motion is held off until all of the listed slaves have queued their slave moves.




Figure 1-67: MC_SyncSlaves

1.2.5.70.2 Arguments1.2.5.71.3.1 Input

Execute	Description	A positive transition of this input causes the function block to execute
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Master	Description	Master axis identifier
	Data type	AXIS_REF
	Range	1 - 256
	Unit	n/a
	Default	—

	SlaveCount	Description	The number of slave axes listed in the SlaveList array input that are to be synchronized. This number must not be greater than the declared size of the SlaveList array. If this number is 0, the list of synchronized slaves for the specified Master axis is cleared.
		Data type	AXIS_REF
		Range	1-256
			The AXIS_NUM element of the AXIS_REF structure must be in the range [1-256]
		Unit	n/a
		Default	—
	SlaveList	Description	The list of slave axes that are to be synchronized. Each element of this array contains a unique axis number. The axis number must not be the same as the Master axis number.
		Data type	UINT
		Range	1-32
		Unit	n/a
		Default	—

1.2.5.72.4.2 Output

	Done	Description	Indicates the synchronized slave assignments were completed without error
		Data type	BOOL
	Error	Description	Indicates an invalid input was specified
		Data type	BOOL
	ErrorID	Description	Indicates the error if Error output is set to TRUE
		Data type	INT

1.2.5.73.5 Usage

Call MC_SyncSlaves to specify the slave axes to synchronize.

Call each slave move (e.g. MC_GearIn) for each slave axis. The motion is held off until all the slave moves have been queued.

After all the slave moves have been queued, the interpolation for all the slave axes begin on the same servo interrupt, providing a synchronized start.

The master axis can be in motion prior to this sequence, or the master can be commanded after all the slave moves are queued.

1.2.5.74.6 Related Functions

MC GearIn

MC GearInPos


MC CamIn

1.2.5.75.7 Example

1.2.5.76.8.1 Structured Text

```
(* MC_SyncSlaves ST example *)  
  
// Inst_MC_SyncSlaves is an instance of MC_SyncSlaves function  
block  
  
Inst MC SyncSlaves( SyncSlaves, Axis1, SlaveCount, SlaveList );
```

1.2.5.77.9.2 Ladder Diagram



1.2.6 Reference


1.2.6.1 MC_Reference (Function Block)

1.2.6.2.1 Description

This function block is used to execute a fast home to a switch. If the application selects to reference to the index mark of an encoder, or the null of a resolver (which is typical), the new position value is assigned to the position of the index of the encoder (or the null of the resolver) and not the position of the switch. The ECATWriteSDO function block is used to setup the trigger event and any desired preconditions. **This function block utilizes the Position Capture Mode of the AKD.**



At this time, position capture is not available for PLCopen axes assigned to the secondary feedback input (digitizing axes). Therefore, MC_Reference cannot be used to home digitizing axes at this time.

**Figure 1-68: MC_Reference****1.2.6.3.2 Arguments****1.2.6.4.3.1 Input**

Execute	Description	Requests to queue the MC_Reference move and arms reference trigger events
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Axis	Description	Name of a declared instance of the AXIS_REF library function.)
	Data type	AXIS_REF
	Range	[1,256]
	Unit	n/a
	Default	—

<code>TriggerInput</code>	Description	<code>TRIGGER_REF</code> structure defines the trigger INT InputID: 0 = Capture Engine 0 1 = Capture Engine 1 Range is [0,1] For information on configuring the capture engines, refer to AKD Capture Engine Configuration. INT Direction; 1 = rising edge of trigger, 2 = falling edge of trigger INT Trigid; must be zero
	Data type	<code>TRIGGER_REF</code>
	Range	See Description above
	Unit	n/a
	Default	—
<code>Velocity</code>	Description	Commanded velocity for the reference move
	Data type	<code>LREAL</code>
	Range	—
	Unit	User unit/sec
	Default	—
<code>Acceleration</code>	Description	Commanded acceleration for the reference move
	Data type	<code>LREAL</code>
	Range	—
	Unit	User unit/sec ²
	Default	—
<code>Deceleration</code>	Description	Commanded deceleration for the reference move
	Data type	<code>LREAL</code>
	Range	—
	Unit	User unit/sec ²
	Default	—
<code>Jerk</code>	Description	Commanded jerk for the reference move (if zero, then trapezoidal acc/dec is used)
	Data type	<code>LREAL</code>
	Range	—
	Unit	User unit/sec ³
	Default	—
<code>Direction</code>	Description	Commanded Direction of the reference
	Data type	<code>SINT</code>

	Range	[0,1]
	Unit	n/a
	Default	—
Position	Description	Position of the axis at the reference location
	Data type	LREAL
	Range	—
	Unit	User unit
	Default	—
Option	Description	<p>Option identifier for Resolvers/Modulo reference.</p> <p>0 = Use latched position for reference</p> <p>1 = use resolver position of nearest null for reference 2 pole resolver</p> <p>2 = use resolver position of nearest null for reference 4 pole resolver</p> <p>3 = use resolver position of nearest null for reference 6 pole resolver</p> <p>4 = use resolver position of nearest null for reference 8 pole resolver</p> <p>5 = use resolver position of nearest null for reference 10 pole resolver</p> <p>...</p> <p>15 = use resolver position of nearest null for reference 30 pole resolver</p>
	Data type	SINT
	Range	[0,15]
	Unit	n/a
	Default	—

1.2.6.5.4.2 Output

Done	Description	Indicates the reference move and position adjustment is complete
	Data type	BOOL
Busy	Description	Indicates this function block is executing
	Data type	BOOL
Active	Description	Indicates this move is the Active move
	Data type	BOOL

CommandAborted	Description	Indicates the move was aborted
	Data type	BOOL
Error	Description	Indicates an invalid input, or the move was terminated due to an error
	Data type	BOOL
ErrorID	Description	Indicates the error if the Error output is high
	Data type	INT

1.2.6.6.5 Usage

The following lists the steps for homing a PLCopen axis, using the MC_Reference function block. Not all of the steps are necessary depending on the configuration and the homing cycle design.

The sequence of events of a PLCopen homing cycle consists of the following steps:

- Ensure Axis is not on Reference switch.
If a switch is used in the homing cycle for the event or precondition to the event, check to ensure the axis is not already tripping the switches that trigger the event and precondition. If it is, move the axis off the switches.
- Configure AKD capture engine
Configuration of the AKD capture engine is performed by writing drive CAN objects via SDO. It is accomplished with the ECATWriteSdo function. **The AKD Capture mode must be set to POSITION CAPTURE.**
The available configurations are discussed in paragraph "**AKD Capture Engine Configuration**". Example AKD capture engine configurations and reference examples are discussed in paragraph "**PLCopen Homing Methods**".
- Call the MC_REFERENCE function to initiate optional homing motion and to arm the AKD capture engine
The MC_Reference function block selects the trigger edge (rising or falling edge) and arm the capture. Then, it optionally moves the axis to the reference location as directed by inputs to this function. When the AKD indicates that the capture event has occurred, the coordinate system is shifted so that the reference position input to this function block is set to the reference location. Then, the reference motion is stopped.
- Wait for the completion of the MC_Reference function block
The application is notified by the completion, abort or error of the homing by the MC_Reference function block.
- Upon completion of the MC_Reference function block, the axis can be moved to the home position with a MC_MoveAbsolute function block.

 **TIP**

Once the MC_Reference block is queued, but before it is completed, the cycle can be aborted with a MC_Halt or MC_Stop function block or by queuing a new motion function block with the Abort selected for buffer mode.

1.2.6.7.6 Related Functions


ECATWriteSdo

MC_MoveAbsolute

1.2.6.8.7 Example**1.2.6.9.8.1 Structured Text**

```
(* MC_Reference ST example *)

TriggerInput.InputID := 0; //configure the reference InputID
TriggerInput.DIRECTION := 1; //configure the reference direction
Inst_MC_Reference( RefReq, Axis1, TriggerInput, 20.0, 100.0,
100.0, 100.0, 0, 0.0, 0 );
```

1.2.6.10.9.2 Ladder Diagram**1.2.6.11 MC_SetPosition (Function)****1.2.6.12.1 Description**

This function has been deprecated by the MC_SetPos function block.

2 Fieldbus Library

2.1 EtherCAT Library	268
----------------------------	-----

2.1 EtherCAT Library

Name	Object Type	Description
DriveParamRead	SDO	Reads a drive parameter (ASCII format)
DriveParamWrite	SDO	Writes a drive parameter (ASCII format)
ECATGetObjVal	PDO	Reads cyclic drive parameter (String format) by returning the value of an EtherCAT PDO element
ECATGetStatus	PDO	Reads cyclic status word (Index 6041)
ECATReadData	PDO	Reads cyclic parameter (byte offset format)
ECATReadSdo	SDO	Reads parameter (32 bit format) using SDO command
ECATSetControl	PDO	Manipulates the state of a drive by setting its control word (Index 6040)
ECATWriteData	PDO	Writes cyclic parameter (byte offset format)
ECATWriteSdo	SDO	Writes parameter (32 bit format) using SDO command

Table 2-1: List of EtherCAT FB

The four EtherCAT SDO function blocks are activated by the CANopen over EtherCAT (CoE) protocol in a client/server mode.

- The client (aka EtherCAT master) is the KAS Runtime application
- The servers (aka EtherCAT slaves) are the drives and I/O nodes where data can be retrieved

The SDO function blocks only support the reading and writing of 32-bit values. It is the fundamental size of CANopen SDO calls.

Why use ECATReadSdo and ECATWriteSdo FBs?

The ECATReadSdo and ECATWriteSdo response time is faster and therefore is typically preferred over the DriveParamRead and DriveParamWrite.

Why use the DriveParam FBs?

The two reasons to prefer the DriveParam FBs are:

- They allow direct use of the parameter name (e.g. IL.LIMITP instead of the SDO index: 356Eh)
- They can be used to setup a drive terminal in the HMI application (which is similar to the Terminal view available in the AKD widget embedded in the KAS IDE)

See some stats about the CPU load

Increase of CPU load when calling SDO function blocks

	Mid-range IPC (Celeron 1.2GHz)	High-range IPC (Core 2 Duo 1.86GHz)
Mean	60 µs	30 µs
Min	48 µs	24 µs
Max	64 µs	38 µs

(these values have been computed with the TraceTimes command)

2.1.1 EtherCAT Library - Drive

These function blocks are used to work with drive parameters that are not supported by ML and MC function blocks.

They support reading and writing drive parameters using the non-cyclic SDO channel in the EtherCAT network. The ASCII name for the parameter is used as an input.

2.1.1.1 Execution Time

These function blocks typically take a longer time to execute (up to ten cycles to finish executing).

It takes the same amount of time to Read or Write a parameter.



NOTE It takes more than one cycle to execute these function blocks (but less than 100 ms).

2.1.1.2.2.1 Reason

It is not only linked to the SDO ASCII communication. Because these FBs are waiting for the AKD drive to respond, the execution time can also increase due to the load of the AKD firmware at the time you call them.

2.1.1.3.3.2 Result

The PLC code is overrunning the cycle duration. as explained in paragraph "**Tasking Model / Scheduling**".

As a consequence, you can see the following message in the Controller Log window:

"The Virtual Machine missed 1 cycle(s) of PLC execution"

2.1.1.4.4.3 Solution

When this happens we recommend to:

- Use these function blocks sparingly in programs
- Rely on the EtherCAT read/write SDO function blocks whenever possible
- Smooth the load of the PLC code by executing these function blocks at the required update rate.

See some stats about the FB execution time

- **Max** time to consider when executing a single Drive Parameter command (i.e. before the Done output becomes True): **60 ms**

	4 kHz	1 kHz
Mean	20 ms	11 ms
Min	15 ms	9 ms
Max	45 ms	58 ms

- When sending multiple commands to a single drive, only one command can be sent at a time. Therefore the time to execute multiple commands is:
Number of commands x Execution time of a single command

2.1.1.5 DriveParamRead (Function Block)

2.1.1.6.1 Description

This function block reads a drive parameter by sending an ASCII command to a drive.

See also some **stats** about the execution time here.




Figure 2-1: DriveParamRead

NOTE

This function block uses *and reserves* the EtherCAT SDO Channel. The SDO Channel will remain reserved until the done output is "true". Therefore, this FB should be called at each cycle until the done output is true. If it is not called at each cycle the rest of SDO communication (the AKD GUI Views, for example) will be blocked.

Using this FB in SFC P0 or P1 steps is not recommended as these steps are executed only once. If this FB is used in P0 or P1 then it must be used in an SFC N step to ensure the FB completes.

2.1.1.7.2 Arguments**2.1.1.8.3.1 Input**

Execute

Description

On the rising edge of Execute, a drive parameter is read.



The function block only handles one request at a time. If Execute is toggled quickly so that another rising edge occurs before the function block has completed, the function block does not issue a second read command.

Data type

BOOL

Range

0, 1

Unit

n/a

Default

—


Drive

Description

The address of the drive from which data is read.

The first node usually has the value '1001'. The second node usually has the value '1002'.

Alternately, you can use the members of the EtherCAT structure to specify a drive's address when you create the variable.



Data type

INT

Range

—

Unit

n/a

Default

—

Param	Description	The parameter to read.
	Data type	STRING
	Range	—
	Unit	n/a
	Default	—

2.1.1.9.4.2 Output

Done	Description	Indicates whether the DriveParamRead function block has completed without error.
	Data type	BOOL
	Unit	n/a
Error	Description	Indicates whether the DriveParamRead function block call has completed with error:
	Data type	BOOL
	Unit	n/a
ErrorID	Description	The DriveParamRead error result if Error is TRUE (see list of Error Codes in table below). Upon success, Error is set to zero.
	Data type	DINT
	Unit	n/a

Error Code	Value, dec (hex)	Description
ECERR_OK	0	The SDO call succeeded
ECERR_DEVICE_INVALIDINDEX	1795 (0x703)	An invalid value for the Index input was specified
ECERR_DEVICE_INVALIDACCESS	1796 (0x704)	Reading of the variable is not permitted
ECERR_DEVICE_INVALIDDATA	1798 (0x706)	Invalid parameter value (s) in SDO index and/or sub-index
ECERR_DEVICE_NOTREADY	1799 (0x707)	device is not in a ready state, network is not in operational
ECERR_DEVICE_NOTFOUND	1804 (0x70C)	EtherCAT device not found
ECERR_DEVICE_SYNTAX	1805 (0x70D)	An unexpected error occurred
ECERR_DEVICE_INVALIDSTATE	1810 (0x712)	The EtherCAT device is in an invalid state
ECERR_DEVICE_TIMEOUT	1817 (0x719)	The EtherCAT device failed to respond, timing out

Error Code	Value, dec (hex)	Description
ECERR_DEVICE_INSERTMAILBOX	1826 (0x722)	Error while inserting the mailbox command into internal FIFO
ECERR_DEVICE_UNKNOWNMAILBOXCMD	1828 (0x724)	The master sent an unknown mailbox command to the slave
ECERR_DEVICE_INVALIDADDR	1832 (0x728)	Can't send a mailbox command to the specified slave
ECERR_DEVICE_INVALIDOFFSET	1827 (0x723)	An invalid value for the SubIndex input was specified
ECERR_DEVICE_PARAM_ACCESS_ERROR	1920 (0x780)	Unknown error occurred while accessing parameter
ECERR_DEVICE_PARAM_NOT_FOUND	1921 (0x781)	Parameter was not found
ECERR_DEVICE_PARAM_NOT_INTEGER	1922 (0x782)	Parameter is a floating-point value. Integer value required.
ECERR_DEVICE_VALUE_IS_NEGATIVE	1923 (0x783)	No negative values allowed. Value specified was negative.
ECERR_DEVICE_VALUE_OUT_OF_RANGE	1924 (0x784)	Value is out of data-range
ECERR_DEVICE_VALUE_GREATER_THAN_MAX	1925 (0x785)	Value bigger than maximum
ECERR_DEVICE_VALUE_LOWER_THAN_MIN	1926 (0x786)	Value lower than minimum
ECERR_CLIENT_ERROR	2048 (0x800)	Error in Mailbox response to a previously sent mailbox command
ECERR_CLIENT_TIMEOUT	2049 (0x801)	The SDO command timed out
ECERR_CLIENT_INVALIDPARM	2050 (0x802)	An invalid value was specified
ECERR_CLIENT_INVALIDSIZE	2051 (0x803)	An invalid value for the size input was specified

Table 2-2: List of EtherCAT Error Codes

Value	Description	The value of the drive parameter. Value is only set when the function block has successfully completed.
Data type Unit	LREAL n/a	

Units	Description	The units of the drive parameter. Value is only set when the function block has successfully completed.
	Data type	STRING
	Unit	n/a

2.1.1.10.5 Usage

Use this FB to read drive parameters that are not supported by other function blocks. Examples would be motor temperature, drive bus voltage, Present drive limit settings, present regen loading, drive display, and fault history.

2.1.1.11.6 Related Functions

DriveParamWrite

2.1.1.12.7 Example

2.1.1.13.8.1 Structured Text

```
(* Read PL.KP on first AKD Drive on EtherCAT network *)
(* The code continually calls the FB (without re-executing it) until
the first execution is done, then reads the returned value from the
drive and reset the FB *)

IF ReadPropGain then
    Inst_DriveParamRead1( 1, 1001, 'PL.KP' );
End_If;

On Inst_DriveParamRead1.Done do
    Inst_DriveParamRead1( 0, 1001, 'PL.KP' );
    PositionProportionalGain := Inst_DriveParamRead1.Value; (* Reads
the returned value from the drive *)
    ReadPropGain := 0; (* Reset the FB *)
End_DO;
```

See example with animation

```
IF FALSE ReadPropGain FALSE then
    Inst_DriveParamRead1( 1, 1001, 'PL.KP' );
End_If;


On Inst_DriveParamRead1.Done TRUE do
    Inst_DriveParamRead1( 0, 1001, 'PL.KP' );
    PositionProportionalGain 94.999000 := Inst_DriveParamRead1.Value 94.999000 ;
    ReadPropGain FALSE := 0;
End_DO;
```

2.1.1.14 DriveParamWrite (Function Block)

2.1.1.15.1 Description

This function block writes a drive parameter by sending an ASCII command to a drive.

See also some **stats** about the execution time here.

**Figure 2-2:** DriveParamWrite***NOTE***


This function block uses *and reserves* the EtherCAT SDO Channel. The SDO Channel will remain reserved until the done output is "true". Therefore, this FB should be called at each cycle until the done output is true. If it is not called at each cycle the rest of SDO communication (the AKD GUI Views, for example) will be blocked.

Using this FB in SFC P0 or P1 steps is not recommended as these steps are executed only once. If this FB is used in P0 or P1 then it must be used in an SFC N step to ensure the FB completes.

2.1.1.16.2 Arguments**2.1.1.17.3.1 Input**

Execute	Description	On the rising edge of Execute, a drive parameter is set.
	Data type Range	<i>NOTE</i> The function block only handles one request at a time. If Execute is toggled quickly so that another rising edge occurs before the function block has completed, the function block does not issue a second write command. BOOL 0, 1

	Unit	n/a
	Default	—
Drive	Description	<p>The address of the drive to which data is written to.</p> <p>The first node usually has the value '1001'. The second node usually has the value '1002'.</p> <p>Alternately, you can use the members of the EtherCAT structure to specify a drive's address when you create the variable.</p>



	Data type	INT
	Range	—
	Unit	n/a
	Default	—
Param	Description	The parameter to write.
	Data type	STRING
	Range	—
	Unit	n/a
	Default	—
Value	Description	The value to set the drive parameter to.
	Data type	LREAL
	Range	—
	Unit	n/a
	Default	—

2.1.1.18.4.2 Output

	Done	Description	Indicates whether the DriveParamWrite function block has completed without error.
		Data type	BOOL
		Unit	n/a
Error	Description	Indicates whether the DriveParamWrite function block call has completed with error.	
	Data type	BOOL	
	Unit	n/a	

ErrorID	Description	The DriveParamWrite error result if Error is TRUE (see "Table 2-2: List of EtherCAT Error Codes " on page 274)
	Data type	Upon success, Error is set to zero.
	Unit	DINT n/a

2.1.1.19.5 Usage

The function block can be used to change drive parameters. Common examples include tuning parameters and changing drive limits such as peak current.

2.1.1.20.6 Related Functions

DriveParamRead

2.1.1.21.7 Example

2.1.1.22.8.1 Structured Text

```
(* Write 58.000 to PL.KP of first AKD Drive on EtherCAT
network *)

Inst_DriveParamWrite( TRUE, 1001, 'PL.KP', 58 );
```

2.1.2 EtherCAT Library - SDO

These function blocks are used to work with drive or remote I/O parameters that are not supported by ML and MC function blocks.

Drive or remote I/O parameters that have an associated SDO number can be read and written using these function blocks.



NOTE It takes more than one cycle to execute these function blocks (but less than 100 ms).

See some stats about the FB execution time

- There is a small difference in timing when running EtherCAT at 2ms compared to other frequencies.

	0.25, 0.5, 1ms	2ms
Mean	9ms	14ms
Min	3ms	8ms
Max	16ms	24ms

- **Max** time to consider when executing a single SDO command, (i.e. before the Done output becomes true): **24ms**.
- When sending multiple commands to a single drive, only one command can be sent at a time. Therefore the time to execute multiple commands is:
Number of commands x Execution time of a single command

- When commands are sent to different AKD drives at the same time, the requests do not interfere with each other. So you can be confident the function finishes execution in the same max time as to one drive

2.1.2.1 ECATReadSdo (Function Block)

2.1.2.2.1 Description

This function block reads a 32-bit word from I/O nodes using a CANopen SDO read command. It is typically used to query the status of inputs.




Figure 2-3: ECATReadSdo


2.1.2.3.2.1 State Diagram

Figure 2-4: ECATReadSdo State Diagram

NOTE

This function block uses and reserves the EtherCAT SDO Channel. The SDO Channel will remain reserved until the done output is "true". Therefore, this FB should be called at each cycle until the done output is true. If it is not called at each cycle the rest of SDO communication (the AKD GUI Views, for example) will be blocked.


Using this FB in SFC P0 or P1 steps is not recommended as these steps are executed only once. If this FB is used in P0 or P1 then it must be used in an SFC N step to ensure the FB completes.

2.1.2.4.3 Arguments

2.1.2.5.4.1 Input

Execute	Description	On the rising edge of Execute, an SDO read command is issued.
		<p>NOTE The function block only handles one SDO command at a time. If Execute is toggled quickly so that another rising edge occurs before the SDO command has completed, the function block does not issue a second SDO command.</p>
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—
Index	Description	<p>The object directory index of the data to be read.</p> <p>For more details, refer to:</p> <ul style="list-style-type: none"> • Communication SDOs • Manufacturer specific SDOs • Profile specific SDOs
	Data type	INT
	Range	—
	Unit	n/a
	Default	—
Subindex	Description	<p>The sub-index of the object directory variable to be read.</p> <p>For more details, refer to:</p> <ul style="list-style-type: none"> • Communication SDOs • Manufacturer specific SDOs • Profile specific SDOs
	Data type	SINT
	Range	—
	Unit	n/a
	Default	—

Size	Description	The size (number of bytes) to write.
	Data type	SINT
	Range	1 - 4
	Unit	n/a
	Default	—
SlaveAddress	Description	<p>The EtherCAT address of the slave from which data is written to. The first node usually has the value '1001'. The second node usually has the value '1002'.</p> <p>Alternately, you can use the members of the EtherCAT structure to specify a drive's address when you create the variable.</p>



Data type	INT
Range	—
Unit	n/a
Default	—

2.1.2.6.5.2 Output

Done	Description	Indicates whether the SDO call has completed without error.
	Data type	BOOL
	Unit	n/a
Error	Description	Indicates whether the SDO call has completed with error:
	Data type	BOOL
	Unit	n/a
ErrorID	Description	<p>The SDO call error result, if Error is TRUE (see).</p> <p>Upon success, Error is set to zero.</p>
	Data type	DINT
	Unit	n/a

Value	Description	The value of the object directory variable being read.
		Value is only set when an SDO read command has successfully completed.
	Data type	DINT
	Unit	n/a

2.1.2.7.6 Related Functions

ECATWriteSDO

2.1.2.8.7 Example

2.1.2.9.8.1 Structured Text

```
(* Read PL.KP on first AKD Drive on EtherCAT network *)
Inst_ECATReadSdo( TRUE, 16#3542, 0, 4, 1001 );
PositionProportionalGain := Inst_ECATReadSdo.Value;
```

2.1.2.10 ECATWriteSdo (Function Block)

2.1.2.11.1 Description

This function block writes a 32-bit word to I/O nodes using a CANopen SDO write command.




Figure 2-5: ECATWriteSdo


2.1.2.12.2.1 State Diagram

Figure 2-6: ECATWriteSdo State Diagram

NOTE

This function block uses *and reserves* the EtherCAT SDO Channel. The SDO Channel will remain reserved until the done output is "true". Therefore, this FB should be called at each cycle until the done output is true. If it is not called at each cycle the rest of SDO communication (the AKD GUI Views, for example) will be blocked.

Using this FB in SFC P0 or P1 steps is not recommended as these steps are executed only once. If this FB is used in P0 or P1 then it must be used in an SFC N step to ensure the FB completes.

2.1.2.13.3 Arguments**2.1.2.14.4.1 Input**

Execute

Description

On the rising edge of Execute, an SDO write command will be issued.



The function block will only handle one SDO command at a time. If Execute is toggled quickly so that another rising edge occurs before the SDO command has completed, the function block will not issue a second SDO command.

Data type

BOOL

Range

0, 1

Unit

n/a

Default

—

Index

Description

The object directory index of the data to be written to.

For more details, refer to:

- Communication SDOs
- Manufacturer specific SDOs
- Profile specific SDOs

Data type

INT

Range

—

Unit

n/a

Default

—

Subindex

Description

The sub-index of the object directory variable to be written to.

For more details, refer to:

- Communication SDOs
- Manufacturer specific SDOs
- Profile specific SDOs

Data type

SINT

Range

—


Unit

n/a

Default

—

Size	Description	The size (number of bytes) to write.
	Data type	SINT
	Range	1 - 4
	Unit	n/a
	Default	—
SlaveAddress	Description	<p>The EtherCAT address of the slave from which data will be written to. The first node usually has the value '1001'. The second node usually has the value '1002'.</p> <p>Alternately, you can use the members of the EtherCAT structure to specify a drive's address when you create the variable.</p>



	Data type	INT
	Range	—
	Unit	n/a
	Default	—
Value	Description	The value to write to the object directory variable.
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—

2.1.2.15.5.2 Output

Done	Description	Indicates whether the SDO call has completed without error.
	Data type	BOOL
	Unit	n/a
Error	Description	Indicates whether the SDO call has completed with error:
	Data type	BOOL
	Unit	n/a
ErrorID	Description	<p>The SDO call error result, if Error is TRUE (see).</p> <p>Upon success, Error is set to zero.</p>

Data type	DINT
Unit	n/a


2.1.2.16.6 Related Functions

ECATReadSDO

2.1.2.17.7 Example**2.1.2.18.8.1 Structured Text**

```
(* Write 58.000 to PL.KP of first AKD Drive on EtherCAT
network *)

Inst_ECATWriteSdo( TRUE, 16#3542, 0, 4, 1001, 58000 );
```

2.1.2.19.9.2 Ladder Diagram**2.1.3 EtherCAT Library - Debug**

The following function blocks support advanced functionality typically used for diagnostic support.

Most information available in these function blocks is also available in a ML and MC function block.

2.1.3.1 ECATReadData (Function)

IMPORTANT This is a low level function and it should only be used carefully by advanced users.

2.1.3.2.1 Description

This function allows a direct access to the memory image of the EtherCAT frame which is sent or received when you need to debug your application. You access the EtherCAT image element by giving the offset in the image and the size of the element.

If you have a device other than the drive, ECATReadData is used for more than just debug. It is used to get the status of the module (e.g. Stepper I/O slice).

2.1.3.3.2 Arguments

2.1.3.4.3.1 Input

Offset	Description	Offset from the beginning of the frame
	Data type	UINT
	Range	0-size of frame (maximum size of an Ethernet frame is 1500)
	Unit	n/a
	Default	—
Nbytes	Description	Number of bytes to read
	Data type	SINT
	Range	1, 2 or 4
	Unit	bytes
	Default	—
Direction	Description	Direction of the frame (true = output image, false = input image).
	Data type	BOOL
	Range	0, 1
	Unit	n/a
	Default	—

2.1.3.5.4.2 Output

Value	Description	Value of the EtherCAT frame
	Data type	DINT
	Unit	n/a

2.1.3.6.5 Related Functions

ECATGetObjVal

2.1.3.7.6 Example

2.1.3.8.7.1 Structured Text

```
// Read 4 bytes starting at offset 26 of the output image

Position := ECATReadData(26, 4, true);
```

2.1.3.9 ECATWriteData (Function)

! IMPORTANT This is a low level function and it should only be used carefully by advanced users.

2.1.3.10.1 Description

Modify the EtherCAT process image by directly writing values in it.

If you have a device other than the drive, ECATWriteData is used for more than just debug. It is used to set the status of the module (e.g. Stepper I/O slice) in the case your project is based on an external XML file because it contains unsupported EtherCAT Device.

2.1.3.11.2 Arguments

2.1.3.12.3.1 Input

Offset	Description	Byte offset from the beginning of the process image where data is to be written
	Data type	UINT
	Range	0 - 1500
	Unit	n/a
	Default	—
Nbytes	Description	Number of bytes to write
	Data type	SINT
	Range	1, 2 or 4
	Unit	bytes
	Default	—
Value	Description	Value to be written in the image. Only the number of bytes specified by Nbytes is copied.
	Data type	DINT
	Range	[-2147483648, 2147483648]
	Unit	n/a
	Default	—

2.1.3.13.4.2 Output

Default (.Q)	Description	True if data was written
	Data type	BOOL
	Unit	n/a

2.1.3.14.5 Related Functions

ECATReadData

2.1.3.15 ECATGetObjVal (Function)

NOTE This function block is deprecated as of KAS v2.7. The recommended best practice is to map a PLC variable to a PDO object.

2.1.4 EtherCAT Library - Status

The following function blocks support advanced functionality typically used for diagnostic support.

Most information available in these function blocks is also available in ML and MC function blocks.

2.1.4.1 ECATGetStatus (Function)

2.1.4.2.1 Description

Return the status word of the designated drive (SDO 0x6041).

The status machine for the status word corresponds to the CANopen status machine.

The Function Block receives the status word through the cyclic EtherCAT PDO communications. The status word is captured in every instance of fixed PDO mapping.

2.1.4.3.2 Arguments

2.1.4.4.3.1 Input

Address	Description	EtherCAT address of the drive
	Data type	DINT
	Range	[0, 65535]
	Unit	n/a
	Default	—

2.1.4.4.3.2 Output

Status	Description	Status word of the drive as defined in the EtherCAT profile for the S300/S400/S600/S700. Compatible with CiA 402 definition of status word (CANopen object 0x6041).
	Data type	UINT
	Unit	n/a

2.1.4.6.5 Related Functions

ECATSetControl

2.1.4.7.6 Example**2.1.4.8.7.1 Structured Text**

```

(*****)
(* read EtherCAT axis status (Bit3: Fault, Bit7: Warning) *)
(*****)

ECATStatus := ECATGetStatus(AxisAddress); //Read the ECAT Status
Word (SDO 6041) of the Axis

IF AxisAddress > 1000 THEN
(*****)
(* timer to read cyclically SDOs *)
(*****)

```

2.1.4.9 ECATSetControl (Function)**2.1.4.10.1 Description**

Manipulate the state of a drive by setting its control word (SDO 06040).

The status machine for the control word corresponds to the CANopen status machine.

The Function Block transmits the control word through the cyclic EtherCAT PDO communications. The control word is captured in every instance of fixed PDO mapping.

2.1.4.11.2 Arguments**2.1.4.12.3.1 Input**

Address	Description	EtherCAT address of the drive
	Data type	DINT
	Range	[0, 65535]
	Unit	n/a
	Default	—
Control	Description	Control word of the drive as defined in the EtherCAT profile for the S300/S400/S600/S700. Compatible with CiA 402 definition of control word (CANopen object 0x6040).
	Data type	UINT
	Range	—
	Unit	n/a
	Default	—

2.1.4.13.4.2 Output

Default (.Q)	Description	Returns true when function successfully executes (i.e. if the control word was successfully set)
	Data type	BOOL
	Unit	n/a

2.1.4.14.5 Related Functions

ECATGetStatus

This page intentionally left blank.

3 System Library

3.1 PrintMessage (Function)	296
-----------------------------------	-----

Name	Description
PrintMessage	Generate an output message in the log windows.
GetCtrlErrors	Get a list of the active errors and alarms on the controller.
ClearCtrlErrors	Clears the list of active errors and alarms on the controller.

Table 3-1: List of System Functions

3.1 PrintMessage (Function)

3.1.1 Description

The PrintMessage block is used to generate a log message with any wanted strings in the log message window.

3.1.1.1 About the Source

PrintMessage use the PLC message type. So, to display all messages generated by PrintMessage, go to the log configuration and select the DEBUG level for the PLC source.

3.1.1.2 About the Level

The message could be sent with a logging level from 0 to 4 that qualifies its importance. The highest level, 4, logs critical messages (available levels are: debug, informational, warning, error and Critical).

Keep in mind that only Error and Critical messages are generated by default. If you want to force the system to generate every message level, go into the log configuration and change the settings to the desired level.

IMPORTANT Enabling all messages can slow down the application's execution. To avoid locking up communications between the IDE and Runtime, you must never include a print statement in your program that prints to the log every update cycle.

See at the configuration settings for more details.

3.1.2 Arguments

3.1.2.1 Input

Level	Description	Level of the logged message. In other words, the importance of it. Keep in mind that not all messages are displayed in the log windows by default. Only Error and Critical messages are displayed. So, in order to show lower level, it is needed to change the log settings. PrintMessage logs PLC messages.
	Data type	DINT
	Range	[0 , 4] Defines are: LEVEL_DEBUG, LEVEL_INFO, LEVEL_WARNING, LEVEL_ERROR, LEVEL_CRITICAL
	Unit	n/a
	Default	—
Message	Description	Content of the message. A string of 255 characters maximum.
	Data type	String

Range	1 to 255 characters
Unit	n/a
Default	—

3.1.2.2 Output

Default (.Q)	Description	Returns true when function successfully executes
	Data type	BOOL

Unit n/a

3.1.3 Usage

```
PrintMessage( LEVEL_DEBUG, 'Message string to be logged' );
```

3.1.4 Example

3.1.4.1 Structured Text

```
// It's possible to create a temporary variable with the
message.

MESSAGE := CONCAT( 'MachineState=', ANY_TO_STRING(MachineState),
'. MachineSpeed=', ANY_TO_STRING(MachineSpeed) );


// Then print the message to the log window

PrintMessage( LEVEL_INFO, MESSAGE );
PrintMessage( LEVEL_WARNING, MESSAGE );
PrintMessage( LEVEL_ERROR, MESSAGE );

// Or to create the string directly in the function call:

PrintMessage( LEVEL_CRITICAL, CONCAT( 'MachineState=', ANY_TO_
STRING(MachineState), '. MachineSpeed=', ANY_TO_STRING
(MachineSpeed) ) );
```

3.1.4.2 Function Block Diagram



Index

A

actual velocity	189
ASCII	270

C

copyrights	2
curve	
synchronizer	149
cycle	
missed	270

D

debug	
EtherCAT	288
delay compensation	155
disclaimer	3
DriveParamRead	270
DriveParamWrite	275

E

ECATGetObjVal	290
ECATGetStatus	291
ECATReadData	288
ECATReadSdo	279
ECATSetControl	292
ECATWriteData	289
ECATWriteSdo	283
EtherCAT	
image	288, 290
timeout	273
EtherCAT library	268
EtherCAT library function	
DriveParamRead	270
DriveParamWrite	275
ECATGetObjVal	290
ECATGetStatus	291
ECATReadData	288
ECATReadSdo	279
ECATSetControl	292
ECATWriteData	289
ECATWriteSdo	283

F

falling edge	151
fast input	156
feed-forward	
torque-	88
feedback position	72

H

hom 264

I

image EtherCAT 288, 290

M

MC_AbortTrigger	180
MC_CamIn	229
MC_CamOut	236
MC_CamTblSelect	239
MC_ClearFaults	165
MC_CreateAxis	166
MC_EStop	169
MC_GearIn	242
MC_GearInPos	247
MC_GearOut	252
MC_Halt	202
MC_InitAxis	171
MC_MoveAbsolute	205
MC_MoveAdditive	211
MC_MoveRelative	215
MC_MoveSuperimp	220
MC_MoveVelocity	223
MC_Phasing	255
MC_Power	173
MC_ReadActPos	187
MC_ReadActVel	188
MC_ReadAxisErr	190
MC_ReadBoolPar	192
MC_ReadParam	194
MC_ReadStatus	196
MC_Reference	260
MC_ResetError	175
MC_SetOverride	227
MC_SetPosition	265
MC_Stop	177
MC_SyncSlaves	258
MC_TouchProbe	182
MC_WriteBoolPar	198
MC_WriteParam	200
missing PLC cycles	270
MLTrigGetPos	157
MLTrigGetTime	159
motion library	37-38
adder	53
Axis	71
Block	45
CAM Profile	73
Comparator	74
Convertor	85
Delay	93
Derivator	95
Gear	100
Integrator	102

Master	106
Phaser	131, 270, 278, 288, 291
Pipe	39
PMP	133
Sampler	134
State Machine	38
Synchronizer	140
Trigger	149
motion library function	
MC_AbortTrigger	180
MC_CamIn	229
MC_CamOut	236
MC_CamTblSelect	239
MC_ClearFaults	165
MC_CreateAxis	166
MC_EStop	169
MC_GearIn	242
MC_GearInPos	247
MC_GearOut	252
MC_Halt	202
MC_InitAxis	171
MC_MoveAbsolute	205
MC_MoveAdditive	211
MC_MoveRelative	215
MC_MoveSuperimp	220
MC_MoveVelocity	223
MC_Phasing	255
MC_Power	173
MC_ReadActPos	187
MC_ReadActVel	188
MC_ReadAxisErr	190
MC_ReadBoolPar	192
MC_ReadParam	194
MC_ReadStatus	196
MC_Reference	260
MC_ResetError	175
MC_SetOverride	227
MC_SetPosition	265
MC_Stop	177
MC_SyncSlaves	258
MC_TouchProbe	182
MC_WriteBoolPar	198
MC_WriteParam	200

P**phasing**

PLCopen	255
synchronizer pipe block	140

position

feedback position	72
reference position	73-74

PrintMessage

296

R

reference position	73-74
registration	177
rising edge	151

S

servo axis	171
stats	268, 270, 278

T

timeout	
EtherCAT	273
torque feed-forward	88
trademarks	2

About Kollmorgen

Kollmorgen is a leading provider of motion systems and components for machine builders. Through world-class knowledge in motion, industry-leading quality and deep expertise in linking and integrating standard and custom products, Kollmorgen delivers breakthrough solutions that are unmatched in performance, reliability and ease-of-use, giving machine builders an irrefutable marketplace advantage.

For assistance with your application needs, visit www.kollmorgen.com or contact us at:

North America

KOLLMORGEN

203A West Rock Road
Radford, VA 24141 USA

Internet www.kollmorgen.com
E-Mail support@kollmorgen.com
Tel.: +1 - 540 - 633 - 3545
Fax: +1 - 540 - 639 - 4162

Europe

KOLLMORGEN Europe GmbH

Pempelfurtstraße 1
40880 Ratingen, Germany

Internet www.kollmorgen.com
E-Mail technik@kollmorgen.com
Tel.: +49 - 2102 - 9394 - 0
Fax: +49 - 2102 - 9394 - 3155

Asia

KOLLMORGEN

Rm 2205, Scitech Tower, China
22 Jianguomen Wai Street

Internet www.kollmorgen.com
E-Mail sales.asia@kollmorgen.com
Tel.: +86 - 400 666 1802
Fax: +86 - 10 6515 0263

KOLLMORGEN®

Because Motion Matters™