

NOTE: Use the BK32 and BK42 Motor Files for B8961/2 Firmware Version Earlier than 6.8x. Version 6.8x has the files for BK32 and BK42.