

This is a Discontinued Product

Contact Kollmorgen Customer Support at
1-540-633-3545 or email us at support.kollmorgen.com
if assistance is required.

ADDENDUM TO 400030-060 SS2000MD4-M INSTALLATION MANUAL FOR USE WITH MODEL SS2000MD4-M-103

Replace Section 4.7 STEP RESOLUTION, with the following:

The number of pulses per revolution is selected using positions 7 and 8 of the switch described in Section 4.5. The following chart provides the correct switch setting for each available step resolution.

Switch Position		Step Resolution	Pulses Per Revolution
7	8		
0 (OFF)	0 (OFF)	Full	200
1 (ON)	0 (OFF)	1/2	400
0 (OFF)	1 (ON)	1/5	1,000
1 (ON)	1 (ON)	1/10	2,000

www.superiorelectric.com



383 MIDDLE STREET • BRISTOL, CT 06010
(860) 585-4500 • FAX: (860) 589-2136



ADDENDUM TO 400030-060 SS2000MD4-M INSTALLATION MANUAL FOR USE WITH MODEL SS2000MD4-M-103

Replace Section 4.7 STEP RESOLUTION, with the following:

The number of pulses per revolution is selected using positions 7 and 8 of the switch described in Section 4.5. The following chart provides the correct switch setting for each available step resolution.

Switch Position		Step Resolution	Pulses Per Revolution
7	8		
0 (OFF)	0 (OFF)	Full	200
1 (ON)	0 (OFF)	1/2	400
0 (OFF)	1 (ON)	1/5	1,000
1 (ON)	1 (ON)	1/10	2,000

www.superiorelectric.com



383 MIDDLE STREET • BRISTOL, CT 06010
(860) 585-4500 • FAX: (860) 589-2136

